



GE Medical Systems

gehealthcare.com

Technical Publication

Direction 5134194-100

Revision 11

Pages 1 - 488

GE Medical Systems LightSpeed 5.X HP60 Illustrated Parts List



LEGAL NOTES

TRADEMARKS

Adobe, the Adobe logo, Acrobat, the Acrobat logo, Exchange, and PostScript are trademarks of Adobe Systems Incorporated or its subsidiaries and may be registered in certain jurisdictions.

Microsoft is a registered trademark and Windows is a trademark of Microsoft Corporation.

All other products and their name brands are trademarks of their respective holders.

COPYRIGHTS

All Material, Copyright © 2003-2007 by General Electric Company, Inc. All rights reserved.

IMPORTANT PRECAUTIONS

LANGUAGE

WARNING

- THIS SERVICE MANUAL IS AVAILABLE IN ENGLISH ONLY.
- IF A CUSTOMER'S SERVICE PROVIDER REQUIRES A LANGUAGE OTHER THAN ENGLISH, IT IS THE CUSTOMER'S RESPONSIBILITY TO PROVIDE TRANSLATION SERVICES.
- DO NOT ATTEMPT TO SERVICE THE EQUIPMENT UNLESS THIS SERVICE MANUAL HAS BEEN CONSULTED AND IS UNDERSTOOD.
- FAILURE TO HEED THIS WARNING MAY RESULT IN INJURY TO THE SERVICE PROVIDER, OPERATOR OR PATIENT FROM ELECTRIC SHOCK, MECHANICAL OR OTHER HAZARDS.

AVERTISSEMENT

- CE MANUEL DE MAINTENANCE N'EST DISPONIBLE QU'EN ANGLAIS.
- SI LE TECHNICIEN DU CLIENT A BESOIN DE CE MANUEL DANS UNE AUTRE LANGUE QUE L'ANGLAIS, C'EST AU CLIENT QU'IL INCOMBE DE LE FAIRE TRADUIRE.
- NE PAS TENTER D'INTERVENTION SUR LES ÉQUIPEMENTS TANT QUE LE MANUEL SERVICE N'A PAS ÉTÉ CONSULTÉ ET COMPRIS.
- LE NON-RESPECT DE CET AVERTISSEMENT PEUT ENTRAÎNER CHEZ LE TECHNICIEN, L'OPÉRATEUR OU LE PATIENT DES BLESSURES DUES À DES DANGERS ÉLECTRIQUES, MÉCANIQUES OU AUTRES.

WARNUNG

- DIESES KUNDENDIENST-HANDBUCH EXISTIERT NUR IN ENGLISCHER SPRACHE.
- FALLS EIN FREMDER KUNDENDIENST EINE ANDERE SPRACHE BENÖTIGT, IST ES AUFGABE DES KUNDEN FÜR EINE ENTSPRECHENDE ÜBERSETZUNG ZU SORGEN.
- VERSUCHEN SIE NICHT, DAS GERÄT ZU REPARIEREN, BEVOR DIESES KUNDENDIENST-HANDBUCH ZU RATE GEZOGEN UND VERSTANDEN WURDE.
- WIRD DIESE WARNUNG NICHT BEACHTET, SO KANN ES ZU VERLETZUNGEN DES KUNDENDIENSTTECHNIKERS, DES BEDIENERS ODER DES PATIENTEN DURCH ELEKTRISCHE SCHLÄGE, MECHANISCHE ODER SONSTIGE GEFAHREN KOMMEN.

LANGUAGE (CONTINUED)

AVISO

- ESTE MANUAL DE SERVICIO SÓ LO EXISTE EN INGLÉS.
- SI ALGÚN PROVEEDOR DE SERVICIOS AJENO A GEMS SOLICITA UN IDIOMA QUE NO SEA EL INGLÉS, ES RESPONSABILIDAD DEL CLIENTE OFRECER UN SERVICIO DE TRADUCCIÓN.
- NO SE DEBERÁ DAR SERVICIO TÉCNICO AL EQUIPO, SIN HABER CONSULTADO Y COMPRENDIDO ESTE MANUAL DE SERVICIO.
- LA NO OBSERVANCIA DEL PRESENTE AVISO PUEDE DAR LUGAR A QUE EL PROVEEDOR DE SERVICIOS, EL OPERADOR O EL PACIENTE SUFRAN LESIONES PROVOCADAS POR CAUSAS ELÉCTRICAS, MECÁNICAS O DE OTRA NATURALEZA.

ATENÇÃO

- ESTE MANUAL DE ASSISTÊNCIA TÉCNICA SÓ SE ENCONTRA DISPONÍVEL EM INGLÊS.
- SE QUALQUER OUTRO SERVIÇO DE ASSISTÊNCIA TÉCNICA, QUE NÃO A GEMS, SOLICITAR ESTES MANUAIS NOUTRO IDIOMA, É DA RESPONSABILIDADE DO CLIENTE FORNECER OS SERVIÇOS DE TRADUÇÃO.
- NÃO TENHA TENTAR REPARAR O EQUIPAMENTO SEM TER CONSULTADO E COMPREENDIDO ESTE MANUAL DE ASSISTÊNCIA TÉCNICA.
- O NÃO CUMPRIMENTO DESTE AVISO PODE POR EM PERIGO A SEGURANÇA DO TÉCNICO, OPERADOR OU PACIENTE DEVIDO A CHOQUES ELÉTRICOS, MECÂNICOS OU OUTROS.

AVVERTENZA

- IL PRESENTE MANUALE DI MANUTENZIONE È DISPONIBILE SOLTANTO IN INGLESE.
- SE UN ADDETTO ALLA MANUTENZIONE ESTERNO ALLA GEMS RICHIEDE IL MANUALE IN UNA LINGUA DIVERSA, IL CLIENTE È TENUTO A PROVVEDERE DIRETTAMENTE ALLA TRADUZIONE.
- SI PROCEDA ALLA MANUTENZIONE DELL'APPARECCHIATURA SOLO DOPO AVER CONSULTATO IL PRESENTE MANUALE ED AVERNE COMPRESO IL CONTENUTO.
- NON TENERE CONTO DELLA PRESENTE AVVERTENZA POTREBBE FAR COMPIERE OPERAZIONI DA CUI DERIVINO LESIONI ALL'ADDETTO ALLA MANUTENZIONE, ALL'UTILIZZATORE ED AL PAZIENTE PER FOLGORAZIONE ELETTRICA, PER URTI MECCANICI OD ALTRI RISCHI.

LANGUAGE (CONTINUED)

警告

このサービスマニュアルには英語版しかありません。

G E M S 以外でサービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。

このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないで下さい。

この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。

注意:

本维修手册仅存有英文本。

非 G E M S 公司的维修员要求非英文本的维修手册时，
客户需自行负责翻译。

未详细阅读和完全了解本手册之前，不得进行维修。

忽略本注意事项会对维修员，操作员或病人造成触电，机械伤害或其他伤害。

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent write "Damage In Shipment" on ALL copies of the freight or express bill BEFORE delivery is accepted or "signed for" by a GE representative or hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

Call Traffic and Transportation, Milwaukee, WI (414) 785 5052 or 8*323 5052 immediately after damage is found. At this time be ready to supply name of carrier, delivery date, consignee name, freight or express bill number, item damaged and extent of damage.

Complete instructions regarding claim procedure are found in Section S of the Policy And Procedures Bulletins.

14 July 1993

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Medical personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Medical Systems Group, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Medical Systems Group, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

LITHIUM BATTERY CAUTIONARY STATEMENTS



CAUTION
Risk of
Explosion

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



ATTENTION
Danger
d'Explosion

Il y a danger d'explosion s'il y a un remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GEMS CQA Process to report all omissions, errors, and defects in this publication.

Revision History

Revision	Date	Reason for change
11	12/01/08	Updated Gantry
10	12/21/07	Updated Gantry and PDU
9	04/14/07	Updated Gantry PDU (PQR13097455)
8	11/27/06	Updated Table, PDU, Gantry Section and Miscellaneous Items (PQR13057840, 13088237)
7	06/20/06	Updated Gantry Section and Miscellaneous Items (PQR13058053, 13072972).
6	01/30/06	Updated Gantry Section and Miscellaneous Items.
5	11/14/05	Updated Gantry Section, PDU Section
4	08/18/05	Updated PDU Section
3	05/25/05	Deleted OC Section
2	03/25/05	Updated Gantry Section
1	02/16/05	Initial Release

Table of Contents

Chapter 1

Manual Conventions	29
Section 1.0 — Page Layout, Including Finger Tabs	29
Section 2.0 — Manual Organization.....	30

Chapter 2

Table	31
Cat Coll/H Power Table with Footswitch (2373155 BOM, rev 0).....	31
Section 1.0 — Table Assembly - H Power (2335179).....	32
Table Assembly - H Power (2335179, sheet 1, rev 2).....	32
Table Assembly - H Power (2335179, sheet 2, rev 2).....	33
Table Assembly - H Power (2335179 BOM, rev 9)	34
1.1 Side Panel Kit (2269167-2).....	37
Side Panel Kit for H2 LCC Cathay Table (2269167-2 BOM, rev 0).....	37
1.2 Cover Table Top - Left (2372371)	38
Cover Table Top - Left (2372371, sheet 1, rev 1)	38
Cover Table Top - Left (2372371 BOM, rev 01).....	39
1.3 Cover Table Top - Right (2372372)	40
Cover Table Top - Right (2372372, sheet 1, rev 1).....	40
Cover Table Top - Right (2372372 BOM, rev 1)	41
1.4 860-941208 Metalless Cradle (2115992-5)	42
Metalless Cradle (2115992, sheet 2, rev 7)	42
Metalless Cradle (2115992-5 BOM, rev 1).....	43
1.5 Table Subassembly - H Power (2335178).....	44
Table Subassembly (2335178, sheet 1, rev 5).....	44
Table Subassembly (2335178, sheet 2, rev 2).....	45
Table Subassembly (2335178, sheet 3, rev 2).....	46
Table Subassembly (2335178, sheet 4, rev 1).....	47
Table Subassembly (2335178 BOM, rev 8)	48

1.5.1 – Carriage Assembly (2269168-2)	52
Carriage Assembly (2269168, sheet 2, rev 1)	52
Carriage Assembly (2269168-2 BOM, rev 1)	53
1.5.2 – Latch Assembly (2269177)	54
Latch Assembly (2269177, sheet 1, rev 0)	54
Latch Assembly (2269177 BOM, rev 0)	55
1.5.3 – Cradle Drive Assembly (2339120)	56
Cradle Drive Assembly (2339120, sheet 1, rev 2)	56
Cradle Drive Assembly (2339120, sheet 2, rev 1)	57
Cradle Drive Assembly (2339120, sheet 3, rev 0)	58
Cradle Drive Assembly (2339120 BOM, rev 6)	59
1.5.4 – Encoder Assembly, Elevation - H Power (2337217)	62
Encoder Assembly, Elevation - H Power (2337217, sheet 1, rev 3)	62
Encoder Assembly, Elevation - H Power (2337217 BOM, rev 3)	63
1.5.5 – Table Frame Assembly (2335177)	64
Table Frame Assembly (2335177, sheet 1, rev 2)	64
Table Frame Assembly (2335177, sheet 2, rev 0)	65
Table Frame Assembly (2335177, sheet 3, rev 2)	66
Table Frame Assembly (2335177, sheet 4, rev 0)	67
Table Frame Assembly (2335177, sheet 5, rev 0)	68
Table Frame Assembly (2335177 BOM, rev 5)	69
Section 2.0 — Foot Switch Assembly (2330508)	73
Foot Switch Assembly (2330508, sheet 1, rev 2)	73
Footswitch Assembly (2330508 BOM, rev 6)	74

Chapter 3

PDU	75
NGPDU -90 KVA VERSION- (B79932AB BOM, rev 1)	75
Section 1.0 — NGPDU (90 KVA VERSION) (2326492-3)	76
NGPDU -90 KVA VERSION- (2326492-3ADW, sheet 1, rev 1)	76
NGPDU -90 KVA VERSION- (2326492-3 BOM, Rev 6)	77

1.1	NGPDU ASSEMBLY3 (2380116)	78
	NGPDU ASSEMBLY3 (2380116ADW, sheet 1, rev 0)	78
	NGPDU ASSEMBLY3 (2380116ADW, sheet 2, rev 1)	79
	NGPDU ASSEMBLY3 (2380116ADW, sheet 3, rev 2)	80
	NGPDU ASSEMBLY3 (2380116 BOM, Rev 18)	81

Chapter 4

Gantry (LS 16, Ultra, Plus)..... **89**

Gantry-2385570 BOM Tree	90
-------------------------------	----

Section 1.0 — GANTRY ASSEMBLY W/PHANTOMS..... **91**

1.1	Gantry Assembly w/Phantoms (2385570, -3, -10, -11)	91
	P2033AH HP60 GANTRY W/PHANTOMS (2385570 BOM Rev.: 002)	91
	HP60 GDAS-16 GANTRY WITH PHANTOMS (2385570-3 BOM Rev.: 003)	91
	GDAS16 GANTRY WITH PHANTOMS for EMC Edition2 (2385570-3 BOM Rev.: 001)	91
	GDAS16 Gantry with Phantoms for EMC Edition2 Phase2 (2385570-11 BOM Rev.: 001)	91
1.2	Gantry Assembly w/Phantoms (2399889-2, -10, -11, -12)	92
	HP60 GDAS 4 GANTRY WITH PHANTOMS (2399889-2 BOM Rev.: 001).....	92
	GDAS4 GANTRY WITH PHANTOMS EMC ED2 (2399889-10 BOM Rev.: 001).....	92
	GANTRY WITH PHANTOMS EMC ED2 (2399889-11 BOM Rev.: 001).....	92
	GDAS4 Gantry with Phantoms for EMC Edition2 Phase2 90kVA (2399889-12 BOM Rev.: 001).....	93
1.3	Gantry Assembly w/Phantoms (2399890-2, -10, -11)	93
	GDAS8 GANTRY WITH PHANTOMS (2399890-2 BOM Rev.: 001).....	93
	GDAS8 GANTRY WITH PHANTOMS for EMC Edition2 (2399890-10 BOM Rev.: 001)	93
	GDAS8 GANTRY WITH PHANTOMS for EMC Edition2 Phase2 (2399890-11 BOM Rev.: 001)	93

Section 2.0 — GANTRY ASSEMBLY..... **95**

2.1	Gantry Assembly (2378661, -3, -10, -11)	95
	GANTRY ASM (2378661, sheet 2, rev 9)	95
	LIGHTSPEED 5.0J GANTRY ASM (2378661 BOM Rev.: 030)	96
	LIGHTSPEED 5.0J GANTRY ASM GDAS16 (2378661-3 BOM Rev.: 009).....	97
	HP60 LIGHTSPEED5.0J GDAS16 EMC ED2 (2378661-10 BOM Rev.: 003).....	98
	HP60 LIGHTSPEED5.0J GDAS16 ED2 ASTEC (2378661-11 BOM Rev.: 010).....	99
2.2	Gantry Assembly (2383549-2, -10, -11)	100
	HP60 GANTRY LIGHTSPEED5.0J GDAS8 (2383549-2 BOM Rev.: 004).....	100

	HP60 GANTRY LIGHTSPEED5.0J GDAS8 EMC ED2 (2383549-10 BOM Rev.: 004).....	101
	HP60 LIGHTSPEED5.0J GDAS8 EMC ED2 ASTEC (2383549-11 BOM Rev.: 008).....	102
2.3	Gantry Assembly (2383550-2, -10, -11, -12).....	104
	HP60 GANTRY LIGHTSPEED5.0J GDAS4 (2383550-2 BOM Rev.: 004).....	104
	HP60 GANTRY LIGHTSPEED5.0J GDAS4 EMC Ed-2 (2383550-10 BOM Rev.: 004).....	105
	HP60 LIGHTSPEED5.0J GDAS4 EMC ED2 ASTEC (2383550-11 BOM Rev.: 008).....	106
	HP60 LIGHTSPEED5.0J GDAS4 EMC ED2 ASTEC 90KVA (2383550-12 BOM Rev.: 005)	107
Section 3.0	— H-Power60 Vertical Assembly (2378662, -2, -3, -4, -5, -6, -7, -8, -9, -10)	109
	HP60 VERTICAL ASSEMBLY (2378662, sheet 1, rev 2)	109
	HP60 VERTICAL ASSEMBLY (2378662, sheet 2, rev 0)	110
	HP60 VERTICAL ASSEMBLY (2378662, sheet 3, rev 2)	111
	HP60 VERTICAL ASSEMBLY (2378662, sheet 4, rev 1)	112
	HP60 VERTICAL ASSEMBLY (2378662, sheet 5, rev 1)	113
	HP60 VERTICAL ASM (2378662 BOM Rev.: 016).....	114
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 2, rev 9)	120
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 3, rev 6)	121
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 4, rev 6)	122
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 5, rev 6)	123
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 6, rev 6)	124
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 7, rev 6)	125
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 8, rev 6)	126
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 9, rev 2)	127
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 10, rev 6)	128
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 11, rev 11)	129
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 12, rev 6)	130
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 13, rev 8)	131
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 14, rev 7)	132
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 15, rev 8)	133
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 16, rev 6)	134
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 17, rev 6)	135
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 18, rev 6)	136
	HP60 VERTICAL ASSEMBLY (2378662-2, sheet 19, rev 10)	137
	HP60 GANTRY GDAS16 VERTICAL ASM (2378662-2 BOM Rev.: 014).....	138
	HP60 GANTRY GDAS8 VERTICAL ASM (2378662-3 BOM Rev.: 008).....	143
	HP60 GANTRY GDAS4 VERTICAL ASM (2378662-4 BOM Rev.: 008).....	148

	HP60 GANTRY GDAS16 ED2 VERTICAL ASM (2378662-5 BOM Rev.: 005).....	153
	HP60 GANTRY GDAS8 ED2 VERTICAL ASM (2378662-6 BOM Rev.: 007).....	158
	HP60 GANTRY GDAS4 ED2 VERTICAL ASM (2378662-7 BOM Rev.: 007).....	164
	HP60 GANTRY GDAS16 ED2 ASTEC VERTICAL ASM (2378662-8 BOM Rev.: 012).....	169
	HP60 GANTRY GDAS8 ED2 ASTEC VERTICAL ASM (2378662-9 BOM Rev.: 015).....	176
	HP60 GANTRY GDAS4 ED2 ASTEC VERTICAL ASM (2378662-10 BOM Rev.: 015).....	184
3.1	H-Power60 HORIZONTAL Assembly (2378663, -2, -3, -5, -6, -8, -9).....	194
	HP60 HORIZONTAL ASSEMBLY (2378663, sheet 1, rev 5).....	194
	HP60 HORIZONTAL ASSEMBLY (2378663, sheet 2, rev 3).....	195
	HP60 HORIZONTAL ASM (2378663 BOM Rev.: 021)	196
	HP60 HORIZONTAL ASSEMBLY (2378663-2, sheet 2, rev 9)	199
	HP60 HORIZONTAL ASSEMBLY (2378663-2, sheet 3, rev 2)	200
	HP60 HORIZONTAL ASSEMBLY (2378663-2, sheet 4, rev 8)	201
	HP60 GDAS16 HORIZONTAL ASM (2378663-2 BOM Rev.: 011)	202
	HP60 GANTRY GDAS8 HORIZONTAL ASM (2378663-3 BOM Rev.: 006)	204
	HP60 GANTRY GDAS16 ED2 HORIZONTAL ASM (2378663-5 BOM Rev.: 006).....	207
	HP60 GANTRY GDAS4-8 ED2 HORIZONTAL ASM (2378663-6 BOM Rev.: 005).....	209
	HP60 GANTRY GDAS16 ED2 ASTEC HORIZONTAL ASM (2378663-8 BOM Rev.: 008)	212
	HP60 GANTRY GDAS4-8 ED2 ASTEC HORIZONTAL ASM (2378663-9 BOM Rev.: 008).....	216
	3.1.1 – H-POWER GANTRY HIGH LEVEL BUY (2357736)	220
	H-POWER GANTRY HIGH LEVEL BUY (2357736, sheet 1, rev 2)	220
	H-POWER GANTRY HIGH LEVEL BUY (2357736, sheet 2, rev 2)	221
	H-POWER GANTRY HIGH LEVEL BUY (2357736 BOM Rev.: 011).....	222
	3.1.1.1 – HYDRAULIC TILT MOTOR ASSY (2334727)	224
	HYDRAULIC TILT MOTOR ASSY (2334727, sheet 1, rev 3)	224
	HYDRAULIC TILT MOTOR ASSY (2334727, sheet 2, rev 1)	225
	HYDRAULIC TILT MOTOR ASSY (2334727, sheet 3, rev 0)	226
	HYDRAULIC TILT MOTOR ASSY (2334727 BOM Rev.: 005)	227
	3.1.2 – PERFORMIX ULTRA TUBE UNIT (D3186T).....	228
	PERFORMIX ULTRA TUBE UNIT (D3186T BOM Rev.: 006).....	228
	3.1.2.1 – Performix LightSpeed Red Reloaded Tube Unit and Gantry Mounting Bracket Assembly (5111363-4)	229
rev 8)	PERFORMIX LIGHTSPEED RED RELOADED TUBE UNIT & GANTRY MOUNTING BRACKET ASM (5111363, sheet 1, rev 8)	229
	Performix LightSpeed Red Reloaded Tube Unit and Gantry Mounting Bracket Assembly (5111363-4 BOM Rev.: 006) ..	230

3.1.3 – HELIOS 4 COLLIMATOR ASSEMBLY (2214768-4).....	232
HELIOS 4 COLLIMATOR ASSEMBLY (2214768, sheet 4, rev 6)	232
HELIOS 4 COLLIMATOR ASSEMBLY (2214768-4 BOM Rev.: 002)	233
3.1.3.1 – HELIOS 4 COLLIMATOR (2120100-4)	234
HELIOS 4 COLLIMATOR (2120100-4, sheet 7, rev 9)	234
HELIOS 4 COLLIMATOR (2120100-4, sheet 8, rev 8)	235
HELIOS 4 COLLIMATOR (2120100-4 BOM Rev.: 008).....	236
H4 COLLIMATOR BASE ASSEMBLY (2273645-3)	238
H4 COLLIMATOR BASE ASSEMBLY (2273645, sheet 1, rev 2)	238
H4 COLLIMATOR BASE ASSEMBLY (2273645-3 BOM Rev.: 001)	239
3.1.4 – Helios 4 collimator with notched filler bar and rating plate (5140001-4).....	240
Helios 4 collimator with notched filler bar and rating plate (5140001, sheet 4, rev 1)	240
Helios 4 collimator with notched filler bar and rating plate (5140001-4 BOM Rev.: 008)	241
3.1.4.1 – Helios 4 collimator with notched filler bar (5140000-4)	242
Helios 4 collimator with notched filler bar (5140000, sheet 7, rev 1)	242
Helios 4 collimator with notched filler bar (5140000, sheet 8, rev 2)	243
Helios 4 collimator with notched filler bar (5140000-4 BOM Rev.: 010)	244
3.1.5 – JEDI 60 DC GENERATOR (2371333, -2).....	246
JEDI 60 Structure (2371333).....	246
JEDI 60 Structure (2371333-2)	246
JEDI 60 DC GENERATOR (2371333, sheet 1, rev2)	247
JEDI 60 DC GENERATOR -For system with MDAS ONLY- (2371333 BOM Rev.: 005).....	248
JEDI 60 DC GENERATOR (2371333-2, sheet 1, rev 1)	249
JEDI 60DC Generator (2371333-2 BOM Rev.: 009).....	250
3.1.5.1 – JEI 60DC POWER MODULE (5168246).....	250
JEI 60DC POWER MODULE (5168246 BOM Rev.: 002)	250
3.1.5.2 – JEDI 60DC HLB POWER UNIT (2377668, -2) (Order 2401826 or 2401826-2 when replacing this part.)	252
JEDI 60DC HLB POWER UNIT (2377668, sheet 1, rev 1)	252
JEDI 60DC HLB POWER UNIT (2377668 BOM Rev.: 002).....	253
JEDI 60DC HLB POWER UNIT (2377668-2, sheet 1, rev 1)	254
JEDI 60DC HLB POWER UNIT (2377668-2 BOM Rev.: 003)	255
POWER UNIT JEDI 60 DC (2241515-2, -3).....	256
POWER UNIT JEDI 60 DC (2241515-2, sheet 1, rev 2)	256
POWER UNIT JEDI 60 DC (2241515-2, sheet 2, rev 2)	257

POWER UNIT JEDI 60 DC (2241515-2 BOM Rev.: 010)	258
POWER UNIT JEDI 60 DC (2241515-3, sheet 1, rev 1)	259
POWER UNIT JEDI 60 DC (2241515-3, sheet 2, rev 1)	260
POWER UNIT JEDI 60 DC (2241515-3 BOM Rev.: 008)	261
EQUIPED INVERTER JEDI 60 DC (2242441-2, sheet 1, rev 0).....	262
EQUIPED INVERTER JEDI 60 DC (2242441-2 BOM Rev.: 002).....	263
EQUIPED INVERTER JEDI 60 DC (2242441-3, sheet 1, rev 1).....	264
EQUIPED INVERTER JEDI 60 DC (2242441-3 BOM Rev.: 004).....	265
PROGRAMMED KV CTRL (2351200-16 BOM Rev.: 000).....	265
PPC KV CTRL V2E (2340155-5 BOM Rev.: 002).....	266
Programed KV control P6.30BF4 (5117564-10 BOM Rev.: 001).....	266
PPC KV CTRL V3 (2382791-4 BOM Rev.: 006)	266
POWER UNIT CABLES JEDI 60 DC (2246200-2 BOM Rev.: 001)	267
PI FILTER ASSEMBLY (2375375)	268
PI FILTER ASSEMBLY (2375375, sheet 1, rev 3)	268
PI FILTER ASSEMBLY (2375375, sheet 2, rev 3)	269
PI FILTER ASM2375375 BOM Rev.: 006)	270
3.1.5.3 – JEDI STD HV TANK (2186730) (Order 2214527 when replacing this part.).....	271
JEDI STD HV TANK (2186730, sheet 1, rev 2).....	271
JEDI STD HV TANK (2186730 BOM Rev.: 009).....	272
3.1.5.4 – HEMIT TANK JEDI 60 DC (5176270)	272
HEMIT TANK JEDI 60 DC (5176270 BOM Rev.: 001).....	272
3.1.5.5 – HEMIT TANK JEDI 60 DC (2237336-2) (Order 2246223-2 when replacing this part.)	273
HEMIT TANK JEDI 60 DC (2237336-2, sheet 1, rev 2)	273
HEMIT TANK JEDI 60 DC (2237336-2 BOM Rev.: 007).....	274
EQUIPED COVER HEMIT JEDI 60 DC (2239703-2).....	276
EQUIPED COVER HEMIT JEDI 60 DC (2239703-2 BOM Rev.: 007)	276
3.1.5.6 – JH4 AUXILIARY EQUIPED V2 (2324118)	279
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 1, rev 8)	279
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 2, rev 8)	280
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 3, rev 8)	281
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 4, rev 8)	282
JH4 AUXILIARY EQUIPED V2 (2324118 BOM Rev.: 023).....	283
3.1.5.7 – JEDI 60DC INTER-MODULE CABLE SET (2377667).....	285
JEDI 60DC INTER-MODULE CABLE SET (2377667 BOM Rev.: 003)	285

3.1.6 – PWR SUPPLY ASSEMBLY, 24V DC (H16) (2334457)	286
PWR SUPPLY ASSEMBLY, 24V DC -H16- (2334457, sheet 1, rev 0)	286
PWR SUPPLY ASSEMBLY, 24V DC (H16) (2334457 BOM Rev.: 000)	287
3.1.7 – DHCB / FUSE BOX ASM (HP60) (2331963-4)	288
DHCB / FUSE BOX ASM -HP60- (2331963-2, sheet 1, rev 3)	288
DHCB / FUSE BOX ASM -HP60- (2331963-2, sheet 2, rev 1)	289
DHCB / FUSE BOX ASM (HP60) (2331963-4 BOM Rev.: 000)	290
3.1.7.1 – HARNESS, FUSEBX/ORP/DAS/INV/ (2377650)	292
HARNESS, FUSEBX/ORP/DAS/INV/ (2377650, sheet 1, rev 2)	292
HARNESS, FUSEBX/ORP/DAS/INV/ (2377650 BOM Rev.: 001)	293
3.1.8 – POWER SUPPLY ASSEMBLY, 12V DC PARALLEL (H16) (2334459)	294
POWER SUPPLY ASSEMBLY, 12V DC PARALLEL -H16- (2334459, sheet 1, rev 0)	294
POWER SUPPLY ASSEMBLY, 12V DC PARALLEL (H16) (2334459 BOM Rev.: 000)	295
3.1.9 – HOME FLAG (2227383-2)	296
HOME FLAG (2227383, sheet 1, rev 3)	296
HOME FLAG (2227383-2 BOM Rev.: 001)	297
3.2 ASSEMBLY, S/R 120V PWR & INTERCOM BD (2357521, -2)	298
ASSEMBLY, S/R 120V PWR & INTERCOM BD (2357521, sheet 1, rev 2)	298
ASSEMBLY, S/R 120V PWR & INTERCOM BD (2357521 BOM Rev.: 004)	299
SLIPRING 120V PS AND INTERCOM PWA ASM, EMC ED2 (2357521-2 BOM Rev.: 005)	299
3.3 DETECTOR PLATE ASSEMBLY (2358133, -2, -4)	302
DETECTOR PLATE ASSEMBLY, H4 (2358133, sheet 1, rev 3)	302
DETECTOR PLATE ASSEMBLY, H4 (2358133 BOM Rev.: 002)	303
DETECTOR PLATE ASSEMBLY, GDAS (2358133-2 BOM Rev.: 001)	303
DAS-DET PLATE ASM, 9.88 STEEL, GDAS, EMC Ed. 2 (2358133-4 BOM Rev.: 002)	304
3.3.1 – DAS COLLECTOR ASSEMBLY (H4) (2358139, -2, -3)	306
DAS COLLECTOR ASSEMBLY -H4- (2358139, sheet 1, rev 4)	306
DAS COLLECTOR ASSEMBLY (H4) (2358139 BOM Rev.: 004)	307
DAS COLLECTOR ASSEMBLY H4, GDAS-16 (2358139-2 BOM Rev.: 005)	307
GDAS EMC COLLECTOR ASSEMBLY (2358139-3, sheet 1, rev 1)	309
GDAS EMC COLLECTOR ASSEMBLY (2358139-3 BOM Rev.: 006)	310
3.3.1.1 – BP/CHASSIS LT ASSEMBLY (2371625, -2, -3, -4, -5)	311
BP/CHASSIS LT ASSEMBLY -H4- (2371625, sheet 1, rev 1)	311
BP/CHASSIS LT ASSEMBLY (H4) (2371625 BOM Rev.: 002)	312

BP/CHASSIS LT ASSEMBLY (GDAS) (2371625-2 BOM Rev.: 000).....	312
BP-Chassis Left EMC Asm - GDAS (2371625-3, sheet 1, rev 2).....	313
BP-Chassis Left EMC Asm - GDAS (2371625-3 BOM Rev.: 001).....	314
GDAS 16 Slice LEFT BP-Chassis Asm EMC Edition 1-2 (2371625-4 BOM Rev.: 001)	314
MDAS 16 Slice LEFT BP-Chassis Asm - with Intercon Shroud (2371625-5 BOM Rev.: 001)	314
<i>CHASSIS LT ASSEMBLY (H4) (2371628, -2)</i>	<i>316</i>
CHASSIS LT ASSEMBLY -H4- (2371628, sheet 1, rev 2).....	316
CHASSIS LT ASSEMBLY (H4) (2371628 BOM Rev.: 004)	317
Chassis Left EMC Asm - GDAS (2371628-2, sheet 1, rev 3).....	318
Chassis Left EMC Asm - GDAS (2371628-2 BOM Rev.: 003).....	319
<i>3.3.1.2 – BP/CHASSIS CTR ASSEMBLY (H4) (2371626, -2, -3, -4)</i>	<i>320</i>
BP/CHASSIS CTR ASSEMBLY -H4- (2371626, sheet 1, rev 1).....	320
BP/CHASSIS CTR ASSEMBLY (H4) (2371626 BOM Rev.: 002)	321
BP/CHASSIS CTR ASSEMBLY (GDAS) (2371626-2 BOM Rev.: 000)	321
BP-Chassis Center EMC Asm - GDAS (2371626-3, sheet 1, rev 2).....	322
BP-Chassis Center EMC Asm - GDAS (2371626-3 BOM Rev.: 001)	323
GDAS-MDAS 16 Slice CENTER BP-Chassis Asm (2371626-4 BOM Rev.: 001).....	323
<i>CHASSIS CTR ASSEMBLY (H4) (2371630, -2)</i>	<i>324</i>
CHASSIS CTR ASSEMBLY -H4- (2371630, sheet 1, rev 2).....	324
CHASSIS CTR ASSEMBLY (H4) (2371630 BOM Rev.: 003).....	325
Chassis Center EMC Asm - GDAS (2371630-2, sheet 1, rev 2).....	326
Chassis Center EMC Asm - GDAS (2371630-2 BOM Rev.: 002)	327
<i>3.3.1.3 – BP/CHASSIS RT ASSEMBLY (2371627, -2, -3, -4).....</i>	<i>328</i>
BP/CHASSIS RT ASSEMBLY (2371627, sheet 1, rev 3)	328
BP/CHASSIS RT ASSEMBLY (H4) (2371627 BOM Rev.: 004).....	329
BP/CHASSIS RT ASSEMBLY (GDAS) (2371627-2 BOM Rev.: 002).....	329
BP-Chassis Right EMC Asm - GDAS (2371627-3, sheet 1, rev 2)	330
BP-Chassis Right EMC Asm - GDAS (2371627-3 BOM Rev.: 001).....	331
GDAS-MDAS 16 Slice RIGHT BP-Chassis Asm EDITION 1-2 (2371627-4 BOM Rev.: 001).....	331
<i>CHASSIS RT ASSEMBLY (H4) (2371631, -2)</i>	<i>332</i>
CHASSIS RT ASSEMBLY -H4- (2371631, sheet 1, rev 5)	332
CHASSIS RT ASM (H4) (2371631 BOM Rev.: 006).....	333
Chassis Right EMC Asm - GDAS (2371631-2, sheet 1, rev 2)	334
Chassis Right EMC Asm - GDAS (2371631-2 BOM Rev.: 002).....	335

	3.3.2 – DETECTOR PLATE SUB ASSEMBLY (H4) (2357478)	336
	DETECTOR PLATE SUB ASSEMBLY -H4- (2357478, sheet 1, rev 0)	336
	DETECTOR PLATE SUB ASSEMBLY (H4) (2357478 BOM Rev.: 000).....	337
	3.3.3 – DETECTOR PLATE SUB-ASM, STEEL (GDAS) (2392114)	338
	DETECTOR PLATE SUB-ASM, STEEL -GDAS- (2392114, sheet 1, rev 3).....	338
	DETECTOR PLATE SUB-ASM, STEEL (GDAS) (2392114 BOM Rev.: 004).....	339
	3.3.4 – DAS DUCT FAN ASSEMBLY (H16) (2333651)	340
	DAS DUCT FAN ASSEMBLY -H16- (2333651, sheet 1, rev 3)	340
	DAS DUCT FAN ASSEMBLY (H16) (2333651 BOM Rev.: 007).....	341
3.4	HP60 GDAS DETECTOR PLATE ASM -4/8SLICE (2286241-5, -6, -7, -8, -9, -10)	342
	GDAS DETECTOR PLATE ASSEMBLY -4/8SLICE (2286241-5, sheet 1, rev 3).....	342
	HP60 GDAS DETECTOR PLATE ASM -8SLICE (2286241-5 BOM Rev.: 001).....	343
	HP60 GDAS DETECTOR PLATE ASM -4SLICE (2286241-6 BOM Rev.: 001).....	343
	HP60 DETECTOR PLATE ASM GDAS8 ED2 (2286241-7 BOM Rev.: 001).....	344
	HP60 GDAS DETECTOR PLATE ASM -4SLICE ED2 (2286241-8 BOM Rev.: 001).....	344
	HP60 GANTRY DETECTOR_PLATE_ASM_GDAS-8SLICE EMC2 (2286241-9 BOM Rev.: 001).....	345
	HP60 DETECTOR PLATE ASM GDAS4 ED2-2 (2286241-10 BOM Rev.: 001).....	345
	3.4.1 – GDAS8 COLLECTOR Detection HP60 (5112908, -2, -3)	348
	GDAS8 COLLECTOR Detection HP60 (5112908 BOM Rev.: 001)	348
	HP60 GANTRY GDAS8 EMC COLLECTOR (5112908-2 BOM Rev.: 001)	348
	HP60 GANTRY GDAS8 EMC COLLECTOR2 (5112908-3 BOM Rev.: 001)	348
	3.4.2 – GDAS4 COLLECTOR Detection HP60 (5112909, -2, -3)	350
	GDAS4 COLLECTOR DETECTOR HP60 (5112909, sheet 1, rev 3)	350
	GDAS4 COLLECTOR Detection HP60 (5112909 BOM Rev.: 004)	351
	HP60 GANTRY GDAS4 EMC COLLECTOR (5112909-2 BOM Rev.: 003)	351
	HP60 GANTRY GDAS4 EMC COLLECTOR2 (5112909-3 BOM Rev.: 002)	352
	3.4.3 – WARP3 MP3 DETECTOR ASM (2282649)	354
	WARP3 MP3 DETECTOR ASSEMBLY (2282649, sheet 1, rev 4)	354
	WARP3 MP3 DETECTOR ASM (2282649 BOM Rev.: 006).....	355
	3.4.4 – HP60 GANTRY DETECTOR PALTE SUB ASM GDAS4-8 (2297580-3)	356
	HP60 GANTRY DETECTOR PLATE SUB ASSEMBLY (2297580-3, sheet 1, rev 1)	356
	HP60 GANTRY DETECTOR PALTE SUB ASM GDAS4-8 (2297580-3 BOM Rev.: 001).....	357
	3.4.5 – MDAS DUCT/FAN ASSEMBLY - H3 (2277359)	358
	MDAS DUCT/FAN ASSEMBLY (2277359, sheet 1, rev 1)	358

	MDAS DUCT/FAN ASSEMBLY - H3 (2277359 BOM Rev.: 004).....	359
3.5	H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524, 5118577-2).....	360
	H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524, sheet 1, rev 1).....	360
	H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524, sheet 2, rev 1).....	361
	H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524 BOM Rev.: 004).....	362
	Axial Dynamic Braking Module (5118577, sheet 1, rev 3)	364
	Axial Dynamic Braking Module (5118577, sheet 2, rev 1)	365
	Axial Dynamic Braking Module (5118577-2 BOM Rev.: 002).....	366
3.6	DRIVE ASSEMBLY, H-POWER AXIAL (2217930-2, -3, -4).....	368
	DRIVE ASSEMBLY, H-POWER AXIAL (2217930, sheet 1, rev 6)	368
	DRIVE ASSEMBLY, H-POWER AXIAL (2217930, sheet 3, rev 5)	369
	DRIVE ASSEMBLY, H-POWER AXIAL (2217930-2 BOM Rev.: 001)	370
	DRIVE ASSEMBLY, H-POWER AXIAL (2217930-3 BOM Rev.: 001)	370
	Series windings with a long cable for RT (2217930-4 BOM Rev.: 001)	371
	3.6.1 – AXIAL MOTOR W/ SPROCKET, H-POWER (2235342-3).....	374
	AXIAL MOTOR W/ SPROCKET, H-POWER (2235342-3, sheet 1, rev 0).....	374
	AXIAL MOTOR W/ SPROCKET, H-POWER (2235342-3 BOM Rev.: 000)	375
	3.6.2 – BRAKE ASSEMBLY, H2 AXIAL DRIVE MOTOR (2277225).....	376
	BRAKE ASSEMBLY, H2 AXIAL DRIVE MOTOR (2277225, sheet 1, rev 0).....	376
	BRAKE ASSEMBLY, H2 AXIAL DRIVE MOTOR (2277225 BOM Rev.: 000).....	377
	3.6.3 – AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402)	378
	AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402, sheet 1, rev 2).....	378
	AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402, sheet 2, rev 2).....	379
	AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402 BOM Rev.: 003)	380
3.7	ENCODER ASSEMBLY (2369747, -2 / 5182284).....	382
	ENCODER ASSEMBLY (2369747, sheet 1, rev 1).....	382
	ENCODER ASSEMBLY (2369747 BOM Rev.: 000)	383
	ENCODER ASSEMBLY (2369747-2 BOM Rev.: 001).....	383
	AXIAL DRIVE FEEDBACK ENCODER ASSEMBLY (5182284, sheet 1, rev 2)	384
	AXIAL DRIVE FEEDBACK ENCODER ASSEMBLY (5182284 BOM Rev.: 001).....	385
3.8	BRACE, GANTRY COVER UPPER (2398105, -2).....	386
	BRACE, GANTRY COVER UPPER (2398105, sheet 1, rev 1).....	386
	BRACE, GANTRY COVER UPPER (2398105 BOM Rev.: 000).....	387
	Brace Assembly without terminator (2398105-2 BOM Rev.: 001).....	387

3.9	BRACE, GANTRY COVER LOWER (2368302)	388
	BRACE, GANTRY COVER LOWER (2368302, sheet 1, rev 0).....	388
	BRACE, GANTRY COVER LOWER (2368302 BOM Rev.: 000).....	389
3.10	ORP ASSEMBLY (2358141, -2)	390
	ORP ASSEMBLY (2358141, sheet 1, rev 3).....	390
	ORP ASSEMBLY (2358141 BOM Rev.: 010).....	391
	ORP ASSEMBLY EMC ED2 (2358141-2 BOM Rev.: 004).....	391
3.11	POWER SUPPLY ASSEMBLY, 5V LOGIC (H16) (2334458)	392
	POWER SUPPLY ASSEMBLY, 5V LOGIC -H16- (2334458, sheet 1, rev 0).....	392
	POWER SUPPLY ASSEMBLY, 5V LOGIC (H16) (2334458 BOM Rev.: 000).....	393
3.12	850 MB H-POWER SLIPRING ASSEMBLY (2349589)	394
	850 MB H-POWER SLIPRING ASSEMBLY (2349589, sheet 1, rev 3).....	394
	850 MB H-POWER SLIPRING ASSEMBLY (2349589 BOM Rev.: 004).....	395
	3.12.1 – 850 MB PLATTER HSDCD SLIPRING SYSTEM (2320265)	396
	850 MB PLATTER HSDCD SLIPRING SYSTEM (2320265, sheet 1, rev 0).....	396
	850 MB PLATTER HSDCD SLIPRING SYSTEM (2320265 BOM Rev.: 002).....	397
	3.12.1.1 – H-POWER RECEIVER-ANTENNA ASSEMBLY (2333609)	398
	H-POWER RECEIVER-ANTENNA ASSEMBLY (2333609, sheet 1, rev 1).....	398
	H-POWER RECEIVER-ANTENNA ASSEMBLY (2333609 BOM Rev.: 000).....	399
	3.12.1.2 – SLIPRING ASSEMBLY FOR H-POWER (2349587)	400
	SLIPRING ASSEMBLY FOR H-POWER (2349587, sheet 1, rev 1).....	400
	SLIPRING ASSEMBLY FOR H-POWER (2349587 BOM Rev.: 000).....	401
	3.12.1.3 – VCT Slipring Brushblock (5120819)	402
	VCT Slipring Brushblock (5120819, sheet 1, rev 3).....	402
	VCT Slipring Brushblock (5120819 BOM Rev.: 003).....	403
3.13	TILT, FEEDBACK ASSEMBLY (2356863, -2)	404
	TILT, FEEDBACK ASSEMBLY (2356863, sheet 1, rev 0).....	404
	TILT, FEEDBACK ASSEMBLY (2356863 BOM Rev.: 001).....	405
	TILT FEEDBACK ASSEMBLY, EMC ED2 (2356863-2 BOM Rev.: 002).....	405
3.14	MSUB/TGP ASSEMBLY (2349209)	406
	MSUB/TGP ASSEMBLY (2349209, sheet 1, rev 3).....	406
	MSUB/TGP ASSEMBLY (2349209 BOM Rev.: 009).....	407

3.14.1 – MSUB/TGP POWER SUPPLY ASSEMBLY (2349205)	408
MSUB/TGP POWER SUPPLY ASSEMBLY (2349205, sheet 1, rev 0)	408
MSUB/TGP POWER SUPPLY ASSEMBLY (2349205 BOM Rev.: 001)	409
3.15 HP60 GANTRY TGPU ASSY (5111425, -2, -3)	410
HP60 GANTRY TGPU ASSEMBLY (5111425, sheet 1, rev 1)	410
HP60 GANTRY TGPU ASSY (5111425 BOM Rev.: 001)	411
HP60 GANTRY TGPU ASSY ED2 (5111425-2, sheet 1, rev 3)	412
HP60 GANTRY TGPU ASSY ED2 (5111425-2, sheet 2, rev 2)	413
HP60 GANTRY TGPU ASSY ED2 (5111425-2 BOM Rev.: 008)	414
HP60 GANTRY TGPU ASSY ED2 (5111425-3, sheet 1, rev 2)	415
HP60 GANTRY TGPU ASSY ED2 (5111425-3, sheet 2, rev 1)	416
HP60 GANTRY TGPU ASSY ED2 (5111425-3 BOM Rev.: 001)	417
3.15.1 – HP60 GANTRY TGPU POWER SUPPLY ASSEMBLY (5111429, -2)	418
HP60 GANTRY TGPU POWER SUPPLY ASSEMBLY (5111429, sheet 1, rev 2)	418
HP60 GANTRY TGPU POWER SUPPLY ASM (5111429 BOM Rev.: 002)	419
HP60 GANTRY TGPU POWER SUPPLY ASM for mobile (5111429-2 BOM Rev.: 001)	419
3.16 SERVICE OUTLET/ESTOP ASSEMBLY (2349257)	420
SERVICE OUTLET/ESTOP ASSEMBLY (2349257, sheet 1, rev 2)	420
SERVICE OUTLET/ESTOP ASSEMBLY (2349257 BOM Rev.: 002)	421
3.17 POWER PAN ASSEMBLY 550V (2387385)	422
POWER PAN ASSEMBLY 550V (2387385, sheet 1, rev 1)	422
POWER PAN ASSEMBLY 550V (2387385, sheet 2, rev 1)	423
POWER PAN ASSEMBLY 550V (2387385 BOM Rev.: 006)	424
3.18 POWER PAN ASSEMBLY - 120V (2334726, -2)	426
POWER PAN ASSEMBLY - 120V (2334726, sheet 1, rev 2)	426
POWER PAN ASSEMBLY - 120V (2334726 BOM Rev.: 002)	427
POWER PAN ASM, 120V, EMC ED2 (2334726-2 BOM Rev.: 004)	427
3.19 ASSEMBLY, SERVICE SWITCH BOARD H-POWER (2358124)	430
ASSEMBLY, SERVICE SWITCH BOARD H-POWER (2358124, sheet 1, rev 1)	430
ASSEMBLY, SERVICE SWITCH BOARD H-POWER (2358124 BOM Rev.: 002)	431
3.20 HARNESS, GDAS, DETECTOR, ORP, Power Supply (2394982-3, -4, -5)	432
HARNESS, GDAS, DETECTOR, ORP, POWER SUPPLY (2394982, sheet 1, rev 6)	432
HARNESS, GDAS, DETECTOR, ORP, P/S (2394982-3 BOM Rev.: 002)	433
HARNESS, GDAS, DETECTOR, ORP, P/S (2394982-4 BOM Rev.: 005)	433

	GDAS-16 Main Harness, With ASTEC PS's (2394982-5, sheet 1, rev 3)	434
	GDAS-16 Main Harness With ASTEC PS's (2394982-5 BOM Rev.: 003)	435
Section 4.0 — Scan Win Assembly - H2 Gantry (5142849-4)		436
	SCAN WIN ASSEMBLY - H2 GANTRY (5142849, sheet 1, rev 3)	436
	ASSEMBLY, SCAN WINDOW (5142849-4 BOM Rev.: 003)	437
Section 5.0 — Cover Assembly, Front Gantry-H4 (2361872)		438
	COVER ASSEMBLY, FRONT GANTRY-H4 (2361872, sheet 1, rev 1)	438
	COVER ASSY, FRONT GANTRY-H4 (2361872 BOM Rev.: 009)	439
5.1 COVER SUB ASSY, GANTRY FRONT (2273017-5)		440
	COVER SUB ASSY, GANTRY FRONT (2273017, sheet 1, rev 7)	440
	COVER SUB ASSY, GANTRY FRONT (2273017, sheet 2, rev 6)	441
	COVER SUB ASSY, GANTRY FRONT (2273017-5 BOM Rev.: 002)	442
5.2 ESW ASSEMBLY (2194456-3)		444
	(2194456-3 BOM Rev.: 001)	444
5.3 MIC ASSEMBLY (2111955)		446
	MIC ASSEMBLY (2111955 BOM Rev.: 000)	446
5.4 PATIENT SENSOR, SMALL (2277405)		448
	PATIENT SENSOR, SMALL (2277405, sheet 1, rev 0)	448
	PATIENT SENSOR, SMALL (2277405 BOM Rev.: 002)	449
Section 6.0 — Cover Assembly, Rear Gantry-H4 (2361874)		450
	COVER ASSEMBLY, REAR GANTRY-H4 (2361874, sheet 1, rev 2)	450
	COVER ASSY, REAR GANTRY-H4 (2361874 BOM Rev.: 007)	451
6.1 COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873, -2)		452
	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873, sheet 1, rev 2)	452
	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873, sheet 2, rev 0)	453
	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873 BOM Rev.: 001)	454
	COVER SUB-ASSY, GANTRY-H4 (2361873-2 BOM Rev.: 002)	455
6.2 IND ASSEMBLY (2194474)		458
	IND ASSY (2194474 BOM Rev.: 025)	458
6.3 PATIENT SENSOR, LARGE (2277404)		460
	PATIENT SENSOR, LARGE (2277404, sheet 1, rev 1)	460
	PATIENT SENSOR, LARGE (2277404 BOM Rev.: 002)	461

Section 7.0 — Assembly, H-Power60 Top Cover (2378660, -3)	462
ASSEMBLY, H-POWER60 TOP COVER (2378660, sheet 1, rev 3)	462
ASSEMBLY, H-POWER60 TOP COVER (2378660, sheet 2, rev 2)	463
ASSEMBLY, H-POWER60 TOP COVER (2378660 BOM Rev.: 006)	464
ASSEMBLY, H-POWER60 TOP COVER (2378660-2 BOM Rev.: 002)	464
ASSY HPWR60 TOP COVER (2378660-3 BOM Rev.: 004)	465
Section 8.0 — Cover Assembly, Side Gantry Right H2 (2276690, -5)	467
COVER ASSEMBLY, SIDE GANTRY RIGHT H2 (2276690, sheet 1, rev 2)	467
COVER ASSEMBLY, SIDE GANTRY RIGHT H2 (2276690 BOM Rev.: 004)	468
COVER ASSY SIDE GANTRYRIGHT (2276690-5 BOM Rev.: 000)	468
Section 9.0 — Cover Asm, Side Gantry Left (2276691-5, -7)	469
Cover Assembly, Side Gantry Left, H-Power (2276691, sheet 1, rev 3)	469
COVER ASSY SIDE GANTRY LEFT (2276691-5 BOM, Rev 000)	470
COVER ASSEMBLY, SIDE GANTRY LEFT, H-POWER (2276691-7 BOM, Rev 000)	470
Section 10.0 — Helios 1.0 Tested Phantoms (2180544)	471
HELIOS 1.0 TESTED PHANTOMS (2180544 BOM Rev.: 001)	471
10.1 HELIOS IQ CAL 48 POLY Phantom (2144721-2)	472
HELIOS IQ CAL 48 POLY (2144721-2 BOM Rev.: 001)	472
10.1.1 – 48 Poly Phantom (2145287-2)	472
48 POLY PHANTOM (2145287-2 BOM Rev.: 000)	472
10.2 HELIOS IQ CAL 35 POLY Phantom (2144721)	472
HELIOS IQ CAL 35 POLY (2144721 BOM Rev.: 001)	472
10.2.1 – 35 Poly Phantom (2145287)	472
35 POLYPHANTOM (2145287 BOM Rev.: 000)	472
Section 11.0 — P2030GB DVD SAVESTATE (2385415)	473
P2030GB DVD SAVESTATE (2385415 BOM Rev.: 000)	473

Chapter 5

Miscellaneous Itemsf 475

Section 1.0 — HP60 Ship Collector (2385414, -2, -3, -4 / 5135131, -2)	476
HP60-16 SHIP COLLECTOR (2385414 BOM, rev 3)	476
HP60 4 and 8 slice Ship Collector (2385414-2 BOM, rev 4)	476

	HP60-16 Ship Collector - PF1.0 (2385414-3 BOM, rev 3)	477
	HP60 4, 8 Ship Collector - PF1.0 (2385414-4 BOM, rev 3)	477
	HP60-16 SHIP COLLECTOR, Without short cable collector - PF1.5 (5135131 BOM, rev 2)	478
	HP60 4 and 8 SLICE SHIP COLLECTOR, Without short cable collector - PF1.5 (5135131-2 BOM, rev 2)	478
1.1	Base Cover Collector (2290278-4)	479
	BASE COVER COLLECTOR (2290278-4 BOM, rev 0)	479
1.2	Fuse Kit HP60 90kVA (2385412)	479
	Fuse Kit HP60 90kVA (2385412 BOM, rev 2)	479
1.3	HP60 Field Balance Weight Kit (2381045-2)	480
	HP60 FIELD BALANCE WEIGHT KIT (2381045-2 BOM, rev 2)	480
1.4	P2030BD Ship C HP-100/60 Common (2385413)	481
	P2030BD Ship C HP-100/60 Common (2385413 BOM, rev 7)	481
1.5	DAS/Detector Service Kit (2227089-2)	483
	DAS/Detector Service Kit (2227089-2 BOM, rev 0)	483
	Section 2.0 — Cable Collectors	484
2.1	Short Cable Collector (2281840-5)	484
	Short Cable Collector (2281840-5 BOM, rev 0)	484
2.2	Long Cable Collector (2281840-4)	484
	Long Cable Collector (2281840-4 BOM, rev 0)	484
	Section 3.0 — Counter Weight Kit	485
3.1	HP60 Gantry 78Weight Upgrade Kit (5179280)	485
	Long Cable Collector (5179280 BOM, rev 1)	485

Chapter 1

Manual Conventions

Section 1.0 — Page Layout, Including Finger Tabs

Headers and footers in this publication are designed to allow you to quickly identify your location. The document's part number, revision number and title appear in the header on every page. All page footers display the current page number, at left (when viewed landscape). Odd numbered page footers include a reversed "finger tab" to help the user quickly flip through this manual. These tabs include chapter number and name, plus the name of the current major (level one) section heading. Where applicable, even page footers will show the current minor (level two) section number and name (e.g., 1.1 Side Panel Kit (2269167-2)) - otherwise, they repeat the current major (level one) section heading and name (e.g., Section 1.0 — Page Layout, Including Finger Tabs).

Section 2.0 — Manual Organization

This document is organized according to product structure. That is, the order in which the contents appear is based on the BOMs (Bills of Material) used herein. This means that the user may be required to “dig down” through the product structure in order to find the part they are looking for. [For pdf users, hyperlinks are provided for quick navigation downward (the “back” arrow may be used to move back up)].

WHAT IS A BOM?

A BOM is a Bill (list) Of Materials (parts) used to produce an item. The Parent Item is the thing that is made from the parts listed on the BOM. Because BOMs describe the materials required for a specific manufacturing process, they may not necessarily list every single item used to produce the parent item. The parts on a BOM themselves may be the result of a separate process, and thus have their own BOMs, listing the secondary items required to produce these primary parts.