

The Driver Module is currently responsible for all multicoil, head, and body TR bias switching in the system and for providing dynamic disable and direct drive system bias. It also provides bias for the head and multicoil preamps located inside the **Low Profile Carriage Assembly**. The switches along the top of the unit allow the various sense circuits and the high voltage output to be disabled during service. These should always be enabled during normal scanning. In normal operation the **CAN Core Communication** **HeaRTbeat** LED and the **Digital Control Board** **HeaRTbeat** LED repeatedly flash one opposite of the other. The **CCC STATUS** LED will repeatedly flash twice in quick succession if the Driver Module is able to communicate over the CAN link. If the CCC Board inside Driver Module faults then the **CCC ERROR** LED will illuminate. Be aware that the Driver Module provides 24VDC for the entire CAN link. The whole link would cease to function if this supply failed. The **MODULE ERROR** LED will illuminate if a fault that would normally not stop scanning, such as a power supply out of limit or fan status fault, occurs. Information for each of these faults is logged to the system error log as each occurs. The **DRIVER FAULT** LED will illuminate when a fault that would normally interrupt scanning, such as a TR driver fault, dynamic or direct drive disable fault, or other internal hardware failure, occurs. The **NarrowBand Unblank** LED (flashes during normal scanning), **BroadBand** LED, and **Continuous Wave** LED all provide visual indications of the unblank signal used for each. The **INHIBIT** LED illuminates when the unblank signal has been inhibited due to any kind of hardware fault. Note that **Test Points** 1-3 and a **Ground** access are provided for measurement of these unblank signals. **J21 CCC_DEBUG** and **J22 DCB_DEBUG** are standard RS-232 data ports. Field access to these is normally not necessary since existing Driver Module system diagnostics provide the same information in a more easy to read output format. During installation and anytime hardware is replaced in any of the TR, dynamic disable, or direct drive circuits the Driver Module must be calibrated. This is done using a software tool located on the CSD under Calibration called **TR/Dynamic Disable Calibration**. No special setup is required.

Available Driver Module Calibration:

- **TR/Dynamic Disable Calibration**

Available Driver Module

Diagnostics:

- **Power Supply Data**
- **I/O Status**
- **Xpt Switch Test**
- **MCD Volt Test**
- **MCD Channel Disable Test**
- **MCD Channel Enable Test**
- **Gather Load Data**

