



GE Healthcare

gehealthcare.com

Technical Publication

Direction 5117717-100
Revision 4

Book 1 of 2

Pages 1 - 86

LightSpeed 5.X Plus Illustrated Parts List



LEGAL NOTES

TRADEMARKS

Adobe, the Adobe logo, Acrobat, the Acrobat logo, Exchange, and PostScript are trademarks of Adobe Systems Incorporated or its subsidiaries and may be registered in certain jurisdictions.

Microsoft is a registered trademark and Windows is a trademark of Microsoft Corporation.

All other products and their name brands are trademarks of their respective holders.

COPYRIGHTS

All Material, Copyright © 2004-2005 by General Electric Company, Inc. All rights reserved.

IMPORTANT PRECAUTIONS

LANGUAGE

WARNING

- THIS SERVICE MANUAL IS AVAILABLE IN ENGLISH ONLY.
- IF A CUSTOMER'S SERVICE PROVIDER REQUIRES A LANGUAGE OTHER THAN ENGLISH, IT IS THE CUSTOMER'S RESPONSIBILITY TO PROVIDE TRANSLATION SERVICES.
- DO NOT ATTEMPT TO SERVICE THE EQUIPMENT UNLESS THIS SERVICE MANUAL HAS BEEN CONSULTED AND IS UNDERSTOOD.
- FAILURE TO HEED THIS WARNING MAY RESULT IN INJURY TO THE SERVICE PROVIDER, OPERATOR OR PATIENT FROM ELECTRIC SHOCK, MECHANICAL OR OTHER HAZARDS.

AVERTISSEMENT

- CE MANUEL DE MAINTENANCE N'EST DISPONIBLE QU'EN ANGLAIS.
- SI LE TECHNICIEN DU CLIENT A BESOIN DE CE MANUEL DANS UNE AUTRE LANGUE QUE L'ANGLAIS, C'EST AU CLIENT QU'IL INCOMBE DE LE FAIRE TRADUIRE.
- NE PAS TENTER D'INTERVENTION SUR LES ÉQUIPEMENTS TANT QUE LE MANUEL SERVICE N'A PAS ÉTÉ CONSULTÉ ET COMPRIS.
- LE NON-RESPECT DE CET AVERTISSEMENT PEUT ENTRAÎNER CHEZ LE TECHNICIEN, L'OPÉRATEUR OU LE PATIENT DES BLESSURES DUES À DES DANGERS ÉLECTRIQUES, MÉCANIQUES OU AUTRES.

WARNUNG

- DIESES KUNDENDIENST-HANDBUCH EXISTIERT NUR IN ENGLISCHER SPRACHE.
- FALLS EIN FREMDER KUNDENDIENST EINE ANDERE SPRACHE BENÖTIGT, IST ES AUFGABE DES KUNDEN FÜR EINE ENTSPRECHENDE ÜBERSETZUNG ZU SORGEN.
- VERSUCHEN SIE NICHT, DAS GERÄT ZU REPARIEREN, BEVOR DIESES KUNDENDIENST-HANDBUCH ZU RATE GEZOGEN UND VERSTANDEN WURDE.
- WIRD DIESE WARNUNG NICHT BEACHTET, SO KANN ES ZU VERLETZUNGEN DES KUNDENDIENSTTECHNIKERS, DES BEDIENERS ODER DES PATIENTEN DURCH ELEKTRISCHE SCHLÄGE, MECHANISCHE ODER SONSTIGE GEFAHREN KOMMEN.

LANGUAGE (CONTINUED)

AVISO

- ESTE MANUAL DE SERVICIO SÓ LO EXISTE EN INGLÉS.
- SI ALGÚN PROVEEDOR DE SERVICIOS AJENO A GEMS SOLICITA UN IDIOMA QUE NO SEA EL INGLÉS, ES RESPONSABILIDAD DEL CLIENTE OFRECER UN SERVICIO DE TRADUCCIÓN.
- NO SE DEBERÁ DAR SERVICIO TÉCNICO AL EQUIPO, SIN HABER CONSULTADO Y COMPRENDIDO ESTE MANUAL DE SERVICIO.
- LA NO OBSERVANCIA DEL PRESENTE AVISO PUEDE DAR LUGAR A QUE EL PROVEEDOR DE SERVICIOS, EL OPERADOR O EL PACIENTE SUFRAN LESIONES PROVOCADAS POR CAUSAS ELÉCTRICAS, MECÁNICAS O DE OTRA NATURALEZA.

ATENÇÃO

- ESTE MANUAL DE ASSISTÊNCIA TÉCNICA SÓ SE ENCONTRA DISPONÍVEL EM INGLÊS.
- SE QUALQUER OUTRO SERVIÇO DE ASSISTÊNCIA TÉCNICA, QUE NÃO A GEMS, SOLICITAR ESTES MANUAIS NOUTRO IDIOMA, É DA RESPONSABILIDADE DO CLIENTE FORNECER OS SERVIÇOS DE TRADUÇÃO.
- NÃO TENHA TENTADO REPARAR O EQUIPAMENTO SEM TER CONSULTADO E COMPREENDIDO ESTE MANUAL DE ASSISTÊNCIA TÉCNICA.
- O NÃO CUMPRIMENTO DESTES AVISOS PODE POR EM PERIGO A SEGURANÇA DO TÉCNICO, OPERADOR OU PACIENTE DEVIDO A CHOQUES ELÉTRICOS, MECÂNICOS OU OUTROS.

AVVERTENZA

- IL PRESENTE MANUALE DI MANUTENZIONE È DISPONIBILE SOLTANTO IN INGLESE.
- SE UN ADDETTO ALLA MANUTENZIONE ESTERNO ALLA GEMS RICHIEDE IL MANUALE IN UNA LINGUA DIVERSA, IL CLIENTE È TENUTO A PROVVEDERE DIRETTAMENTE ALLA TRADUZIONE.
- SI PROCEDA ALLA MANUTENZIONE DELL'APPARECCHIATURA SOLO DOPO AVER CONSULTATO IL PRESENTE MANUALE ED AVERNE COMPRESO IL CONTENUTO.
- NON TENERE CONTO DELLA PRESENTE AVVERTENZA POTREBBE FAR COMPIERE OPERAZIONI DA CUI DERIVINO LESIONI ALL'ADDETTO ALLA MANUTENZIONE, ALL'UTILIZZATORE ED AL PAZIENTE PER FOLGORAZIONE ELETTRICA, PER URTI MECCANICI OD ALTRI RISCHI.

LANGUAGE (CONTINUED)

警告

このサービスマニュアルには英語版しかありません。
GEMS以外でサービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。
このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないで下さい。
この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。

注意:

本维修手册仅存有英文本。
非 GEMS 公司的维修员要求非英文本的维修手册时，
客户需自行负责翻译。
未详细阅读和完全了解本手册之前，不得进行维修。
忽略本注意事项会对维修员，操作员或病人造成触电，机械伤害或其他伤害。

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent write "Damage In Shipment" on ALL copies of the freight or express bill BEFORE delivery is accepted or "signed for" by a GE representative or hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

Call the Service Center, People's Republic of China, (86) 800-810-8188 immediately after damage is found. At this time be ready to supply name of carrier, delivery date, consignee name, freight or express bill number, item damaged and extent of damage.

Complete instructions regarding claim procedure are found in Section S of the Policy And Procedures Bulletins.

14 July 1993

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Medical personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Medical Systems Group, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Medical Systems Group, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

LITHIUM BATTERY CAUTIONARY STATEMENTS



CAUTION Risk of Explosion

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



ATTENTION Danger d'Explosion

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GEMS CQA Process to report all omissions, errors, and defects in this publication.

Revision History

Revision	Date	Reason for change
1	08/24/04	Initial release document.
2	01/27/05	Updated TABLE, PDU, GANTRY and GRE CONSOLE.
3	06/28/05	Updated PDU (NGPDU).
4	10/14/05	Updated PDU (NGPDU); change the Programmed KV CTRL part number(See Page 158, 160)

Chapter 1

Manual Conventions	27
Section 1.0 — Page Layout, Including Finger Tabs	27
Section 2.0 — Manual Organization.....	28

Chapter 2

Table	29
Cat Coll/H Power Table with Footswitch (2373155 BOM, rev 0).....	29
Section 1.0 — Table Assembly - H Power (2335179).....	30
Table Assembly - H Power (2335179, sheet 1, rev 2).....	30
Table Assembly - H Power (2335179, sheet 2, rev 2).....	31
Table Assembly - H Power (2335179 BOM, rev 7)	32
1.1 Side Panel Kit (2269167-2).....	35
Side Panel Kit for H2 LCC Cathay Table (2269167-2 BOM, rev 0).....	35
1.2 Cover Table Top - Left (2372371)	36
Cover Table Top - Left (2372371, sheet 1, rev 1)	36
Cover Table Top - Left (2372371 BOM, rev 01).....	37
1.3 Cover Table Top - Right (2372372)	38
Cover Table Top - Right (2372372, sheet 1, rev 1).....	38
Cover Table Top - Right (2372372 BOM, rev 1)	39
1.4 Metalless Cradle (2115992-5)	40
Metalless Cradle (2115992, sheet 1, rev 7)	40
Metalless Cradle (2115992-3 BOM, rev 1).....	41
1.5 Table Subassembly - H Power (2335178).....	42
Table Subassembly (2335178, sheet 1, rev 5).....	42
Table Subassembly (2335178, sheet 2, rev 2).....	43
Table Subassembly (2335178, sheet 3, rev 2).....	44
Table Subassembly (2335178, sheet 4, rev 1).....	45
Table Subassembly (2335178 BOM, rev 8)	46
1.5.1 – Carriage Assembly (2269168-2)	50
Carriage Assembly (2269168-2, sheet 2, rev1).....	50
Carriage Assembly (2269168-2 BOM, rev 1)	51

1.5.2 – Latch Assembly (2269177)	52
Latch Assembly (2269177, sheet 1, rev 0)	52
Latch Assembly (2269177 BOM, rev 0)	53
1.5.3 – Cradle Drive Assembly (2339120)	54
Cradle Drive Assembly (2339120, sheet 1, rev 2)	54
Cradle Drive Assembly (2339120, sheet 2, rev 1)	55
Cradle Drive Assembly (2339120, sheet 3, rev 0)	56
Cradle Drive Assembly (2339120 BOM, rev 5)	57
1.5.4 – Encoder Assembly, Elevation - H Power (2337217)	60
Encoder Assembly, Elevation - H Power (2337217, sheet 1, rev 2)	60
Encoder Assembly, Elevation - H Power (2337217 BOM, rev 2)	61
1.5.5 – Table Frame Assembly (2335177)	62
Table Frame Assembly (2335177, sheet 1, rev 2)	62
Table Frame Assembly (2335177, sheet 2, rev 0)	63
Table Frame Assembly (2335177, sheet 3, rev 2)	64
Table Frame Assembly (2335177, sheet 4, rev 0)	65
Table Frame Assembly (2335177, sheet 5, rev 0)	66
Table Frame Assembly (2335177 BOM, rev 3)	67
Section 2.0 — Foot Switch Assembly (2330508)	71
Foot Switch Assembly (2330508, sheet 1, rev 2)	71
Footswitch Assembly (2330508 BOM, rev 6)	72

Chapter 3

PDU	73
H Power PDU (B78742AB BOM, rev 0)	73
NGPDU-3 (B79932 BOM, rev 0)	73
Section 1.0 — NGPDU	74
NGPDU	74
1.1 NGPDU Assembly	76
NGPDU ASSEMBLY1 (2348074, sheet 1, rev 0)	76
NGPDU ASSEMBLY1 (2348074, sheet 2, rev 1)	77
NGPDU ASSEMBLY1 (2348074, sheet 3, rev 0)	78
NGPDU ASSEMBLY3 (2380116, sheet 1, rev 0)	79

NGPDU ASSEMBLY3 (2380116, sheet 2, rev0).....	80
NGPDU ASSEMBLY3 (2380116, sheet 3, rev 0).....	81
NGPDU Assembly	82

Chapter 4

Gantry (LS 5.X Plus)..... 95

Gantry-2383550-20BOM Tree.....	96
Value 4 GANTRY With PHANTOMS (2383550-20BOM Rev.: 003).....	97
GANTRY ASM (5111738 refer to 2378661, sheet 2, rev 5)	98
LIGHTSPEED 5.0J GANTRY ASM (5111738 BOM Rev.: 002)	99

Section 1.0 — Value 4 Vertical Assembly (5111739) 100

Value 4 GANTRY VERTICAL ASSEMBLY (5111739 refer to 2378662, sheet 1, rev 1).....	100
Value 4 GANTRY VERTICAL ASSEMBLY (5111739 refer to 2378662, sheet 2, rev 0).....	101
Value 4 GANTRY VERTICAL ASSEMBLY (5111739 refer to 2378662, sheet 3, rev 2).....	102
Value 4 GANTRY VERTICAL ASSEMBLY (5111739 refer to 2378662, sheet 4, rev 1).....	103
Value 4 GANTRY VERTICAL ASSEMBLY (5111739 refer to 2378662, sheet 5, rev 1).....	104
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 1, rev 5).....	105
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 2, rev 1).....	106
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 3, rev 1).....	107
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 4, rev 4).....	108
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 5, rev 2).....	109
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 7, rev 1).....	110
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 8, rev 1).....	111
Value 4 GANTRY VERTICAL ASSEMBLY (2378662 refer to 2357738 sheet 9, rev 1).....	112
Value 4 GANTRY VERTICAL ASSEMBLY (5111739 refer to 2374680 sheet 6, rev 0).....	113
Value 4 GANTRY VERTICAL ASM (5111739 BOM Rev.: 006).....	114

1.1 Valule 4 HORIZONTAL Assembly (5111740)..... 122

Value 4 HORIZONTAL ASSEMBLY (5111740 Refer to 2378663, sheet 1, rev 4).....	122
Value 4 HORIZONTAL ASSEMBLY (5111740 Refer to 2378663, sheet 2, rev 3).....	123
Value 4 HORIZONTAL ASSEMBLY (5111740 sheet 2, rev 2)	124
Value 4 HORIZONTAL ASM (5111740 BOM Rev.: 007)	125

1.1.1 – H-POWER GANTRY HIGH LEVEL BUY (2357736-2) 130

H-POWER GANTRY HIGH LEVEL BUY (2357736-2, sheet 1, rev 2)	130
H-POWER GANTRY HIGH LEVEL BUY (2357736-2, sheet 2, rev 2)	131

H-POWER GANTRY HIGH LEVEL BUY (2357736-2 BOM Rev.: 002)	132
1.1.1.1 – HYDRAULIC TILT MOTOR ASSY (2334727)	134
HYDRAULIC TILT MOTOR ASSY (2334727, sheet 1, rev 1)	134
HYDRAULIC TILT MOTOR ASSY (2334727, sheet 2, rev 0)	135
HYDRAULIC TILT MOTOR ASSY (2334727, sheet 3, rev 0)	136
HYDRAULIC TILT MOTOR ASSY (2334727 BOM Rev.: 001)	137
1.1.2 – PERFORMIX ULTRA TUBE UNIT (D3186T).....	138
PERFORMIX ULTRA TUBE UNIT (D3186T BOM Rev.: 001).....	138
1.1.2.1 – PERFORMIX LIGHTSPEED RED RELOADED TUBE UNIT AND GANTRY MOUNTING BRACKET ASSEMBLY (5111363-4)	139
PERFORMIX LIGHTSPEED RED RELOADED TUBE UNIT & GANTRY MOUNTING BRACKET ASM (5111363, sheet 1, rev 4)	139
PERFORMIX LIGHTSPEED RED RELOADED TUBE UNIT & GANTRY MOUNTING BRACKET ASM (5111363-4 BOM Rev.: 003).....	140
1.1.3 – HELIOS 4 COLLIMATOR ASSEMBLY (2214768-4).....	142
HELIOS 4 COLLIMATOR ASSEMBLY (2214768-4, sheet 4, rev 5)	142
HELIOS 4 COLLIMATOR ASSEMBLY (2214768-4 BOM Rev.: 000)	143
1.1.3.1 – HELIOS 4 COLLIMATOR (2120100-4)	144
HELIOS 4 COLLIMATOR (2120100-4, sheet 7, rev 9)	144
HELIOS 4 COLLIMATOR (2120100-4, sheet 8, rev 8)	145
HELIOS 4 COLLIMATOR (2120100-4 BOM Rev.: 000).....	146
H4 COLLIMATOR BASE ASSEMBLY (2273645-3)	148
H4 COLLIMATOR BASE ASSEMBLY (2273645-3, sheet 1, rev 2)	148
H4 COLLIMATOR BASE ASSEMBLY (2273645-3 BOM Rev.: 001)	149
1.1.4 – JEDI 60 DC GENERATOR (2371333-2).....	152
JEDI 60 DC GENERATOR (2371333-2, sheet 1, rev1)	152
JEDI 60 DC GENERATOR (2371333-2 BOM Rev.: 002).....	153
1.1.4.1 – JEDI 60DC HLB POWER UNIT (2377668-2).....	154
JEDI 60DC HLB POWER UNIT (2377668-2, sheet 1, rev 1)	154
JEDI 60DC HLB POWER UNIT (2377668-2 BOM Rev.: 001)	155
POWER UNIT JEDI 60 DC (2241515-3)	156
POWER UNIT JEDI 60 DC (2241515-3, sheet 1, rev 1)	156
POWER UNIT JEDI 60 DC (2241515-3, sheet 2, rev 1)	157
POWER UNIT JEDI 60 DC (2241515-3 BOM Rev.: 001)	158

EQUIPED INVERTER JEDI 60 DC (2242441-3, sheet 1, rev 1).....	159
EQUIPED INVERTER JEDI 60 DC (2242441-3 BOM Rev.: 001).....	160
PROGRAMMED KV CTRL (2407577 BOM Rev.: 000).....	160
PPC KV CTRL V2B (2340155-5 BOM Rev.: 001).....	160
<i>PI FILTER ASSEMBLY (2375375).....</i>	<i>162</i>
PI FILTER ASSEMBLY (2375375, sheet 1, rev 3).....	162
PI FILTER ASSEMBLY (2375375, sheet 2, rev 3).....	163
PI FILTER ASM 2375375 BOM Rev.: 003).....	164
<i>1.1.4.2 – JEDI STD HV TANK (2186730).....</i>	<i>165</i>
JEDI STD HV TANK (2186730, sheet 1, rev 2).....	165
JEDI STD HV TANK (2186730 BOM Rev.: 008).....	166
<i>1.1.4.3 – HEMIT TANK JEDI 60 DC (2237336-2).....</i>	<i>167</i>
HEMIT TANK JEDI 60 DC (2237336-2, sheet 1, rev 1).....	167
HEMIT TANK JEDI 60 DC (2237336-2 BOM Rev.: 002).....	168
<i>1.1.4.4 – JH4 AUXILIARY EQUIPED V2 (2324118).....</i>	<i>169</i>
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 1, rev 6).....	169
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 2, rev 6).....	170
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 3, rev 6).....	171
JH4 AUXILIARY EQUIPED V2 (2324118, sheet 4, rev 6).....	172
JH4 AUXILIARY EQUIPED V2 (2324118 BOM Rev.: 010).....	173
<i>1.1.4.5 – JEDI 60DC INTER-MODULE CABLE SET (2377667).....</i>	<i>175</i>
JEDI 60DC INTER-MODULE CABLE SET (2377667 BOM Rev.: 002).....	175
1.1.5 – PWR SPLY ASM, E & F - CASE (LH) (2285907).....	176
PWR SPLY ASM, E & F - CASE (2285907, rev 0).....	176
PWR SPLY ASM, E & F - CASE (2285907 BOM REV.: 000).....	177
1.1.6 – LS CHINA FUSE BOX (5116701).....	178
LS CHINA FUSE BOX (5116701, sheet 1, rev 1).....	178
LS CHINA FUSE BOX (5116701 BOM Rev.: 002).....	179
<i>1.1.6.1 – DHCB / FUSE BOX ASM (2381086).....</i>	<i>180</i>
DHCB/FUSE BOX ASM (2381086, sheet 1, rev 0).....	180
LS CHINA FUSE BOX (2381086, sheet 2, rev 0).....	181
LS CHINA FUSE BOX (2381086 BOM Rev.: 003).....	182
<i>HARNESS, FUSEBX/ORP/DAS/INV/FO/DHCB (2381570).....</i>	<i>184</i>
HARNESS, FUSEBX/ORP/DAS/INV/FO/DHCB (2381570, rev 1).....	184
HARNESS, FUSEBX/ORP/DAS/INV/FO/DHCB (2381570 BOM Rev.: 001).....	185

1.1.7 – DAS POWER SUPPLY RIGHT SIDE (2225209)	186
DAS POWER SUPPLY RIGHT SIDE (2225209, sheet 1, rev 2)	186
DAS POWER SUPPLY RIGHT SIDE (2225209 BOM Rev.: 002)	187
1.1.8 – HOME FLAG (2227383-2)	188
HOME FLAG (2227383, rev 2)	188
HOME FLAG (2227383-2 BOM Rev.: 000)	189
1.2 ASSEMBLY, S/R 120V PWR & INTERCOM BD (2357521)	190
ASSEMBLY, S/R 120V PWR & INTERCOM BD (2357521, sheet 1, rev 1)	190
ASSEMBLY, S/R 120V PWR & INTERCOM BD (2357521 BOM Rev.: 002)	191
1.3 DETECTOR PLATE ASSEMBLY (5111741)	192
DETECTOR PLATE ASSEMBLY (5111741 refer to 2286241 sheet 1, rev 7)	192
DETECTOR PLATE ASSEMBLY (5111741 refer to 2286241 sheet 2, rev 6)	193
DETECTOR PLATE ASSEMBLY (5111741 BOM Rev.: 001)	194
1.3.1 – MDAS ASSEMBLY (2272768-3)	196
MDAS ASM - H3 (4 SLICE) (2272768ADW Sheet 1, rev 5)	196
MDAS ASM - H3 (4 SLICE) (2272768-3 BOM Rev: 002)	197
1.3.1.1 – CHASSIS Left Assembly (2289343)	198
Chassis Left Assembly (2289343ADW sheet 1, rev 0)	198
MDAS BACKPLANE/CHASSIS, LT. ASM (2289343 BOM Rev: 002)	199
1.3.1.2 – CHASSIS Center Assembly (2289548)	200
Chassis Center Assembly (2289548ADW, sheet 1, rev 0)	200
MDAS BACKPLANE/CHASSIS, CTR ASM (2289548 BOM Rev: 002)	201
1.3.1.3 – MDAS Backplane/chassis, Right Assembly (2289460)	202
Chassis Right Assembly (2289460ADW sheet 1, rev 0)	202
MDAS BACKPLANE/CHASSIS, RT. ASM (2289460 BOM Rev: 002)	203
1.3.2 – Detector Assembly (2280784)	204
Detector Assembly (2280784ADW, sheet 1, rev 3)	204
Detector Assembly (2280784ADW, sheet 2, rev 3)	205
WARP3-DCS DET., SIGNLE ZONE HEATER (2280784 BOM Rev: 008)	206
1.3.3 – MDAS Duct/Fan Assembly (2277359)	208
MDAS Duct/Fan Assembly (2277359ADW, sheet 1, rev 0)	208
MDAS DUCT/FAN ASSEMBLY-H3(2277359 BOM Rev: 002)	209

1.3.4 – Power Supply ASM, +5VDC (2285697).....	210
Power Supply Asm, +5VDC D-Case (RH) (2285697 sheet 1, rev 0)	210
Power Supply Asm, +5VDC D-Case (RH) (2285697 BOM, rev 0)	211
1.4 H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524).....	212
H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524, sheet 1, rev 1).....	212
H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524, sheet 2, rev 1).....	213
H-POWER AXIAL DYNAMIC BRAKE MODULE (2357524 BOM Rev.: 004).....	214
1.4.1 – Step Up Transformer (2354743)	216
Step Up Transformer with 97,75mm (2354743 BOM, rev 1).....	216
1.5 DRIVE ASSEMBLY, H-POWER AXIAL (2217930-2)	218
DRIVE ASSEMBLY, H-POWER AXIAL (2217930-2, sheet 1, rev 6)	218
DRIVE ASSEMBLY, H-POWER AXIAL (2217930-2, sheet 3, rev 5)	219
DRIVE ASSEMBLY, H-POWER AXIAL (2217930-2 BOM Rev.: 001)	220
1.5.1 – AXIAL MOTOR W/ SPROCKET, H-POWER (2235342-3).....	222
AXIAL MOTOR W/ SPROCKET, H-POWER (2235342-3, sheet 1, rev 0).....	222
AXIAL MOTOR W/ SPROCKET, H-POWER (2235342-3 BOM Rev.: 000)	223
1.5.2 – BRAKE ASSEMBLY, H2 AXIAL DRIVE MOTOR (2277225).....	224
BRAKE ASSEMBLY, H2 AXIAL DRIVE MOTOR (2277225, rev 0)	224
BRAKE ASSEMBLY, H2 AXIAL DRIVE MOTOR (2277225 BOM Rev.: 000).....	225
1.5.3 – AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402)	226
AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402, sheet 1, rev 2).....	226
AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402, sheet 2, rev 2).....	227
AXIAL DRIVE MOTOR CONTROLLER W/CORERS ASSEMBLY (2233402 BOM Rev.: 003)	228
1.6 Encoder Assembly Hub-Mounted Wheel (2369747).....	230
Encoder Assembly, Hub-Mounted Wheel (2369747 sheet 1, rev 0)	230
Encoder Assembly, Hub-Mounted Wheel (2369747 BOM, rev 0).....	231
1.7 BRACE, GANTRY COVER UPPER (2273029).....	232
BRACE, GANTRY COVER UPPER (2273029, sheet 1, rev 3).....	232
BRACE, GANTRY COVER UPPER (2273029 BOM Rev.: 004).....	233
1.8 BRACE, GANTRY COVER LOWER (2368302).....	234
BRACE, GANTRY COVER LOWER (2368302, rev 0).....	234
BRACE, GANTRY COVER LOWER (2368302 BOM Rev.: 000)	235
1.9 ORP ASSEMBLY (2358141-2)	236
ORP ASSEMBLY (2358141, rev 2).....	236

	ORP ASSEMBLY (2358141-2 BOM Rev.: 002)	237
1.10	Slipring Assembly (5114668).....	238
	Slipring Assembly (5114668 refer to 2349589, sheet 1, rev 0)	238
	Slipring Assembly (5114668 BOM, rev 1)	239
	1.10.1 – Hpower-400MB Slipring Assembly (2364819).....	240
	Hpower-400MB Slipring Assembly (2364819 sheet 1, rev 0).....	240
	Hpower-400MB Slipring Assembly (2364819 BOM, rev 0)	241
	<i>1.10.1.1 – Hpower-400 Receiver-Antenna (2333609-2)</i>	<i>242</i>
	Receiver-Antenna (2333609, sheet 1, rev 0)	242
	Hpower-400 Receiver-antenna Assembly (2333609-2 BOM, rev 0)	243
	<i>1.10.1.2 – Brushblock Assembly For H-power (2349598).....</i>	<i>244</i>
	Brushblock Asm For H-power w/tips (2349598 sheet 1, rev 0)	244
	Brushblock Asm For H-power w/tips (2349598 BOM, rev 0).....	245
	<i>Power Brush Tip Collector for H-pwr (2349603)</i>	<i>245</i>
	Power Brush Tip Collector for H-pwr (2349603 BOM, rev 0)	245
	<i>Signal Brush Tip Collector for H-pwr (2349604).....</i>	<i>245</i>
	Signal Brush Tip Collector for H-pwr (2349604 BOM, rev 0).....	245
	<i>1.10.1.3 – Slipring Assembly For Hpower (2349587-2)</i>	<i>246</i>
	Slipring Assembly For H-power (2349587, sheet 1, rev 0).....	246
	Slipring Assembly for Hpower-400 (2349587-2 BOM, rev 0)	247
1.11	Slipring Cover Collector (2369443).....	248
	Slipring Cover Collector (2369443 BOM, rev 0)	248
1.12	TILT, FEEDBACK ASSEMBLY (2356863).....	250
	TILT, FEEDBACK ASSEMBLY (2356863, sheet 1, rev 0)	250
	TILT, FEEDBACK ASSEMBLY (2356863 BOM Rev.: 001)	251
1.13	TGPU ASSEMBLY (5111425)	252
	TGPU ASSEMBLY (5111425, sheet 1, rev 1).....	252
	TGPU ASSEMBLY (5111425 BOM Rev.: 001)	253
	1.13.1 – TGPU POWER SUPPLY ASSEMBLY (5111429)	254
	TGPU POWER SUPPLY ASSEMBLY (5111429, rev 1).....	254
	TGPU POWER SUPPLY ASSEMBLY (5111429 BOM Rev.: 001)	255
1.14	SERVICE OUTLET/ESTOP ASSEMBLY (2349257).....	256
	SERVICE OUTLET/ESTOP ASSEMBLY (2349257, sheet 1, rev 1).....	256

	SERVICE OUTLET/ESTOP ASSEMBLY (2349257 BOM Rev.: 001)	257
1.15	POWER PAN ASSEMBLY 550V (2387385)	258
	POWER PAN ASSEMBLY 550V (2387385, sheet 1, rev 0)	258
	POWER PAN ASSEMBLY 550V (2387385, sheet 2, rev 0)	259
	POWER PAN ASSEMBLY 550V (2387385 BOM Rev.: 005)	260
1.16	POWER PAN ASSEMBLY - 120V (2334726)	262
	POWER PAN ASSEMBLY - 120V (2334726, sheet 1, rev 1)	262
	POWER PAN ASSEMBLY - 120V (2334726 BOM Rev.: 001)	263
1.17	ASSEMBLY, SERVICE SWITCH BOARD H-POWER (2358124)	264
	ASSEMBLY, SERVICE SWITCH BOARD H-POWER (2358124, sheet 1, rev 1)	264
	ASSEMBLY, SERVICE SWITCH BOARD H-POWER (2358124 BOM Rev.: 002)	265
Section 2.0	— Scan Win Assembly - H2 Gantry (2101967-4)	266
	SCAN WIN ASSEMBLY - H2 GANTRY (2101967-4, sheet 1, rev 5)	266
	SCAN WIN ASSEMBLY - H2 GANTRY (2101967-4 BOM Rev.: 000)	267
Section 3.0	— Cover Assembly, Front Gantry-H4 (2361872)	268
	COVER ASSEMBLY, FRONT GANTRY-H4 (2361872, sheet 1, rev 0)	268
	COVER ASSY, FRONT GANTRY-H4 (2361872 BOM Rev.: 004)	269
3.1	COVER SUB-ASSEMBLY, FRONT GANTRY-H4 (2361871)	270
	COVER SUB-ASSEMBLY, FRONT GANTRY-H4 (2361871, sheet 1, rev 1)	270
	COVER SUB-ASSEMBLY, FRONT GANTRY-H4 (2361871, sheet 2, rev 1)	271
	COVER SUB-ASSEMBLY, FRONT GANTRY-H4 (2361871 BOM Rev.: 002)	272
3.2	ESW ASSEMBLY (2194456-3)	274
	ESW ASSY (2194456-3 BOM Rev.: 000)	274
3.3	MIC ASSEMBLY (2111955)	275
	MIC ASSEMBLY (2111955 BOM Rev.: 000)	275
3.4	PATIENT SENSOR, SMALL (2277405)	276
	PATIENT SENSOR, SMALL (2277405, sheet 1, rev 0)	276
	PATIENT SENSOR, SMALL (2277405 BOM Rev.: 000)	277
Section 4.0	— Cover Assembly, Rear Gantry-H4 (2361874)	278
	COVER ASSEMBLY, REAR GANTRY-H4 (2361874, sheet 1, rev 1)	278
	COVER ASSY, REAR GANTRY-H4 (2361874 BOM Rev.: 003)	279

4.1	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873)	280
	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873, sheet 1, rev 1).....	280
	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873, sheet 2, rev 0).....	281
	COVER SUB-ASSEMBLY, REAR GANTRY-H4 (2361873 BOM Rev.: 001).....	282
4.2	IND ASSEMBLY (2194474)	284
	IND ASSY (2194474 BOM Rev.: 024).....	284
4.3	PATIENT SENSOR, LARGE (2277404)	286
	PATIENT SENSOR, LARGE (2277404, sheet 1, rev 0).....	286
	PATIENT SENSOR, LARGE (2277404 BOM Rev.: 000).....	287
	Section 5.0 — Assembly, H-Power60 Top Cover (2378660-3)	288
	ASSEMBLY, H-POWER60 TOP COVER (2378660, sheet 1, rev 2)	288
	ASSEMBLY, H-POWER60 TOP COVER (2378660-3 BOM Rev.: 003)	289
	Section 6.0 — Cover Assembly, Side Gantry Right H2 (2276690-5)	290
	COVER ASSEMBLY, SIDE GANTRY RIGHT H2 (2276690-5, sheet 1, rev 0).....	290
	COVER ASSEMBLY, SIDE GANTRY RIGHT H2 (2276690-5 BOM Rev.: 000).....	291
	Section 7.0 — Cover Asm, Side Gantry Left (2276691-5)	292
	Cover Assembly, Side Gantry Left, H-Power (2276691-5, sheet 1, rev 3).....	292
	COVER ASSEMBLY, SIDE GANTRY LEFT, H-POWER (2276691-5 BOM, Rev 00).....	293
	HELIOS 1.0 TESTED PHANTOMS (2180544 BOM Rev.: 000).....	294

Chapter 5

GRE Console **295**

Section 1.0 — GRE Console (2378862-10)	296
GRE Console (2378862, sheet 1, rev 06))	296
GRE Console (2378862, sheet 2, rev 06)	297
GRE Console (2378862, sheet 3, rev 06)	298
GRE 16-Slice MDAS (2378862-10 BOM, rev 3)	299
Section 2.0 — Console Chassis Assembly (2385739)	301
Console Chassis Assembly (2385739 sheet 1, rev 0).....	301
Console Chassis Assembly (2385739 sheet 2, rev 0).....	302
Console Chassis Assembly (2385739 BOM, rev 5)	303

2.1	Assembly - Outlet Box (2174159-3)	304
	Assembly - Outlet Box (2174159-3, sheet 1, rev 3)	304
	Outlet Box Assembly (2174159-3 BOM, rev 4)	305
	Section 3.0 — SCSI Tower Assy (5116391-2)	306
	SCSI Tower, DVD-RAM, MOD (5116391, sheet 1, rev 1)	306
	SCSI Tower Assy (5116391-2 BOM, rev 1)	307
	Section 4.0 — Associated Items	308
4.1	Color CRT Monitor - 22 inch (B71712CA)	309
	Console Display Monitors (B71712CA BOM, rev 0)	309
4.2	LCD Monitor - 19 inch (B71292CA)	309
	LCD Monitor (B71292CA BOM, rev 1)	309
4.3	Keyboard w/SCIM, Collectors	310
	Keyboard & SCIM Assembly (Rev 11/15/00)	310
	4.3.1 – Keyboard w/SCIM Collector - English (2275758)	311
	Keyboard w/SCIM Collector - English (2275758 BOM, rev 1)	311
	<i>4.3.1.1 – SCIM Collector – English (2275752)</i>	<i>311</i>
	SCIM Collector - English (2275752 BOM, rev 0)	311
	4.3.2 – French (2275758-2)	312
	Keyboard w/SCIM Collector - French (2275758-2 BOM, rev 1)	312
	<i>4.3.2.1 – SCIM Collector - French (2275752-2)</i>	<i>312</i>
	SCIM Collector - French (2275752-2 BOM, rev 0)	312
	4.3.3 – German (2275758-3)	313
	Keyboard w/SCIM Collector - German (2275758-3 BOM, rev 1)	313
	<i>4.3.3.1 – SCIM Collector - German (2275752-3)</i>	<i>313</i>
	SCIM Collector - German (2275752-3 BOM, rev 0)	313
	4.3.4 – Swedish (2275758-4)	313
	Keyboard w/SCIM Collector - Swedish (2275758-4 BOM, rev 1)	313
	4.3.5 – International (2275758-5)	314
	Keyboard w/SCIM Collector - International (2275758-5 BOM, rev 1)	314
	<i>4.3.5.1 – SCIM Collector - International (2275752-4)</i>	<i>314</i>
	SCIM Collector - International (2275752-4 BOM, rev 0)	314

4.4	GRE Console, Hardware Kit (2379133)	315
	GRE Console, Hardware Kit (2379133 BOM, rev 0)	315
4.5	GRE Console Cable Kit (2384112)	317
	GRE Console Cable Kit (2384112 BOM, rev 0)	317
4.6	GRE Console, SCSI Cable Kit (2379129)	317
	GRE Console, SCSI Cable Kit (2379129 BOM, rev 0)	317
4.7	GRE Console, Ethernet (2379130)	317
	GRE Console, Ethernet (2379130 BOM, rev 0)	317
4.8	GRE Console, Video/Power Cables (2379131)	318
	GRE Console, Video/Power Cables (2379131 BOM, rev 0)	318
4.9	Console Slide Service Kit (2379135)	318
	Console Slide Service Kit (2379135 BOM, rev 0)	318
4.10	Power Switch & Cables (2379134)	318
	Power Switch & Cables (2379134 BOM, rev 0)	318
4.11	GRE Console, Electrical Component (2379132)	319
	GRE Console, Electrical Component (2379132 BOM, rev 0).....	319
4.12	GRE Modem Kit (B7700MG)	319
	GRE Modem Kit (B7700MG BOM, rev 0).....	319
Section 5.0 — Options		320
5.1	Video Upgrade For Linux Console (B7868MC)	320
	Video Upgrade For Linux Console (B7868MC BOM, rev 0).....	320
	5.1.1 – Video Upgrade (2378278)	320
	Video Upgrade (2378278 BOM, rev 0)	320
5.2	LCD & SUSP (Boom In Room) LNX (B7710LM)	321
	LCD & SUSP (Boom In Room) LNX (B7710LM BOM, rev 0).....	321
	5.2.1 – Boom-in-a-Room for Linux (2376773)	321
	Boom-in-a-Room for Linux (2376773 BOM, rev 0).....	321
5.3	HS/LS Remote Color (LNX) Monitor (B7530LC)	322
	HS/LS Remote Color (LNX) Monitor (B7530LC BOM, rev 0).....	322
	5.3.1 – Remote Monitor Kit (2377146)	322
	Remote Monitor Kit (2377146 BOM, rev 0)	322

Chapter 6

Miscellaneous Items	323
Section 1.0 — Pro16 Ship Collector (Non-Mobile) (2373160)	324
Pro16 Ship Collector (Non-Mobile) (2373160 BOM, rev 4)	324
1.1 Base Cover Collector H4 (2366670)	324
Base Cover Collector H4 (2366670 BOM, rev 0)	324
1.2 H-Power Fuse Kit (2218570-2)	325
H-Power Fuse Kit (2218570-2 BOM, rev 1)	325
1.3 Balance Kit, Field, H-Power (2376682)	326
Balance Kit, Field, H-Power (2376682 BOM, rev 0)	326
1.4 P2030BD Ship C HP-100/60 Common (2385413)	327
P2030BD Ship C HP-100/60 Common (2385413 BOM, rev 1)	327
Section 2.0 — LightSpeed RT Ship Collector (2394003)	329
LightSpeed RT Ship Collector (2394003 BOM, rev 0)	329
2.1 Collector-Base Cover-SG (2381848)	330
Collector-Base Cover-SG (2381848 BOM, rev 1)	330
2.2 Installation Support Kit, Stargate (2319891-4)	331
Installation Support Kit, Stargate (2319891-4 BOM, rev 0)	331
Section 3.0 — Cable Collectors	334
3.1 Short Cable Collector (2281840-5)	334
Short Cable Collector (2281840-5 BOM, rev 0)	334
3.2 Long Cable Collector (2281840-4)	334
Long Cable Collector (2281840-4 BOM, rev 0)	334

Chapter 1

Manual Conventions

Section 1.0 — Page Layout, Including Finger Tabs

Headers and footers in this publication are designed to allow you to quickly identify your location. The document's part number, revision number and title appear in the header on every page. All page footers display the current page number, at left (when viewed landscape). Odd numbered page footers include a reversed "finger tab" to help the user quickly flip through this manual. These tabs include chapter number and name, plus the name of the current major (level one) section heading. Where applicable, even page footers will show the current minor (level two) section number and name (e.g., 1.1 Side Panel Kit (2269167-2)) - otherwise, they repeat the current major (level one) section heading and name (e.g., Section 1.0 — Page Layout, Including Finger Tabs).

Section 2.0 — Manual Organization

This document is organized according to product structure. That is, the order in which the contents appear is based on the BOMs (Bills of Material) used herein. This means that the user may be required to “dig down” through the product structure in order to find the part they are looking for. [For pdf users, hyperlinks are provided for quick navigation downward (the “back” arrow may be used to move back up)].

WHAT IS A BOM?

A BOM is a Bill (list) Of Materials (parts) used to produce an item. The Parent Item is the thing that is made from the parts listed on the BOM. Because BOMs describe the materials required for a specific manufacturing process, they may not necessarily list every single item used to produce the parent item. The parts on a BOM themselves may be the result of a separate process, and thus have their own BOMs, listing the secondary items required to produce these primary parts.