



GE Medical Systems

gehealthcare.com

Technical Publication

Direction 5159067-100

Revision 1

GE Medical Systems Non-Fixed CT LightSpeed HP60 Electrical Integration Procedure

Retain this installation manual permanently with your CT System. Any other revisions of this installation manual may not exactly match your system.

*Copyright © 2005 by General Electric Company
All rights reserved.*



LEGAL NOTES

TRADEMARKS

Adobe, the Adobe logo, Acrobat, the Acrobat logo, Exchange, and PostScript are trademarks of Adobe Systems Incorporated or its subsidiaries and may be registered in certain jurisdictions.

Microsoft is a registered trademark and Windows is a trademark of Microsoft Corporation.

Sears Industrial Sales is an operation of Sears Commercial Sales. Sears is a trademark of the Sears, Roebuck and Co.

Snap-on is a registered trademark of Snap-on Incorporated.

All other products and their name brands are trademarks of their respective holders.

COPYRIGHTS

All Material, Copyright © 2005 by General Electric Company. All rights reserved.

This page intentionally left blank

IMPORTANT PRECAUTIONS

LANGUAGE

WARNING

- THIS SERVICE MANUAL IS AVAILABLE IN ENGLISH ONLY.
- IF A CUSTOMER'S SERVICE PROVIDER REQUIRES A LANGUAGE OTHER THAN ENGLISH, IT IS THE CUSTOMER'S RESPONSIBILITY TO PROVIDE TRANSLATION SERVICES.
- DO NOT ATTEMPT TO SERVICE THE EQUIPMENT UNLESS THIS SERVICE MANUAL HAS BEEN CONSULTED AND IS UNDERSTOOD.
- FAILURE TO HEED THIS WARNING MAY RESULT IN INJURY TO THE SERVICE PROVIDER, OPERATOR OR PATIENT FROM ELECTRIC SHOCK, MECHANICAL OR OTHER HAZARDS.

AVERTISSEMENT

- CE MANUEL DE MAINTENANCE N'EST DISPONIBLE QU'EN ANGLAIS.
- SI LE TECHNICIEN DU CLIENT A BESOIN DE CE MANUEL DANS UNE AUTRE LANGUE QUE L'ANGLAIS, C'EST AU CLIENT QU'IL INCOMBE DE LE FAIRE TRADUIRE.
- NE PAS TENTER D'INTERVENTION SUR LES ÉQUIPEMENTS TANT QUE LE MANUEL SERVICE N'A PAS ÉTÉ CONSULTÉ ET COMPRIS.
- LE NON-RESPECT DE CET AVERTISSEMENT PEUT ENTRAÎNER CHEZ LE TECHNICIEN, L'OPÉRATEUR OU LE PATIENT DES BLESSURES DUES À DES DANGERS ÉLECTRIQUES, MÉCANIQUES OU AUTRES.

WARNUNG

- DIESES KUNDENDIENST-HANDBUCH EXISTIERT NUR IN ENGLISCHER SPRACHE.
- FALLS EIN FREMDER KUNDENDIENST EINE ANDERE SPRACHE BENÖTIGT, IST ES AUFGABE DES KUNDEN FÜR EINE ENTSPRECHENDE ÜBERSETZUNG ZU SORGEN.
- VERSUCHEN SIE NICHT, DAS GERÄT ZU REPARIEREN, BEVOR DIESES KUNDENDIENST-HANDBUCH ZU RATE GEZOGEN UND VERSTANDEN WURDE.
- WIRD DIESE WARNUNG NICHT BEACHTET, SO KANN ES ZU VERLETZUNGEN DES KUNDENDIENSTTECHNIKERS, DES BEDIENERS ODER DES PATIENTEN DURCH ELEKTRISCHE SCHLÄGE, MECHANISCHE ODER SONSTIGE GEFAHREN KOMMEN.

AVISO

- ESTE MANUAL DE SERVICIO SÓLO EXISTE EN INGLÉS.
- SI ALGÚN PROVEEDOR DE SERVICIOS AJENO A GEMS SOLICITA UN IDIOMA QUE NO SEA EL INGLÉS, ES RESPONSABILIDAD DEL CLIENTE OFRECER UN SERVICIO DE TRADUCCIÓN.
- NO SE DEBERÁ DAR SERVICIO TÉCNICO AL EQUIPO, SIN HABER CONSULTADO Y COMPRENDIDO ESTE MANUAL DE SERVICIO.
- LA NO OBSERVANCIA DEL PRESENTE AVISO PUEDE DAR LUGAR A QUE EL PROVEEDOR DE SERVICIOS, EL OPERADOR O EL PACIENTE SUFRAN LESIONES PROVOCADAS POR CAUSAS ELÉCTRICAS, MECÁNICAS O DE OTRA NATURALEZA.

ATENÇÃO

- ESTE MANUAL DE ASSISTÊNCIA TÉCNICA SÓ SE ENCONTRA DISPONÍVEL EM INGLÊS.
- SE QUALQUER OUTRO SERVIÇO DE ASSISTÊNCIA TÉCNICA, QUE NÃO A GEMS, SOLICITAR ESTES MANUAIS NOUTRO IDIOMA, É DA RESPONSABILIDADE DO CLIENTE FORNECER OS SERVIÇOS DE TRADUÇÃO.
- NÃO TENHA TENTAR REPARAR O EQUIPAMENTO SEM TER CONSULTADO E COMPREENDIDO ESTE MANUAL DE ASSISTÊNCIA TÉCNICA.
- O NÃO CUMPRIMENTO DESTA AVISO PODE POR EM PERIGO A SEGURANÇA DO TÉCNICO, OPERADOR OU PACIENTE DEVIDO A CHOQUES ELÉTRICOS, MECÂNICOS OU OUTROS.

AVVERTENZA

- IL PRESENTE MANUALE DI MANUTENZIONE È DISPONIBILE SOLTANTO IN INGLESE.
- SE UN ADDETTO ALLA MANUTENZIONE ESTERNO ALLA GEMS RICHIEDE IL MANUALE IN UNA LINGUA DIVERSA, IL CLIENTE È TENUTO A PROVVEDERE DIRETTAMENTE ALLA TRADUZIONE.
- SI PROCEDA ALLA MANUTENZIONE DELL'APPARECCHIATURA SOLO DOPO AVER CONSULTATO IL PRESENTE MANUALE ED AVERNE COMPRESO IL CONTENUTO.
- NON TENERE CONTO DELLA PRESENTE AVVERTENZA POTREBBE FAR COMPIERE OPERAZIONI DA CUI DERIVINO LESIONI ALL'ADDETTO ALLA MANUTENZIONE, ALL'UTILIZZATORE ED AL PAZIENTE PER FOLGORAZIONE ELETTRICA, PER URTI MECCANICI OD ALTRI RISCHI.

警告

このサービスマニュアルには英語版しかありません。

GEMS以外でサービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。

このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないで下さい。

この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。

注意:

本维修手册仅存有英文本。

非 GEMS 公司的维修员要求非英文本的维修手册时，客户需自行负责翻译。

未详细阅读和完全了解本手册之前，不得进行维修。

忽略本注意事项会对维修员，操作员或病人造成触电，机械伤害或其他伤害。

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent, have notation "damage in shipment" written on all copies of the freight or express bill before delivery is accepted or "signed for" by a General Electric representative or a hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14-day period.

To file a report:

- Call 1-800-548-3366 and use option 8.
- Fill out a report on <http://us44hdd21/sctq/InstallFulfill/InstalFulfillment.htm>
- Contact your local service coordinator for more information on this process.

Rev. Jan. 5, 2005

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Medical personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Medical Systems Group, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Medical Systems Group, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

IMPORTANT...RADIOACTIVE MATERIAL HANDLING

Only employees formally trained in radioactive materials handling and this equipment are authorized by the GE Healthcare Radiation Safety Officer to use radioactive materials to service this equipment.

GE Healthcare Services is required to notify the applicable U.S. state agency PRIOR to any source service event involving pin source handling. See NUC/PET Radioactive material guides for specific instruction or contact your EHS Specialist.

A radiation survey must be performed when a pin source has been removed and replaced. See Radiation Survey Form Instructions or contact your EHS Specialist.

Rev 2 (July 21, 2005)

LITHIUM BATTERY CAUTIONARY STATEMENTS



CAUTION Risk of Explosion

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



ATTENTION Danger d'Explosion

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives. GE personnel, please use the GEMS PQR process to report all omissions, errors, and defects in this publication.

Revision History

Revision	Date	Reason for change
1	10/5/05	Initial release

This page intentionally left blank

Table of Contents

Chapter 1

Electrical Introduction..... 19

Section 1.0

Introduction 19

Section 2.0

Required FE Common Tools and Supplies..... 20

2.1 FE Calibration and Service Tool List 20

2.2 Electrical Tools 20

2.3 Image Quality Calibration Tools..... 20

2.4 Detector Service Tools 20

2.5 Optional Tools..... 21

2.6 Safety Materials 21

2.7 Cleanliness 21

Section 3.0

Requirements/Assumptions..... 22

Chapter 2

Electrical Integration and Safety Verifications 23

Section 1.0

Electrical Power ON & Ground Checks..... 23

1.1 Required Tools 24

1.2 Initial PDU Configuration 24

1.2.1 Circuit Breakers 24

1.2.2 Relay Board 24

1.2.3 Power Switches 25

1.2.4 Hardware and Connection Check..... 25

1.2.5 Covers 25

1.3 Suite Emergency Off Checks 26

1.4 Line Transformer Settings 26

1.4.1 Requirements 26

1.4.2 Line Input Conditions 26

1.5 System Power Up 27

1.6 Emergency Stop Check 29

Section 2.0

Computer Integration..... 31

2.1 Introduction 31

2.2 System Configuration Data Sheets..... 31

2.3 Restore System State 31

2.4 Install Customer Options 32

2.4.1 Software..... 32

2.4.2 Camera 34

2.5 Monitor Setup 35

2.6 Contrast/Brightness Black & White Adjustment Procedure 35

2.7 Shut Down Application..... 36

2.8	Check/Set Date and Time	36
2.9	Reconfig the OC.....	36
2.9.1	Overview	36
2.9.2	Procedure.....	37
2.10	Applications Start-Up	43
2.11	GRE Console Boot-up Flow Chart	44

Section 3.0

Table Gantry Integration 45

3.1	Introduction	45
3.2	Check Alignment Lights	45
3.2.1	Room Light Adjustment.....	45
3.2.2	Turning the Alignment Lights ON	45
3.2.3	Internal Axial Lights.....	46
3.2.4	External Axial to Internal Axial Distance	46
3.2.5	Coronal Lights	46
3.2.6	Turn Lights OFF	46
3.3	Autovoice/Intercom Check	47
3.3.1	Requirements.....	47
3.3.2	Patient Speaker.....	47
3.3.3	Operator Console Speaker	47
3.3.4	Autovoice Volume	47
3.4	CT System X-Ray ON Indicators, Cautions & Warning Labels.....	48
3.4.1	Check And Install System Warning Labels	48
3.4.2	Console	48
3.4.2.1	On The SCIM	48
3.4.2.2	On The Keyboard.....	48
3.4.3	Gantry	48
3.4.3.1	Scan Window Laser Labels	48
3.4.3.2	Laser Window Labels.....	48
3.4.3.3	Front Cover Laser Warning.....	48
3.4.3.4	Front cover Information Labels	48
3.4.3.5	Gantry System GIB (Rating) label.....	48
3.4.4	Table - 2000mm	48
3.4.4.1	Front Side Cover - Pinch Hazard Warning Label	48
3.4.4.2	Back Cradle Pan - Pinch Hazard Warning Label	48
3.4.5	Table - 1700mm	49
3.4.5.1	Front Side Cover - Pinch Hazard Warning Label	49
3.4.5.2	Rear Side Cover - Pinch Hazard Warning Label	49
3.4.5.3	Back Cradle Pan - Pinch Hazard Warning Label	49
3.4.6	NGPDU	49
3.4.6.1	Front Cover - Emergency Off label	49
3.4.6.2	Front Cover - Gantry Enable Label	49
3.4.6.3	Front Cover - Power On Label	49
3.4.7	Accessories	49
3.4.7.1	Table Foot Extender Label.....	49
3.4.7.2	Coronal Head Holder Label	49
3.4.7.3	Sagittal Head Holder Label	49
3.4.7.4	Accessory Tray Label	49
3.4.7.5	IV Pole Label.....	49
3.4.8	Documentation - Verification	49

3.5	Check Warning Labels.....	50
3.5.1	On SCIM	50
3.5.2	On Gantry	50
3.5.3	On Laser	50
3.6	Process Product Locator Cards.....	50
3.7	Install Service Cabinet.....	50
3.8	Check X-Ray Lights	50
3.9	Mechanical Characterization	51
3.9.1	Alignment Light Characterization.....	51
3.9.2	Alignment Light Characterization.....	51
3.10	Interference Test.....	51
3.10.1	Verify Table Elevation - All Systems.....	52
3.10.2	Tests for Pro16, LS16, Ultra & Plus Systems	53
3.10.2.1	Position Tilt, Move Table to Interference Limit	53
3.10.2.2	Position Table, Move Tilt to Interference Limit	53
3.10.2.3	Tilt Limits When Table Below Scan Plane Lower Limit	54
3.10.3	Alignment Light Characterization - All Systems.....	55
3.10.3.1	Overview.....	55
3.10.3.2	Procedure	56

Chapter 3 Image Quality 57

Section 1.0 Introduction 57

Section 2.0 Calibration Process..... 58

2.1	Reference Procedures.....	58
2.1.1	Scanning with Service Protocols	58
2.1.2	Center Phantom.....	58
2.2	Prepare the QA Phantom	58
2.3	Calibration Process Introduction.....	58

Section 3.0 Table/Gantry Alignment Procedure 59

3.1	Conditions.....	59
3.2	Procedure	59

Section 4.0 Tube Warm Up and Fast Cal..... 60

Section 5.0 Tomographic Plane Indication 61

Section 6.0 Image Series 62

6.1	Scan Protocol	62
6.2	Data Recording: Means and Standard Deviation	62
6.3	Term Definitions and Screens	62
6.4	48cm Phantom Image Series Image Performance Verification	64
6.4.1	Acquiring the 48cm Phantom Image Series	64

6.4.2	Image Performance Verification	65
6.4.2.1	Series Means (AvXo-AvXc and AvSDo) & Center Smudge	65
6.4.2.2	Band and Streak Artifact	65
6.4.3	Failure Recommended Actions	67
6.4.3.1	Series Means (AvXo-AvXc or AvSDo) Failure Recovery	67
6.4.3.2	Center Smudge Failure Recovery	67
6.4.3.3	Band or Streak Artifact Failure Recovery	68
6.5	20cm QA Phantom Image Series Image Performance Verification	68
6.5.1	Acquiring the 20cm QA Phantom Image Series	68
6.5.2	20cm QA Phantom Image Series Image Performance Verification	69
6.5.3	Failure Recommended Actions	73
6.5.3.1	1 st Image Series (4 Image MTF Average) Failure Recovery	73
6.5.3.2	2 nd Image Series (Visible Lines) Failure Recovery	73
6.5.3.3	3 rd Image Series (Visible Holes) Failure Recovery	73
6.5.3.4	4 th Image Series Failure Recovery	74

Section 7.0

System Functional Test	76
-------------------------------------	-----------

Section 8.0

Save System State	77
--------------------------------	-----------

Chapter 4

Customer Options Installation & Verification	79
---	-----------

Section 1.0

CT Options	79
-------------------------	-----------

Section 2.0

Install Options	80
------------------------------	-----------

2.1	Camera (Filming Device)	80
2.2	Injector	80
2.3	Advantage Windows Workstation (AWW)	80
2.4	Uninterruptible Power System (UPS)	81
2.5	Other Options	81

Section 3.0

DICOM Network Introduction	82
---	-----------

Section 4.0

Before You Start	83
-------------------------------	-----------

4.1	Network Physical Requirements	83
4.2	Network Identity Information	83
4.3	Scanner to DICOM Remote Hosts Network Information	83
4.4	Scanner to DICOM HIS/RIS Interface Network Information	83
4.5	Scanner to DICOM Printers Network Information	84

Section 5.0

Declaring the System on the Hospital Network	85
---	-----------

5.1	Enter Configuration Routine	85
5.2	Configure Network Settings	86
5.3	Initiate System Reconfiguration	88

Section 6.0	
Declaring Remote Hosts on the CT System	89
6.1 Enter Remote Host Configuration Screen	89
6.2 Declaring Advantage NET Remote Hosts on the Scanner	89
6.3 Declaring DICOM Remote Hosts on the CT Scanner.....	90
Section 7.0	
Declaring the CT System on Remote Hosts	92
7.1 Declaring the Scanner on Advantage NET Protocol Devices/Systems	92
7.2 Declaring the Scanner on DICOM Protocol Devices/Systems	92
Section 8.0	
DICOM HIS/RIS Setup	93
8.1 Prerequisites.....	93
8.2 Loading ConnectPRO Software Option on the CT System	93
Section 9.0	
DICOM Filming Devices Setup.....	95
9.1 Prerequisites.....	95
9.2 Declaring DICOM Filming Devices on the CT System	95
9.3 Troubleshooting Tips	106
Section 10.0	
Network Connections	108

Chapter 5	
Finalization.....	113

Section 1.0	
Gantry Cover Alignment Adjustment Guide.....	113
1.1 Overview.....	113
1.2 Tools Required	113
1.3 Adjustment Guide	113
1.3.1 Front/Rear Cover Adjustment.....	113
1.3.2 Scan Window.....	114
1.3.3 Top Cover Adjustment.....	114
1.3.4 Side Covers	115
1.3.5 Finish	115
Section 2.0	
Customer Touch Leakage Test.....	116
2.1 Personnel Requirements	116
2.2 Overview.....	116
2.3 Preliminary Requirements	116
2.3.1 Tools and Test Equipment.....	116
2.3.2 Consumables.....	116
2.3.3 Replacement Parts	116
2.3.4 Safety.....	116
2.3.5 Required Conditions	117
2.4 Procedure	117
2.4.1 Patient Touch Leakage Current Test Procedure	117
2.4.2 Ground Resistance Checks Procedure (done during mechanical install).....	119

Chapter 6

Forms and Checklists 121

Section 1.0

Mechanical Vendor Installation List..... 123

Section 2.0

Electrical Calibration Installation Checklist 125

Section 3.0

GE Form 4879 Installation Data Verification 127

3.1 Installation Site History..... 127

3.1.1 RECORDS KEEPING AND DOCUMENTATION - IMPORTANT!..... 127

3.1.2 Component Tractability - IMPORTANT!..... 127

3.1.3 Installation Procedures Traceability - IMPORTANT!..... 127

3.1.4 Installation Test & Tools Traceability - IMPORTANT!..... 128

3.2 System X-Ray Indicators and Warning Labels..... 128

3.2.1 X-Ray On Indicators..... 128

3.2.2 Operator Indicators - HHS Requirement..... 129

3.3 Warning Labels 129

3.3.1 Laser Warning labels 129

3.3.2 Operator Use Warning Label - SCIM 129

3.3.3 Appropriate Language Warning Labels Verification..... 130

3.4 Tomographic Plane Indication Accuracy..... 130

3.5 Table/Gantry Alignment Procedure..... 130

3.6 Check Alignment Lights - Test 131

3.7 Interference Test..... 131

3.8 System Functional Test..... 132

3.9 IQ Section - 5.X Image Quality Series 132

3.10 Documentation Section - System Paperwork & Product Locator..... 132

3.10.1 Installation Verification 132

3.10.2 Product Locator 132

3.10.3 Regulatory Information Distribution..... 133

Section 4.0

Install Completion Checklist..... 135

4.1 CT System 135

4.2 CT Options..... 135

4.3 System Cleanup..... 135

4.4 Dollies Return..... 135

4.5 Install Completion Material Checks..... 136

Section 5.0

Electronic Forms 137

Appendix A

Additional Characterization Procedures..... 139

Appendix B

System Configuration Data Sheets 141

Appendix C

Symbols..... 145

This page intentionally left blank

Chapter 1

Electrical Introduction



NOTICE
Potential for
Data Loss and/
or Equipment
Damage

To prevent potential data loss and equipment damage, please do the following:

- Record data collected from procedures in this chapter into Form F4879 when directed, located in [Chapter 6](#) of this book.
- Only use the Installation manual that arrives with your system for installation. Any other revisions of this manual may not exactly match your system.

Section 1.0

Introduction

Use the continuity and ground checks to verify the system power connections have not shorted to ground and that the ground and neutral connections are intact.

Section 2.0

Required FE Common Tools and Supplies

2.1 FE Calibration and Service Tool List

Note: Items with a “check” (✓) are included in the Install Support Kit.

Special CT Tools used for mechanical alignments:

- | | |
|---|---|
| ✓ 5mm hex bit for 3/8" drive 6" long
(Snap-On FAML5E or equivalent) | ✓ 10mm open-end thin wrench
(Snap-On SRSM10 or equivalent) |
| ✓ 10mm hex bit for ratchet wrench (ball end)
(Snap-On FABM10E or equivalent) | ✓ 21mm open-end thin wrench
(Snap-On LTAM2124 or equivalent) |
| ✓ 2.5mm Allen hex bit for 1/4" | ✓ 14mm ball hex socket bit for 3/8" drive |
| • Standard FE Tool Kit | ✓ 14 mm hex socket bit for 1/2" drive |
| • Torque Wrench Kit | |

2.2 Electrical Tools

These tools must be calibrated yearly.

- Fluke 87 DVM or equivalent
- Clamp on amp meter

2.3 Image Quality Calibration Tools

- GE Performance Phantom
- QA Phantom (2206352)
 - 24cm (2144721)
 - 48cm (2144721-2)
 - Phantom Holder

2.4 Detector Service Tools

A DAS/Detector Service Kit (PN 2344539) is included in the Install Support Kit.

- Aero Duster
- AMAX Contact Cleaner

2.5 Optional Tools

Needed for warranty recalibration:

- GE HV Bleeder
- Scope with 10X probes
- Beckman CT231 clamp-on Amp probe: 46-194427P228 (Fits up to #2 size wire)
- Beckman CT232 clamp-on Amp probe: 46-194427P270 (Fits #1 size wire and larger)
- Scope Probe-to-bleeder Cable 46-219921G1 (Belden #8422 cable, 30 ft)
- Polaroid type 52 film and developer
- Radial dial indicator (mm or inches) and mounting bracket
- Caliper Dial indicators (mm or inches)
- Ground Rod Tester Clamp on Amp Probe

2.6 Safety Materials

Note: Items with “checks” (✓) are included in the Install Support Kit

- ✓ Lockout/Tagout kit, or equivalent
- ✓ Nitrile Rubber Gloves
- Safety Glasses

2.7 Cleanliness

Any dirt on the surface increases leakage current on the filter or converter cards and causes the DAS to fail the drift spec. Wear Nitrile gloves (part number 2207303-6 [large] and 2207303-7 [extra large]) when you handle the DAS, because fingerprints on the board can cause problems during humid conditions. Use only clean, new Nitrile gloves. Do not use hospital grade gloves.



NOTICE **NEVER USE AN ERASER TO CLEAN ANY PART OF THE DAS.**
DUST COVERS REQUIRED for installations on construction sites.

Section 3.0

Requirements/Assumptions

- This procedure will be performed by an appropriately trained engineer.
- All stations in a suite must have the same SUITE ID.
- You need the name of all hosts in the suite and their corresponding Internet/Ethernet numbers.
- You need the Internet (IP) addresses the first time you execute a reconfig on the system.
 - When you connect the system to a network, contact the system administrator to obtain the IP addresses for all the computers in the suite.
 - You also need an IP address for each gateway (second) ethernet board in any OC or IC.
 - You can use the default internet number on stand-alone systems (stand-alone = not connected to any network).
- For more detailed information and instructions regarding Network Integration, see [Chapter 4 on page 79](#).

Chapter 2

Electrical Integration and Safety Verifications



NOTICE
Potential for
Data Loss and/
or Equipment
Damage

To prevent potential data loss, please do the following:

- Record data collected from procedures in this chapter into Form F4879 when directed, located in [Chapter 6](#) of this book.
- Only use the Installation manual that arrives with your system for installation. Any other revisions of this manual may not exactly match your system.

Section 1.0

Electrical Power ON & Ground Checks



WARNING



**THIS PROCEDURE MEASURES POTENTIALLY HAZARDOUS VOLTAGES.
USE AND FOLLOW LOCKOUT/TAGOUT PROCEDURES.**




Figure 2-1 NGPDU

1.1 Required Tools

- Multimeter with a rating of at least 1000 volts
- Multimeter leads with a rating of at least 1000 volts

1.2 Initial PDU Configuration



1.2.1 Circuit Breakers

Set all circuit breakers to OFF

1.2.2 Relay Board

- 1.) Set SW to the normal position.
- 2.) When system is already, three lamps are both lighting (refer to [Figure 2-2](#)).




Figure 2-2 NGPDU Control Board

1.2.3 Power Switches

Turn OFF all power switches on all subsystems

- Gantry
- Table
- DAS
- Console

1.2.4 Hardware and Connection Check

Use this step to check mechanical connections and tighten anything that may have shaken loose during shipment. Verify **all** hardware and connections in the PDU are securely fastened.

1.2.5 Covers

Install, or verify the presence of, all the lexan safety covers.

1.3 Suite Emergency Off Checks SEO

-  **WARNING**  **VERIFY ALL PERSONNEL HAVE CLEARED THE SYSTEM BEFORE YOU TURN ON WALL POWER.**
- 1.) Turn wall power ON to the PDU.
 - 2.) **Press the suite emergency off button and verify it turns off wall power to the PDU.**
[Typically, this red palm button is located on the wall close to the console, within the scan suite.]
 - 3.) Verify that all “Emergency Off” button are working properly.
 - 4.) Leave power “OFF”

1.4 Line Transformer Settings

1.4.1 Requirements

- 1.) The PDU is shipped configured for 480VAC.
- 2.) Complete only if your site uses a voltage other than 480VAC.
- 3.) If PDU is configured for 480VAC, go to 1.5. Otherwise, proceed to [Section 1.4.2](#).

-  **WARNING**  **MAKE SURE YOU TURNED OFF, TAGGED AND LOCKED THE MAIN WALL POWER BEFORE YOU CHANGE TAPS. FAILURE TO DISCONNECT POWER AT MAIN INPUT MAY RESULT IN ELECTROCUTION. TURN OFF WALL POWER TO CONNECT OR MOVE METER LEADS, OR TO REMOVE OR INSTALL COVERS.**

1.4.2 Line Input Conditions

- 1.) Monitor the No Load Line to Line Voltage at L1, L2, L3, during the workday. Do not record this data during “brown out” conditions.
- 2.) After you determine the nearest nominal line, verify the tap connections match (refer to [Table 2-1](#) and [Figure 2-3](#) for tap locations).




Figure 2-3 PDU Tap Positions (Rear)

Note: **Taps should be shipped as shown for 480 VAC only. For all others, you must move the taps. The tap check should be completed by the mechanical installer.**

- 3.) Verify that the No Load Line to Line Voltage never falls outside the corresponding minimum

and maximum values listed in [Table 2-1](#).

- 4.) Use a 0-750 AC voltmeter of 3/4% accuracy to measure the line-to-line voltages at L1, L2, and L3.
 - Verify the highest line-to-line voltage does not exceed 1.02 times the lowest voltage.
 - **Example:** If the lowest voltage equals 474, the highest voltage should not exceed $474 \times 1.02 = 483.5$ volts.



WARNING



THIS PROCEDURE MEASURES POTENTIALLY HAZARDOUS VOLTAGES. USE AND FOLLOW LOCKOUT/TAGOUT PROCEDURES.

NO LOAD Line to Line Voltages		TAP CONNECTIONS (All 3 phases must have same the configuration)		
Nominal	Maximum Range (10%)	Phase A Connection	Phase B Connection	Phase C Connection
480V*	432 to 528*	3-4*	3-4*	3-4*
460V	414 to 506	3-5	3-5	3-5
440V	396 to 484	3-6	3-6	3-6
420V	378 to 462	2-4	2-4	2-4
400V	360 to 440	2-5	2-5	2-5
380V	342 to 418	2-6	2-6	2-6
240V**	216 to 264**	1-4**	1-4**	1-4**
220V**	198 to 242**	1-5**	1-5**	1-5**
200V**	180 to 220**	1-6**	1-6**	1-6**
* Factory Default				
** 2326492-3 PDU only				

Table 2-1 PDU Line Tap Connections

1.5 System Power Up



CAUTION Verify all personnel have cleared the system before you turn on wall power.

- 1.) Turn ON A1 breaker panel.
- 2.) Turn ON all system power switches and breakers (table, gantry, PDU, console).

SUB-SYSTEM POWER-UP

- 1.) Turn ON switch S3 in the table (120vac 24hr power).
- 2.) Turn ON the Gantry **120VAC**. (Light should turn on.)
- 3.) Turn **AXIAL DRIVE ENABLE** ON. (Light should turn on.)
- 4.) Turn **HV DC ENABLE** ON. (Light should turn on.)
- 5.) Push the Service Switch Panel reset button (see [Figure 2-4](#)).




Figure 2-4 Service Switch Panel

AXIAL ENABLE SWITCH TEST

- 1.) Turn OFF axial drive enable switch **AXIAL_DRIVE** on the Service Switch Panel.
For the initial condition, do not leave the tube at the 2:30 position.
- 2.) Clear the gantry arc for rotation.
- 3.) Press the alignment light push button.
- 4.) Verify that the gantry did not rotate.
- 5.) Turn ON axial drive enable switch **AXIAL_DRIVE** on the Service Switch Panel.

Note:

ROTATION SAFETY CHECKLIST

- 1.) Turn OFF axial drive enable switch AXIAL_DRIVE.
- 2.) Turn OFF HVDC enable switch.
- 3.) Press red E-STOP button.
- 4.) Manually rotate the gantry 360 degrees. (Keep one finger on the Gantry button.)
 - Listen for any interference between the rotating and stationary parts.
(Correct any interference problems.)
 - Listen for any loose parts.
(Tighten parts as needed.)
- 5.) Turn ON axial drive enable switch AXIAL_DRIVE.



WARNING

MAKE SURE THERE ARE NO OBSTRUCTIONS AROUND THE GANTRY. PRESSING THE ALIGNMENT LIGHT PUSHBUTTON WILL CAUSE THE GANTRY TO ROTATE.

- 6.) Press the alignment light push button.
- 7.) Verify that the gantry rotates.
- 8.) Perform a 4 second X-ray OFF scan.



NOTICE

During the scan, it may be necessary to enter the scan room, to obtain a better listening position. If so, keep a finger on one of the four E-STOP buttons (on the gantry), to quickly stop the gantry, if necessary.



- a.) From the console, click on the SERVICE DESKTOP icon.
- b.) Select DIAGNOSTICS.
- c.) Select DIAGNOSTIC DATA COLLECTION
- d.) Set the scan time to 4.00 seconds
- e.) Leave the door open. (This makes it easier to hear any loose or interfering parts.)
 - * Listen for any interference between the rotating and stationary parts.
(Correct any interference problems.)
 - * Listen for any loose parts.
(Tighten parts as needed.)
- 9.) After completing the 4 second scan, repeat steps 9a through 9e, with the following scan times:
 - 2.0 second scans
 - 1.0 second scans
 - 0.7 second scans
 - 0.5 second scans

1.6 Emergency Stop Check

- 1.) Use the gantry push-buttons to advance the cradle about 0.5m (2ft) from the home position.
- 2.) Press one of the E-STOP buttons on the gantry.
- 3.) Make sure the TABLE POWER shuts off, and the green LED flashes.
- 4.) Depress one of the table elevation buttons, to verify the emergency stop disabled table elevation.
- 5.) Depress one of the cradle drive buttons, to verify the emergency stop disabled the cradle drive.
- 6.) Press one of the **RESET** buttons to turn on X-RAY DRIVES POWER. (120 VAC LED stops flashing.)
- 7.) Press the other E-STOP button on the gantry.
 - a.) Make sure the Table Power shuts off.
 - b.) Manually move the cradle to the home position to make sure the cradle clutch released.
 - c.) Make sure the cradle latches securely in the home position.
- 8.) Press one of the **RESET** buttons to turn on X-RAY DRIVES POWER.
- 9.) Press one of the four table tape switches to make sure the table down motion stops. Repeat with the three remaining table tape switches.
- 10.) Press the console emergency stop switch; make sure the Table Power shuts off.
- 11.) Press one of the **RESET** buttons to turn on X-RAY DRIVES POWER. (See [Figure 2-4](#)).




Figure 2-5 Reset buttons on Gantry and Service Switch bank.




Figure 2-6 Emergency Stop button positions

Note: Emergency Stop buttons are located on the front and rear of the gantry (8 in all). They are also located on both sides of the table base (4 in all) as noted in [Figure 2-6](#).

Section 2.0 Computer Integration

2.1 Introduction

This Section describes the reconfiguration, system state restore, options, and monitor adjustment procedures.




Figure 2-7 Computer Integration Process Overview

2.2 System Configuration Data Sheets

For convenient removal and use during installation, System Configuration Data Sheets appear in Appendix D. Please locate and complete to them at this point during installation.

2.3 Restore System State


Tools Required: None

Your system should have a system state DVD, located in the software collector box. The system state DVD contains:

- Collimator Characterization
- Phantom Calibrations
- Gen Cal
- Other Data

The installation process uses all the system state files. At this time, use the system state DVD to restore all files.

If you cannot locate an existing system state DVD, you must recalibrate your system.



- 1.) If you are not on the Service Desktop, click on the SERVICE DESKTOP icon.



- 2.) Click on the PM icon.
- 3.) Select SYSTEM STATE.
- 4.) Insert the DVD in the DVD drive.
- 5.) Select CHARACT.
- 6.) Select CALS.
- 7.) Select RESTORE to restore the system characterization and phantom calibration files to the system.

Note: **Restore State can take as long as ten minutes, although typical times average about three minutes. When Restore State completes, dismiss the tool, and proceed to the next section.**

If any error should occur during the restore process, see the Software Load Procedure manual (Load From Cold) for information regarding possible error messages and their recovery.

- 8.) Click NO for Reset Scan Hardware popup message.
- 9.) Select DISMISS.

2.4 Install Customer Options

Tools Required: None

2.4.1 Software

Note: **Your system may have a DVD that contains customer purchased options. If your system has an options DVD, install it at this time--otherwise skip this section.**

Ensure that the options DVD is NOT write protected at this time. The initial install requires that the DVD be write enabled; subsequent installs can be done with the DVD write protected.



- 1.) If you are not on the Service Desktop, click on the SERVICE DESKTOP icon.



- 2.) Click on the UTILITIES icon.
- 3.) Select INSTALL.

4.) Select INSTALL OPTIONS.

An Options Window appears (Figure 2-8):




Figure 2-8 Options Window when First Selected

- Check the FDO to see what options were ordered.
- Compare FDO options to those on the Option DVD.
- If different contact your local sales representative.

- 5.) Insert the options DVD into the DVD drive and click on OK. (If you do not have an options DVD, click on OK anyway, wait for the abort pop up, then abort the process.)




Figure 2-9 Example: Options Window

- 6.) Select all of the options in the left-hand column to install the corresponding software.
- 7.) Select INSTALL. A box may appear while the options are loading. When an option is displayed in the *Installed Options* list, then installation of that option is complete. Note that some options take a fraction of a second to install, while options like 3D may take a half minute (due to the fact that they are installing software).
- 8.) After the options are installed, select QUIT.
- 9.) Select OK.
- 10.) Remove the DVD and write protect the side with options.
- 11.) When the system prompts to Reboot, click YES, and reboot the system to complete the installation.

2.4.2 Camera

Tools Required:

- Small flat blade screw driver
- Data collected from data sheets (See "Camera Application Configuration" on page 143.)
- Software Load Procedures manual
- System Service manual.

Note: If a DASM is required, the DASM hardware must be installed before proceeding.
For details on camera configuration, refer to the Software Load Procedures manual.
For details on troubleshooting the camera, refer to the System Service manual.



- 1.) Click on the SERVICE DESKTOP icon.



- 2.) Select UTILITIES icon.
- 3.) Select INSTALL CAMERA.
- 4.) Select ADD.
- 5.) Select DASM or DICOM.
- 6.) Follow procedures on the screen.
- 7.) Return to Home Page

2.5 Monitor Setup

The LightSpeed 5.X systems are shipped with LCD monitors. For information on LCD monitor color setup, please refer to the documentation shipped with the monitor.

2.6 Contrast/Brightness Black & White Adjustment Procedure



- 1.) If you are not on the Service Desktop, click on the SERVICE DESKTOP icon.



- 2.) Click on the IMAGE QUALITY icon.
- 3.) Select INSTALL SMPTE IMAGE and wait approximately 3-4 minutes for SMPTE image to install. (When complete the following message will display: SMPTE and QA images have been successfully copied)
- 4.) Press ENTER to exit the Service Desktop.



- 5.) Click the IMAGEWORKS icon.
- 6.) Display the SMPTE pattern. Use the browser to select Exam 1000, which contains the SMPTE pattern, and enlarge the image to full screen display.
- 7.) Select Viewer.
- 8.) Select 1:1 format.
- 9.) Increase the monitor's contrast to maximum.

Note: Adjust monitor contrast until the operator sees the anatomical structure (window raster)

- 10.) Increase the Brightness to maximum.
- 11.) Decrease the Brightness, until the raster just fades into, and matches, the monitor screen background. At this point, the 5% and 95% patches should be just visible.
 - If additional tweaking is required to attempt to match the monitor image to the filmed image, use only the brightness control.
 - If the CRT image exhibits any tearing or smearing of the alphanumeric characters, then reduce the contrast setting slightly until the tearing/smearing is just eliminated. The optimum setting for contrast is the highest setting that does not cause tearing/smearing of the alphanumeric characters.

- You should always finish up by displaying and filming images of anatomy (typical heads and bodies), and asking the technologist to compare the CRT image to the film image.

2.7 Shut Down Application

Tools Required: None

Standard Level

If Applications is currently running, you must shutdown system applications.



- 1.) Click on the SERVICE DESKTOP icon.



- 2.) On the desktop toolbar select UTILITIES icon.
- 3.) Select APPLICATIONS SHUTDOWN (to bring down applications only).

Super User Level

- 1.) Open a UNIX Shell window.
- 2.) Type: `su -` ENTER at the prompt.
- 3.) Type the root (super user) password: #bigguy

2.8 Check/Set Date and Time

Tools Required: None

If date and time need to be corrected:

- 1.) Type/enter `setdate` ENTER.
- 2.) Follow the instructions to set the correct time and date.

2.9 Reconfig the OC

Tools Required: None

Note: The document collector box that arrived with your system contains the *Software Installation Procedures* manual, which documents the reconfiguration procedure in more detail.

2.9.1 Overview

On the following screens, you should make the changes necessary, pressing the corresponding button at the top of the screen to move from screen to screen. When you are done, you can either press the ACCEPT button to start the reconfiguration process, or press the QUIT button to exit without changing the system configuration.

While the reconfiguration is going on, messages are displayed in a shell window that closes when reconfiguration is complete. Should you later want to review the reconfiguration output, it is logged to the following file:

`/var/adm/install.log.YYYYMMDDWWHHMMSS`

Where

`YYYYMMDDWWHHMMSS` is the Date/Time that the reconfiguration was started.

To view the file, type: `more /var/adm/install.log.YYYYMMDDWWHHMMSS`

It is possible to abort the reconfiguration while entering information on the reconfiguration screens. Simply press the QUIT button at the top of the screen. There is NO safe way to abort the reconfiguration after pressing the ACCEPT button. If the entries made in the screens were incorrect, DO NOT try to stop the reconfiguration, instead wait for it to complete, and rerun reconfig, entering the correct parameters.

2.9.2 Procedure

- 1.) Change directory to scripts:
Type: `cd /usr/g/scripts` ENTER at the prompt.
- 2.) Launch the Install utility:
Type: `reconfig` ENTER at the prompt.

The OC displays the Install Utility Window as shown in [Figure 2-10](#).




Figure 2-10 Install Utility Window

- 3.) Click on the CONFIG button.

The OC displays the System Configuration - System Settings Screen as shown in [Figure 2-11](#).

Comment: The following pages show the screens that are used to change the configuration of the system. These screens are the same as those used for the Software Configuration during Load From Cold. The actual screens will vary depending on the current configuration of your system.

Figure 2-11 System Settings Screen

4.) Configure System Settings

- a.) Hospital Name (Figure 2-11, item 1) configures the name that will show up on images produced by this scanner. *Example: ST MARYS HOSPITAL*
- b.) Service ID (Figure 2-11, item 2) is issued by the Service organization.
Example: 262785CT2 (no spaces)
- c.) Select the Time Zone for the site.

Note:

Use the scrollbar at the bottom of the time-zone selection list to view the entire description of the time-zone you are about to select, to ensure that you are selecting the correct time-zone for your location.

If the time-zone of your location is not in the list above, select one of the universal times in the selection menu. In this case, automatic changes for daylight savings time will not take effect. See Load from Cold manual, if you require more information regarding time-zone setting & selection.

- d.) Next MOD # *Customer selected.*
 - e.) Next Patient Exam # configures the next Exam number the scan user interface will use. At initial system installation, type: 1
 - f.) Next Diagnostic Exam # *Customer Selected.*
 - g.) Regenerate Database
 - h.) Mobile System Select to tell the software if this CT is in a mobile environment or not.
- 5.) Select the PREFERENCES button to display the Preference Settings Screen as shown in Figure 2-12.
- 6.) Regenerate Database (refer to Figure 2-12) determines whether the Scan Database will be regenerated during reconfiguration. You should select NO.

Note:

If YES is selected, then all scan data will be deleted on the Scan Data Disk. To avoid accidental regen, NO is selected by default each time reconfig is run. Regenerating the Scan Database destroys all the scan and calibration files on the Scan Data Disk. Make sure that all images have been reconstructed before regenerating the Scan Database.

This procedure is normally only needed when a Scan Data Disk is replaced or reformatted. See Load from Cold manual, if you require more information regarding Scan Database Regeneration.




Figure 2-12 Preferences Setup Screen

7.) Configure Preferences Settings

- a.) **Doctors Title** Enter the title for the Doctor. (eg. radiologist)
- b.) **Units for Patient Weight** Tells the software whether pounds or kilograms are being used.
- c.) **Language** configures the language to be displayed on the Application screens (ENGLISH, FRENCH, GERMAN, ITALIAN, PORTUGUESE, SPANISH).
- d.) **Preferred Fast Cal KV** configures the preferred kV that the Fast Cal Routine will calibrate (80, 100, 120, 140 in the Selected Preferred Fast Cal KV field). The default selections are 120 and 140.
- e.) **Date Format** configure the format in which the date will be displayed on the images.
- f.) **Time Format** configure the format in which the time will be displayed on the images
- g.) Select the site preferred **Dose Information Display** option for the site to use in monitoring calculated Patient Dose:
 - * Select ON (full CTDiw Display)
 - * Select ON WITHOUT TOTAL DLP (no Dose Length Product Display), or
 - * Select OFF (no CTDiw Display)
- h.) **Dose Information Display** selects

Comment:

These kVs should include all kVs that the site uses for patient scanning. Deselecting All Preferred FastCal KVs is the same as selecting ALL the Preferred FastCal KVs

- 8.) Select the **HARDWARE** button to display the Hardware Settings Screen (Figure 2-13).




Figure 2-13 Hardware Settings Screen (example only - actual screen may vary)

- 9.) Configure Hardware Settings
- a.) DAS Type configures which DAS the software should expect.
 - b.) Tube Type configures which X-Ray Tube the software should expect.
 - c.) PDU Type configures which PDU the software should expect.
 - d.) Collimator/Filter Type configures which Collimator/Filter the software should expect. Presently, LightSpeed 5.X systems only support HELIOS G1.
 - e.) Select Network Image Printer only if the site plans to use a network connected Postscript printer (such as Codonics printers) with this system.

Note: A "PRINT SERVER" IS NOT SUPPORTED (i.e., a computer with a printer attached); a Network Image Printer (which is supported) is a printer attached directly to the network.

- Comment:*
- f.) Camera Setup:
Camera Setup is not performed using Reconfig, but rather is performed from the Service Desktop once Applications have been started. See "DICOM Filming Devices Setup" on page 95.
 - g.) Scan Recon Hardware Configuration selects whether the O2 is present.
 - h.) Gantry Type selects the type of Gantry connected to this console

- 10.) Select the **NETWORK** button to display the Network Settings Screen as shown in [Figure 2-14](#).

Figure 2-14 Network Settings Screen

- 11.) Configure Network Settings

Comment:

This screen provides the ability to declare the CT system on a hospital network. Key information such as Host Name, IP Address, Net Mask (for CT systems on a subnet) must be obtained from the hospital network administrator.

See Chapter 4 for more information and complete details of setting the Hospital/System Network Configuration.

- a.) Enter the Suite Name.

The Suite Name must start with a letter, followed by three alphanumeric characters. Total must be four characters long. The name of the OC interface will be <Suite Name>, within the scanner's subnet.

Typically, you should use su01 or ct01 ("su" and "ct" must be lowercase), unless the customer prefers a different suite name.

- b.) Enter the hospital provided Host Name.

The Host Name identifies the network hostname and AE Title of the CT system to the hospital's network. The Host Name:

- * **MUST NOT** exceed 16 Characters.
- * **MUST** only contain the following characters: A through Z, a through z, 0 through 9, - and _.

Comment:

The Host Name is typically stmary or ct01.

- c.) Enter the hospital provided IP Address for the system.

- d.) Enter the hospital provided Net Mask (if the CT system is on a subnet).

- e.) Enter the Broadcast Address.

Comment:

The Broadcast Address should be the same as the IP Address except for the bits of the host id portion (last digit group) set to 1's or 0's depending on the configuration of the network. The standard default is 1's, but older Sun OS machines used 0's.

For example:

If the IP Address is 192.100.9.17, the Broadcast Address should be 192.100.9.255 if the network is configured to use 1's to specify the Broadcast Address.

If the network contains genesis based scanners or other Sun OS 3.5 or 4.1 computers, the Broadcast Address should be 192.100.9.0.

- f.) Enter the hospital provided Default Gateway IP Address in the `Default Gateway` field (if applicable). If the site network does not use a default gateway, leave the field blank.
- g.) Select NIS (a.k.a. Yellow Pages database) `Advanced Option`—only if requested by the hospital network administrator—as follows:
 - * Select ADVANCED OPTIONS button on the Network Settings Screen.
 - * Select USE NIS button.
 - * Enter the hospital provided `Domain Name` (from the hospital network administrator).
 - * Review all pages to be sure the information entered is correct before proceeding to the next step.

- 12.) Select ACCEPT on the System Configuration Screen.

Comment:

The system loads the CT Application Software, OS patches, kernel changes and configures the system on the OC.

The loading process takes approximately 15 minutes. While the load is going on, the results are displayed in a shell window that closes when the loading process is complete. All the window output is logged to a file named:_____

- 13.) When the loading process and configuration changes are complete, the system displays a prompt to reboot. Click on YES. (See [Figure 2-15](#).)



Figure 2-15 Reboot Screen

- 14.) The system will automatically login as `ctuser` after the reboot. Select OK on the Autostart Disabled popup message.

2.10 Applications Start-Up

Open the Console shell window, and type: `st` ENTER. The applications desktop appears on the monitor.

2.11 GRE Console Boot-up Flow Chart




Figure 2-16 GRE Console Boot-up Flow Chart

Section 3.0 Table Gantry Integration

3.1 Introduction

Use these procedures to functionally check every part of the table/gantry subsystem.




Figure 2-17 Table Gantry Integration Process Overview

Required Tool


- Multimeter

3.2 Check Alignment Lights

3.2.1 Room Light Adjustment

Adjust the scan room lights to normal customer operating levels.

3.2.2 Turning the Alignment Lights ON



CAUTION Verify all personnel have cleared the system. The Gantry rotates during this check.

- 1.) Turn ON the AXIAL DRIVE ENABLE and HVDC ENABLE switches (located on the service switch panel).
- 2.) Turn on the alignment light switch on the gantry service panel. The gantry will rotate and the alignment lights will turn ON.



CAUTION LASER EYE INJURY!

NEVER STARE DIRECTLY INTO THE LASER BEAMS WHEN YOU OPERATE THE ALIGNMENT LIGHTS. STARING INTO THE BEAMS CAN CAUSE PERMANENT EYE DAMAGE.

3.2.3 Internal Axial Lights

- 1.) Place a sheet of plain white paper over the output port of each light.
- 2.) Verify that the two laser lines coincide and appear as a single line.

Note: GE designed the internal axial lasers on the current CT system to shine *down* on the collimator. Do NOT adjust the internal alignment lights at this time. The tomographic plane tests use the QA phantom to check the internal axial lasers alignment to the collimator.

3.2.4 External Axial to Internal Axial Distance

Note: Ensure that cradle is level.

- 1.) Raise the table to its highest elevation.
- 2.) Extend the cradle until you see both the internal and external laser lights shining on the cradle.
- 3.) Place a metric rule on the right edge of the cradle, and measure the distance from the internal axial laser line to the external axial line. Verify this distance equals 240.0 mm +1.0 mm.
- 4.) Place the rule on the left edge of the cradle, and measure again.
- 5.) Leave the cradle in its current position, and lower the table to the minimum elevation.
- 6.) Measure the distance between the internal and external lights on both edges of the cradle, as above. Verify the distance remains equal to 240.0 mm +1.0 mm.

3.2.5 Coronal Lights

- 1.) Place a sheet of plain white paper at the left side of the patient opening, in front of the coronal laser light. Verify the two coronal lines coincide.
- 2.) Move the paper to the right side of the patient opening. Verify the two coronal lines coincide.
- 3.) Place the paper in the center of the gantry opening. Use a level to verify that the coronal lines are horizontal.

3.2.6 Turn Lights OFF

Press the alignment light button on the gantry control panel, again, to turn the lights OFF.

3.3 Autovoice/Intercom Check




Figure 2-18 SCIM Volume Controls

3.3.1 Requirements

Two people are required to complete this procedure.

3.3.2 Patient Speaker

- 1.) To adjust the volume of the patient speaker in the table, adjust the left-most volume thumb wheel on the SCIM while speaking into the console microphone. (Press the bar on the SCIM to talk; release the bar to listen.)
- 2.) The patient should be able to clearly hear the operator.

3.3.3 Operator Console Speaker

To adjust the console speaker volume:

- 1.) Have an assistant speak into the gantry microphone.
- 2.) Adjust the SCIM console volume knob until you can clearly hear the patient.

3.3.4 Autovoice Volume

- 1.) On the Scan Desktop, select PROTOCOL MANAGEMENT.
- 2.) Select AUTO VOICE RECORD.
- 3.) Click the 3.4 button, to the right of "FF2. Inspiration".
- 4.) Click the PLAY button, to play the Inspiration AutoVoice message.
- 5.) Adjust the center volume thumb wheel while Autovoice is playing, to set the volume for the gantry speaker.
- 6.) Repeat steps 4 and 5 as necessary to achieve satisfactory volume.
- 7.) Select DONE, then select QUIT.

Note: If a satisfactory volume can not be achieved, refer to the system service manual and review the intercom module setup procedure.

3.4 CT System X-Ray ON Indicators, Cautions & Warning Labels

3.4.1 Check And Install System Warning Labels

All labels are installed in English and present on PDU, Console, Table, Gantry and Accessories. Replace the labels listed below ([Section 3.4.2](#) through [Section 3.4.7](#)) with the appropriate language labels for the country installed. Additionally, apply any other warning labels if present, on equipment where appropriate.

3.4.2 Console

3.4.2.1 On The SCIM

- Replace with the appropriate language overlay
- Replace with the appropriate language X-Ray warning label

3.4.2.2 On The Keyboard

- Replace with the appropriate language keyboard warning label
- Replace with appropriate language function key overlay label
- Replace with the appropriate language keyboard back warning label

3.4.3 Gantry

3.4.3.1 Scan Window Laser Labels

Replace with the appropriate language laser warning labels

3.4.3.2 Laser Window Labels

Replace with the appropriate language laser warning labels

3.4.3.3 Front Cover Laser Warning

Replace with the appropriate language laser warning labels

3.4.3.4 Front cover Information Labels

Replace with the appropriate language labels

3.4.3.5 Gantry System GIB (Rating) label

Replace with the appropriate language system GIB label

3.4.4 Table - 2000mm

3.4.4.1 Front Side Cover - Pinch Hazard Warning Label

Replace with the appropriate language caution label to each side of the cover

3.4.4.2 Back Cradle Pan - Pinch Hazard Warning Label

Replace with the appropriate language caution label to each side of the cover

3.4.5 Table - 1700mm

3.4.5.1 Front Side Cover - Pinch Hazard Warning Label

Replace with the appropriate language caution label to each side of the cover

3.4.5.2 Rear Side Cover - Pinch Hazard Warning Label

Replace with the appropriate language caution label to each side of the cover

3.4.5.3 Back Cradle Pan - Pinch Hazard Warning Label

Replace with the appropriate language caution label to each side of the cover

3.4.6 NGPDU

3.4.6.1 Front Cover - Emergency Off label

Replace with the appropriate language caution label

3.4.6.2 Front Cover - Gantry Enable Label

Replace with the appropriate language caution label

3.4.6.3 Front Cover - Power On Label

Replace with the appropriate language caution label

3.4.7 Accessories

3.4.7.1 Table Foot Extender Label

Replace with the appropriate language warning label

3.4.7.2 Coronal Head Holder Label

Replace with the appropriate language warning label

3.4.7.3 Sagittal Head Holder Label

Replace with the appropriate language warning label

3.4.7.4 Accessory Tray Label

Replace with the appropriate language warning label

3.4.7.5 IV Pole Label

Replace with the appropriate language caution label

3.4.8 Documentation - Verification

When finished update GE4879 (US Only) and the mechanical installation completion form that all appropriate language labels were installed and present.

3.5 Check Warning Labels

3.5.1 On SCIM

- 1.) Make sure the X-Ray warning label appears in the correct location on the SCIM.
- 2.) Record this information on Form 4879 located in [GE Form 4879 Installation Data Verification on page 127](#).

3.5.2 On Gantry

- 1.) Check that all laser warning labels are present on the gantry near the laser opening.
- 2.) There should also be warning labels on the lower right side of the gantry front cover.
- 3.) Record this information on Form 4879 located in [GE Form 4879 Installation Data Verification on page 127](#).

3.5.3 On Laser

- 1.) Make sure all laser warning labels appear in the correct location on the outside of the gantry.
- 2.) Obtain and install replacements for any missing labels.



Figure 2-19 Laser Warnings and Precautions

3.6 Process Product Locator Cards

- 1.) Collect the product locator cards shipped with the system. There should be approximately 28 product locator cards with the average system.
- 2.) Update the online product locator web site with the required hospital information.
- 3.) Confirm that the serial numbers on the cards shipped with the system match those found on the web site for that GON number.
- 4.) Update as required. Place the cards in a plastic bag, then place them in the service cabinet.

3.7 Install Service Cabinet

The service cabinet is shipped disassembled. The cabinet assembly process takes about 1.5 hours to complete.

- 1.) Assemble the cabinet following the instructions located in the cabinet's shipping box.
- 2.) When completed, place the cabinet in the location shown on the site print.
- 3.) Place all of the service materials shipped with the system in the service cabinet.

3.8 Check X-Ray Lights

Perform several scans following the steps below. Verify that the X-ray ON lights are ON during the scans. When done, check the boxes in [Table 2-2](#).

- 1.) Make sure the axial drive enable and HVDC enable switches are ON.
- 2.) If you are not on the Service Desktop, click on the Service Desktop icon.
- 3.) Select DIAGNOSTICS.
- 4.) Select DIAGNOSTIC DATA COLLECTION.
- 5.) Set the scan time to 2.00.
- 6.) Set the kV to 80.
- 7.) Set the mA to 40.
- 8.) Press ACCEPT RX.
- 9.) Press START SCAN button when flashing.
- 10.) Record the above information on Form 4879 located in [GE Form 4879 Installation Data Verification on page 127](#).

Light On?	Warning Light Locations
☐	SCIM
☐	Gantry Front
☐	Gantry Back (Use a mirror to view)
☐	Room Light (outside of the room)

Table 2-2 X-ray Light Chart

3.9 Mechanical Characterization

The relationship of table height to ISO center and internal-to-external landmarks must be characterized for proper interference matrix functionality.

Note: Do NOT perform tilt characterization.

3.9.1 Alignment Light Characterization

- 1.) Start the Mechanical Characterization tool from the Calibration tab on the Common Service Desktop.
- 2.) Select the CHARACTERIZE ALIGNMENT LIGHTS button from the interface.
- 3.) Follow the on-screen instructions.

3.9.2 Alignment Light Characterization

- 1.) Select the CHARACTERIZE TABLE HEIGHT button from the interface.
- 2.) Follow the on-screen instructions.

Note: If the table height is less than 21mm or greater than 25mm, relative to ISO, you must adjust the table height using the table leveling pad and adjusters. Raise or lower all four adjusters equally to achieve desired results.

3.10 Interference Test

PREREQUISITES

- Be sure that the System State was restored from **DVD** per Section 2.0.
- Reset the hardware to download the new characterization values before performing the table/

gantry interference tests in this section.

CONFIGURATION

- 1.) Table flashed with latest SW
- 2.) Table must have elevation and cradle characterized
- 3.) Table must be mechanically aligned to gantry
- 4.) Table must have had the table-gantry characterization completed
- 5.) Verify the Table extender is installed.

TEST OUTLINE

The following tests verify the proper tilt and table interference matrix on the H-Power gantry.

- [Verify Table Elevation - All Systems – Section 3.10.1](#)
- [Position Tilt, Move Table to Interference Limit – Section 3.10.2.1](#)
- [Position Table, Move Tilt to Interference Limit – Section 3.10.2.2](#)
- [Tilt Limits When Table Below Scan Plane Lower Limit – Section 3.10.2.3](#)

REQUIREMENTS

The following requirements are tested in this series of tests.

- 1.) No motion shall cause the table to hit the gantry (or gantry to hit the table)
- 2.) Requirement #1 shall include the use of the table extender.
- 3.) No tilt motion shall cause the gantry tilting frame to touch the stationary base covers for any tilt angle.

LIMITATIONS

These requirements will only be met when the table is NOT in service mode.

INTERPRETING TEST RESULTS

If test results indicate that elevation and/or tilt display readings fail to meet specifications, DO NOT adjust the limit switches. Instead, re-characterize and/or adjust tilt speed. Refer to Appendix C. Perform elevation and cradle first, then repeat the test. If it still fails, perform tilt.

3.10.1 Verify Table Elevation - All Systems

#	TEST	EXPECTED RESULTS
3.10.1-1	Move the cradle to home position. Push the table down gantry push-button to lower the table to the minimum height.	Elevation Display should read 500.0 ± 3 mm
3.10.1-2	Push the table up gantry push button to raise the table to the maximum height. If the mechanical alignment of the table/gantry is not correct, as is often the case during manufacturing staging, this value may be out of range. Most of the following tests will still be valid: Those that might have some variation are indicated in bold type .	Elevation Display should read 25.0 ± 3 mm. If mechanical alignment of the table/gantry is not correct, this value can be as low as 0 mm and as high as 40 mm.

Table 2-3 Table Elevation Tests

3.10.2 Tests for Pro16, LS16, Ultra & Plus Systems

3.10.2.1 Position Tilt, Move Table to Interference Limit

The following tests verify the table interference limits at different tilt locations.

- Note:
- “I” means top of gantry tilts toward the table base
 - “S” means top of gantry tilts away from the table base.

Important: For all tests, make sure there is 2.5 cm of clearance between the gantry and table. Also make sure that the Gantry Tilting frame covers do not touch the stationary base covers, for all tilt angles used in this test.

#	TEST	EXPECTED RESULTS
3.10.2.1 -1	Move cradle to home position and set internal landmark.	Cradle position on display should read 0.0
3.10.2.1 -2	Raise table height to maximum height, set the internal landmark, move cradle into gantry 1m.	Table elevation on display should read $25.0 \pm 3\text{mm}$. (This value will be the same as in 3.10.1-2 above.) Cradle position on display should read 1000.0 mm.
3.10.2.1 -3	Tilt the gantry to I30.0, then lower table until motion stops.	Table elevation on display should read $100 \pm 3\text{mm}$. Tilt display should read I30.
3.10.2.1 -4	Tilt the gantry to I23.0, then lower table until motion stops.	Table elevation on display should read $155 \pm 3\text{mm}$. Tilt display should read I23.
3.10.2.1 -5	Tilt the gantry to I20.0, then lower table until motion stops.	Table elevation on display should read $170 \pm 3\text{mm}$. Tilt display should read I20.
3.10.2.1 -6	Raise the table elevation to maximum height.	Table elevation on display should read $25.0 \pm 3\text{mm}$. (This value will be the same as in 3.10.1-2 above.)
3.10.2.1 -7	Tilt the gantry to S30.0, then lower table until motion stops.	Table elevation on display should read $156 \pm 3\text{mm}$. Tilt display should read S30.
3.10.2.1 -8	Tilt the gantry to S23.0, then lower table until motion stops.	Table elevation on display should read $182 \pm 3\text{mm}$. Tilt display should read S23.
3.10.2.1 -9	Tilt the gantry to S20.0, then lower table until motion stops.	Table elevation on display should read $192 \pm 3\text{mm}$. Tilt display should read S20.
3.10.2.1 -10	Raise the table to 154 mm.	Table elevation on display should read 154mm.
3.10.2.1 -11	Tilt gantry to S30 and verify the table height can be adjusted from 154 to 25 mm. (This value will be the same as in 3.10.1-2 above.)	Tilt display should read S30. Table lower limit should be $154 \pm 3\text{mm}$. Upper table limit should be $25 \pm 3\text{mm}$. (This value will be the same as in 3.10.1-2 above.)
3.10.2.1 -12	Set the table height to 98 mm.	Table elevation on display should read 98mm.
3.10.2.1 -13	Tilt gantry to I30 and verify the table height can be adjusted from 98 to 25 mm. (This value will be the same as in 3.10.1-2 above.)	Tilt display should read I30. Table lower limit should be $98 \pm 3\text{mm}$. Upper table limit should be $25 \pm 3\text{mm}$. (This value will be the same as in 3.10.1-2 above.)

Table 2-4 Position Tilt, Move Table to Interference Limit Tests (Pro16, LS16, Ultra & Plus)

3.10.2.2 Position Table, Move Tilt to Interference Limit

The following tests verify the tilt interference limits at different table heights.

- Note:
- “I” means top of gantry tilts toward the table base
 - “S” means top of gantry tilts away from the table base.

Important: For all tests, make sure there is 2.5 cm of clearance between the gantry and table.

#	TEST	EXPECTED RESULTS
3.10.2.2-1	Move cradle to home position and set internal landmark. Set gantry tilt to zero.	Cradle position on display should read 0.0. Gantry tilt on display should read 0.0.
3.10.2.2-2	Raise table height to maximum height, set the internal landmark, move cradle into gantry 1m.	Table elevation on display should read 25.0 ± 3mm. (This value will be the same as in 3.10.1-2 above.) Cradle position on display should read 1000.0 mm.
3.10.2.2-3	Lower table until height is 115mm. Tilt the gantry top away from the table (“S”) until it stops.	Table elevation on display should read 115 mm. Tilt display should read S30 ±0.5°.
3.10.2.2-4	Tilt the gantry top toward the table (“I”) until it stops.	Table elevation on display should read 115 mm. Tilt display should read I28 ±0.5°.
3.10.2.2-5	Tilt the gantry to 0. Lower table until height is 200mm. Tilt the gantry top away from the table (“S”) until it stops.	Table elevation on display should read 200 mm. Tilt display should read S17 ±0.5°.
3.10.2.2-6	Tilt the gantry top toward the table (“I”) until it stops.	Table elevation on display should read 200 mm. Tilt display should read I14.5 ±0.5°.
3.10.2.2-7	Tilt the gantry to 0. Lower table until height is 210 mm. Tilt the gantry top away from the table (“S”) until it stops.	Table elevation on display should read 210 mm. Tilt display should read S13.5 ±0.5°.
3.10.2.2-8	Tilt the gantry top toward the table (“I”) until it stops.	Table elevation on display should read 210 mm. Tilt display should read I12 ±0.5°.

Table 2-5 Position Table, Move Tilt to Interference Limit Tests (Pro16, LS16, Ultra & Plus)

3.10.2.3 Tilt Limits When Table Below Scan Plane Lower Limit

The following tests verify the table and tilt interference limits when the table height is below the scan plane.

- Note:
- “I” means top of gantry tilts toward the table base
 - “S” means top of gantry tilts away from the table base.

Important: For all tests, make sure there is 2.5 cm of clearance between the gantry and table.

#	TEST	EXPECTED RESULTS
3.10.2.3-1	Set gantry tilt to zero. Move cradle to home position, lower the table all the way, and set the internal landmark.	Cradle position on display should read 0.0. Gantry tilt on display should read 0.0. Table height should read 500 ± 3 mm. (This value will be the offset from 500 mm by the same amount as the upper table limit varies from 25 mm in 3.10.1-2 above.)
3.10.2.3-2	Tilt the gantry forward and backwards and verify the following tilt limits: S4.0 and I30.	Gantry tilt on display should read S4.0 ± 0.5°. Gantry tilt on display should read I30.0 ± 0.5°.

Table 2-6 Tilt Limits When Table Below Scan Plane Lower Limit Tests (Pro16, LS16, Ultra & Plus)

#	TEST	EXPECTED RESULTS
3.10.2.3-3	Set Gantry tilt to 0. Then, using the gantry push-buttons, move the cradle in towards the gantry until it is stopped.	Gantry tilt on display should read 0.0. Cradle should stop at 58.5 mm $\pm$ 6 mm from the home position. (This value will not be valid if the table/gantry mechanical characterization is not correct as described in 3.10.1-2 above. Insure that the front of the table is at least 25 mm from the gantry.)
3.10.2.3-4	Set gantry tilt to zero. Move cradle to home position.	Cradle position on display should read 0.0 Gantry tilt on display should read 0.0.
3.10.2.3-5	Raise the table to a height of 386 mm and verify the following tilt limits: S7.0 and I30.0.	Table height should read 386 mm. Gantry tilt on display should read S7.0 $\pm$ 0.5°. Gantry tilt on display should read I30.0 $\pm$ 0.5°.
3.10.2.3-6	Set Gantry tilt to 0. Set the internal landmark. Then, using the gantry push-buttons, move the cradle in towards the gantry until it is stopped.	Gantry tilt on display should read 0.0. Cradle should stop at 91 mm $\pm$ 6 mm from the home position.
3.10.2.3-7	Set gantry tilt to zero. Move cradle to home position.	Cradle position on display should read 0.0. Gantry tilt on display should read 0.0.
3.10.2.3-8	Raise the table to a height of 242 mm and verify the following tilt limits: S12.0 and I30.0.	Table height should read 242 mm. Gantry tilt on display should read S12.0 $\pm$ 0.5°. Gantry tilt on display should read I30.0 $\pm$ 0.5°.
3.10.2.3-9	Set Gantry tilt to 0. Raise the table to 210 mm. Then, using the gantry push-buttons, move the cradle in towards the gantry until it is stopped.	Gantry tilt on display should read 0.0. Cradle should go all the way through the gantry bore to the full-extended position.
3.10.2.3-10	Set gantry tilt to zero. Move cradle to home position, lower the table all the way and set the internal landmark.	Cradle position on display should read 0.0 Gantry tilt on display should read 0.0. Table height should read 500 $\pm$ 3 mm. (This value will be the offset from 500 mm by the same amount as the upper table limit varies from 25 mm in 3.10.1-2 above.)
3.10.2.3-11	Tilt the gantry top toward the table to a tilt of 30 degrees	Display should read I30.
3.10.2.3-12	With the table down all the way, move the cradle in until it stops.	Cradle position should be 377.3 $\pm$ 3 mm.
3.10.2.3-13	Move the table to the home position, raise the table to a height of 386 mm, set the internal landmark, and then move the cradle in until it stops.	Cradle position should be 350 $\pm$ 50 mm.
3.10.2.3-14	Raise the table to a height of 100 mm, then move the cradle in.	Cradle should go all the way through the gantry bore to the full-extended position.

Table 2-6 Tilt Limits When Table Below Scan Plane Lower Limit Tests (Pro16, LS16, Ultra & Plus)

3.10.3 Alignment Light Characterization - All Systems

3.10.3.1 Overview

The "Characterize Alignment Lights" is part of the Mechanical Characterization tool available under the Calibration tab on the Common Service Desktop. This tool gives the ability to characterize the distance between the internal and external laser alignment lights. Typically this is used to

characterize the distance from the gantry external laser lights to the internal laser lights, which is typically 240mm. For some systems, the customer will supply a set of wall mount laser alignment lights that can provide an external alignment location up to 650mm from the gantry internal laser alignment lights. In this instance the gantry external laser lights are physically disconnected and not used and the characterization is performed from the customer supplied alignment lights to the gantry internal lasers.

3.10.3.2 Procedure

- 1.) Start the Mechanical Characterization tool from the Calibration tab on the Common Service Desktop.
- 2.) Select the “Characterize Alignment Lights” button from the interface.
- 3.) Follow the on-screen instructions.

Pay attention to the table height instructions that depend on what system you are characterizing.

Table height for Gantry laser characterization is different from the table height needed to characterize a customer supplied laser alignment system. This is due to the table travel distance needed to position the black alignment dot on the cradle at the customer alignment light and still drive into the bore without hitting the gantry.

Chapter 3

Image Quality



NOTICE
Potential for
Data Loss and/
or Equipment
Damage

To prevent potential data loss, please do the following:

- Record data collected from procedures in this chapter into Form F4879 when directed, located in [Chapter 6](#) of this book.
- Only use the Installation manual that arrives with your system for installation. Any other revisions of this manual may not exactly match your system.

Section 1.0

Introduction




Figure 3-1 System Test Overview

Section 2.0

Calibration Process

2.1 Reference Procedures

Do not perform these procedures ("[Scanning with Service Protocols](#)" or "[Center Phantom](#)") until instructed to do so in other sections of this chapter.

2.1.1 Scanning with Service Protocols

Locate the Manufacturing and Installation protocols under Infant area 20.

Note: **Manufacturing and Service share this Protocol list. Different product option offerings also use this list. Carefully follow the scan section instructions, and verify you acquired the images with the correct technique before filling out the data sheet. Otherwise you may troubleshoot an image problem that only exists because you used the wrong technique.**

- 1.) Select the NEW PATIENT icon on the left monitor
- 2.) Enter a Patient ID (e.g., **getest**).
- 3.) Click on the box labeled PEDIATRIC.
- 4.) Select a service protocol from the list, to display the corresponding view edit screen.
Optional Method: Enter the protocol number into the Protocol Number Field on the Exam Rx Screen.

2.1.2 Center Phantom

- 1.) Select SCANNER UTILITIES icon on the left monitor
- 2.) Select CENTER PHANTOM.
- 3.) Follow the on-screen procedures.
- 4.) The phantom center spec is ± 5 mm.
- 5.) Select QUIT, when the phantom is within specification.
- 6.) Level the phantom both front to back and side to side. (use a 6" level)

2.2 Prepare the QA Phantom

Note: **The QA phantom is shipped water filled.**

- 1.) Locate the multi-language sticker packet in the QA phantom shipping box.
- 2.) Attach the sticker with the customer's language to the face of the phantom hanger bracket.

2.3 Calibration Process Introduction

If your system has a factory supplied state MOD, you used it to load the system calibration files during the Restore System State ([Restore System State on page 31](#) of this manual).

Section 3.0

Table/Gantry Alignment Procedure

3.1 Conditions

This procedure may require the removal of the table bottom, side and rail covers.

This procedure requires that mechanical final alignment was completed and passed.

3.2 Procedure

- 1.) If this is a Non-Fixed Site, check the Van level. Correct, if necessary.
- 2.) Check Table level. Correct, if necessary.
- 3.) Drive the table to its highest elevation (phantom holder removed).
- 4.) Drive the table cradle in and out five times to seat the rollers.
- 5.) Turn on the alignment lights. Check the scan window for proper installation.
- 6.) Advance the end of the cradle (black dot on cradle) to the internal light.
- 7.) Complete [Section 2.1.1, "Scanning with Service Protocols"](#) now.
- 8.) Select the service protocol PERPENDICULAR ALIGNMENT. Protocol should appear as shown in [Table 3-1](#).

Scan Type	Direction	kV	mA	SFOV	Thickness	Scan Time	Start Loc.	End Loc.	Algorithm
Axial	Head First	120	40	Large	5mm/1i	2sec	S0	S0	Bone
Axial	Head First	120	40	Large	5mm/1i	2sec	I1000	I1000	Bone
Scout		120	40			90°	S0	I1000	
Scout		120	40			0°	S0	I1000	

Table 3-1 Perpendicular Alignment Scan Parameters

Set Internal Landmark. The red boxes will disappear from the screen.

- 9.) Click on CONFIRM, then press the START SCAN button when lighted, to perform the scan.
- 10.) Use over/under multi-image display to view both images at the same time:
 - a.) Click on IMAGE WORKS
 - b.) Highlight the scans just performed and click on VIEWER.
 - c.) Click on FORMAT, and select the "over/under" view (two boxes aligned vertically).
- 11.) Use the upper image (cradle front) to verify that table is centered:
 - a.) Click on the "grid" icon.
 - b.) Click on MEASURE, and select the straight (angled) line.
 - c.) Using the mouse, position one end of the line on the vertical axis.
 - d.) Position the other end at one outside edge of the cradle, forming a perfectly horizontal line (angle = 90). Read the distance displayed on screen.
 - e.) Repeat step d to measure the distance from the vertical axis to the other edge.
- 12.) Repeat step 11 for the lower image (cradle at 1000 mm).

- 13.) If the edges are off by greater than 1 mm (front to back), perform the following:
 - a.) Loosen the table anchors at locations #5, #6 and #7.
 - b.) Move the table half the measured distance.
 - c.) Return to Step 8. Repeat the procedure until the table edges line up (± 1 mm). If needed a scout can be completed to check table horizontal presentation
Check the two scout scans
 - i.) Check the tube at zero scan for table gantry perpendicularity. Make table adjustments as needed
 - ii.) Check the tube at 90 scan for cradle level and visual irregularity with the white side molding. Molding strips should be parallel within ± 3 mm. Cradle should be level within ± 3 mm.
 - d.) Tighten the anchors and torque to 74.6 N-m (55 ft.-lb.) for fixed sites only. (75 ft.-lb.) for non-fixed systems.
 - e.) Reinstall all table parts removed to access the anchors, including covers, ground straps, elevation motor leads and the center support bar.
- 14.) Install all table and gantry covers.
- 15.) Use ERASE ALL to remove lines and grids from the images.
- 16.) Click on END EXAM to exit the program.

Section 4.0

Tube Warm Up and Fast Cal



- 1.) Select  to warm up the tube.
- 2.) Select FAST CALIBRATION from the Daily Prep menu.

Note: **Use the default Fast Cal selections determined by the system configuration. (The system defaults to all four kV stations, but you can choose kV stations to calibrate during reconfig.)**

- 3.) Run the selected air calibrations.
- 4.) When the calibration process completes, click on QUIT.

Section 5.0

Tomographic Plane Indication

- 1.) Place the QA phantom on the phantom holder.
- 2.) Center the Phantom (refer to procedure [2.1.2 on page 58](#))
- 3.) Turn ON the internal alignment lights, and drive the phantom into the gantry opening, until the line on the phantom lines up with the internal laser lights.
- 4.) Verify that BOTH internal axial lasers line up along the line on the QA phantom. If not, check table/gantry, cradle, and/or laser alignment.
- 5.) Center the phantom in the scan plane with the calibration program. (See [2.1.2 on page 58](#) for details on the phantom centering procedure.)
- 6.) Select the service protocol TOMO PLANE INDICATION. (See [2.1.1 on page 58](#) for details on scanning with service protocols.)

or

Manually select the scan parameters in [Table 3-2](#).

Scan Type	kV	mA	SFOV	Thickness	Scan Time	Start Loc.	End Loc.	Algorithm	Interval
Helical	120	200	Small	1.25HQ	1.0sec	I3.0	S3.0	Bone detail	0.2

Table 3-2 Tomographic Plane Indication Scan Parameters

- 7.) Display the image series, and locate the scan plane indicator, the longest bar in the bar pattern on the right side of the phantom. The right side of the phantom corresponds to the side of the image labeled **L** on the display screen.
- 8.) On the HHS Data Sheet, record the scan location (shown on the image annotation) of the image with the darkest scan plane indicator (darkest long bar).
- 9.) If your system meets all the installation and alignment specifications, the image at scan location zero (S0.0) should contain the scan plane indicator. If scan location S1.0 or scan location I1.0 has the darkest bar, the system still meets the specification. The scan plane deviation should equal $S0.0 \pm 1.0\text{mm}$. If necessary, adjust the internal alignment light position to meet the $S0.0 \pm 1.0\text{mm}$ requirement.
- 10.) Repeat the Tomographic Plane Indication test with the external alignment lights.
 - a.) Use the external alignment light, and press the external landmark.
 - b.) Verify the external light lines up along the black line on BOTH the left and right sides of the QA phantom.
 - c.) The scan plane indication must fall within the $S0.0 \pm 1.0\text{mm}$ specification.
- 11.) Initial below.

Section 6.0

Image Series

IMPORTANT: Run ALL Image Series Tests in Auto Mode. Manual procedures are provided in this section as REFERENCE ONLY.

6.1 Scan Protocol

The person who acquires the image series has the responsibility to review the images and verify they meet the specifications listed on data sheets. Responsibilities also include means and standard deviation measurements and keeping a record of failures that occur during the image series.

Unless otherwise stated, use the following scan parameters during the image series acquisition:

- Scan FOV equal to display FOV (Field of View)
- 512x512 matrix size

Note: **Consider any image series scan that does not meet specifications as failing.**

For means and standard deviations, 90% of the slices must pass. Any failure on a particular technique requires at least ten additional slices to evaluate effectively.

Systems with metal-free cradles have a phantom holder with a perpendicular adjustment (Z-axis) knob on it. **Each time you change phantoms**, make sure you use a bubble level, and the Z-axis knob on the phantom holder, to level the phantom.

6.2 Data Recording: Means and Standard Deviation

Any failure on a particular technique requires at least a ten additional slices to evaluate effectively. For means and standard deviations, 90% of the slices must pass.

- Record means to two decimal places, and round to the nearest one-tenth, (one decimal place) when you compare the resulting values to the spec.
- Record standard deviations to two decimal places, then round off to one decimal place, to compare it to the spec.
- Average standard deviations: Use two decimal places to average the values, then round off to one place.

Before you record the means and standard deviations, check the image data sheets to determine whether to average the means and standard deviations, or record them slice by slice. Make sure you record all the required image data on the HHS data sheets.

6.3 Term Definitions and Screens

Xc - Mean CT number for the specified center coordinates of the phantom image.

AvXc - Average Mean CT number for the center of the phantom image: Average the mean CT value for all specified center coordinates of all slices in an exam.

Xo - Mean CT number for the outside of the phantom image: Average the mean CT value for all specified outside coordinates of one slice.

AvXo - Average outside mean CT number for the number of slices in an exam.

AvSDc - Average image noise about the center image coordinate (measured as the standard deviation) of all slices in an exam.

AvSDo - Average image noise (standard deviation) for the outside of a phantom: Average of all outside coordinates of all the slices in an exam.




Figure 3-2 Image Analysis Tool User Interface - Auto 1x Test Pull Down Menu




Figure 3-3 Image Analysis Tool User Interface - Test Results Report Window

6.4 48cm Phantom Image Series Image Performance Verification

6.4.1 Acquiring the 48cm Phantom Image Series

- 1.) Mount the Phantom Holder on the head-end of the table.
- 2.) Mount the 48cm Phantom on the Phantom Holder.
- 3.) Align, level, & center the 48cm Phantom.
 - Align phantom using the internal laser lights.
 - Level phantom using bubble level and the Z Axis knob on the Phantom Holder.
 - Center phantom using the CENTER PHANTOM procedure in the left head SCANNER UTILITIES selection and the X and Y Axis knobs on the Phantom Holder.
- 4.) Set up the system to scan a single, 64 image, 48cm Phantom series.

MANUAL SCAN PROTOCOL SETUP

Refer to [Table 3-3 \(Pro 16\)](#) or [Table 3-4 \(LS 16, Ultra, Plus\)](#) to manually set-up an Axial scan with the parameters shown.

Note: These parameters may differ from those found using the “Auto Scan Protocol Setup” below.

Series Description	Scan Type	Start Loc.	End Loc.	Total # of Images	Thick Speed	Interval (mm)	Gantry Tilt	SFOV	kV	mA	Total Exposure Time	DFOV (cm)	Recon Type
48 16x1.25/120kV /400mA/2s	Axial Full 2.0 sec	I9.375	S9.375	64	1.2516i	0.00	S0.0	Large	120	600	8.0 sec.	50.0	Std

Table 3-3 48cm Phantom Image Series Scan Parameters (Pro 16)

System	Series Description	Scan Type	Start Loc.	End Loc.	Total # of Images	Thick Speed	Interval (mm)	Gantry Tilt	SFOV	kV	mA	Total Exposure Time	DFOV (cm)	Recon Type
16 Slice	48 16x1.25/120kV /400mA/2s	Axial Full 2.0 sec	I9.375	S9.375	64	1.2516i	0.00	S0.0	Large	120	400	8.0 sec.	50.0	Std
4/8 Slice	48 Lg Series 1	Axial Full 1.0 sec.	I7.50	S7.50	16	5.0 4i	0.00	S0.0	Large	120	340	4.0 sec.	50.0	Std

Table 3-4 48cm Phantom Image Series Scan Parameters (LS 16, Ultra, Plus)

AUTO SCAN PROTOCOL SETUP

- a.) On the Exam Rx desktop, select NEW PATIENT.
- b.) Type the following entries in the two listed Patient Information fields:
 - * Patient ID: **Service**
 - * Name: **48cm Phantom Image Series**
- c.) From the Protocol Selection display, click on the Service Tab under Anatomical Selector.
- d.) On the Service Protocol Selection window, click on MANUFACTURING.
- e.) On the Service Category Protocol List, click on IMGSER 48CM MDAS_16_16.
- f.) **Pro 16:**
On the ExamRx protocol parameter display, skip to the 3rd Series.
(Series Description: 48 16x1.25/120kV/400mA/2s).
LS 16:
On the ExamRx protocol parameter display, skip to the 3rd Series.

(Series Description: 48 16x1.25/120kV/400mA/2s)

Ultra or Plus:

On the ExamRx protocol parameter display, skip to the 3rd Series.

(Series Description: 48 4x5.0/120kV/340mA/1s)

g.) Set internal Landmark.

5.) Acquire a single, 64 image, 4 scan, image series of the 48 cm Phantom.

6.4.2 Image Performance Verification

6.4.2.1 Series Means (AvXo-AvXc and AvSDc) & Center Smudge

1.) Launch the Image Analysis Tool.

a.) From the Global Control Palette, click on the Service Desktop.

b.) From the Service Desktop upper navigational bar, click on the IMAGE QUALITY icon.

c.) In the left navigational area directory, click on IMAGE ANALYSIS.

Note:

During the Image Analysis process, you will need to switch between the Service Browser screen (to select the image series to analyze) and the Image Analysis screen (to run a particular Auto 1x analysis test). Use ALT/F1 to bring a window to the front. Use ALT/F3 to send a window to the back.

2.) Using the AUTO 1X Tool on the Image Analysis screen, generate a Series Means and Center Smudge report for the 1st series of the 48cm Phantom acquisition.

a.) From the Service Browser window, select the 48cm Phantom series acquired in Section 6.4.1.

b.) On the Image Analysis Tool window, click on the AUTO 1X diamond shaped button. (See [Figure 3-2, on page 63.](#))

c.) Click on the AUTO 1X rectangular button, select the IMGSER 48CM test from the pull-down menu, slide cursor to the right and select 16X1.25/120KV/400MA/2S from the test pull-down menu, and continue to slide cursor to the right to select AUTO.

d.) Click on the ACCEPT button.

3.) Review the Image Analysis Report data and record the Series Means (AvXo-AvXc, and AvSDc) data and the Center Smudge data for each row in [Table 3-5 \(Pro 16, LS 16\)](#) or [Table 3-6 \(Ultra or Plus\)](#).

a.) Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS. (See [Figure 3-3, on page 63 \(Pro 16\)](#) or [Table 3-4 \(LS 16, Ultra, Plus\)](#).)

b.) Verify the scan parameter values displayed in the report match those in [Table 3-3 \(Pro 16\)](#) or [Table 3-4 \(LS 16, Ultra, Plus\)](#).

c.) Record the Series Means (AvXo-AvXc, and AvSDc) data and the Center Smudge data for each row in [Table 3-5 \(Pro 16, LS 16\)](#) or [Table 3-6 \(Ultra or Plus\)](#).

6.4.2.2 Band and Streak Artifact

1.) Review the 48cm Phantom images acquired in Section 6.4.1 for Bands and Streaks using the Image Works Desktop.

a.) From the Global Control Palette, click on the IMAGE WORKS Desktop.

b.) From the Image Works Browser window, select the 48cm Phantom series acquired in Section 6.4.1.

c.) From the Image Works Browser window, click on the VIEWER button.

d.) While paging through the 64 images in the series, analyze images for any Band or Streak artifacts. Adjust Window/Level using the center mouse button, as required.

e.) Note any image that appears to have a Band or Streak artifact.

- 2.) Verify any images noted above (step 1e) meet 48cm Phantom Band or Streak Image Performance requirements.
- From the Global Control Palette, click on the Service Desktop.
 - From the Service Browser window, select an image of the 48cm Phantom series acquired in Section 6.4.1 that appeared to have a Band or Streak while reviewing the series in Image Works.
 - On the Image Analysis Tool window, click on the AUTO 1X rectangular button, select the IMGSER 48CM test from the pull-down menu, slide cursor to the right and select 16X1.25/120KV/400MA/2S from the test pull-down menu, and continue to slide cursor to the right to select BAND or STREAK.
 - Click on the ACCEPT button.
- Note: If required, adjust Window/Level using the center mouse button.
- Position and size the Band or Streak ROI using the left cursor button.
- Note: To ensure specifications are properly applied, do not adjust the Reference ROI's for the Band and Streak artifact tests. The Reference ROI's are adjustable after the 1st Accept Modification click.
- Click on ACCEPT MODIFICATION twice, to generate a report.
 - Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS.
 - Repeat steps b through g, for each image noted in Step 1e.

Box Size = 1600 mm² to 2500 mm²
 45 mm (+/- 5 mm) x 45 mm (+/- 5 mm)
 45 (+/- 4 pixels) x 45 (+/- 4 pixels)

Box Positions: Box 1 = 0 mm x 0 mm
 Box 2 = 0 mm x -190 mm
 Box 3 = 190 mm x 0 mm
 Box 4 = 0 mm x 190 mm
 Box 5 = -190 mm x 0 mm

Row	Images	Brightness Uniformity (AvXo - AvXc)	Noise (AvSDo)	Center Smudge Row Values	Comments
8A	1, 17, 33, 49				
7A	2, 18, 34, 50				
6A	3, 19, 35, 51				
5A	4, 20, 36, 52				
4A	5, 21, 37, 53				
3A	6, 22, 38, 54				
2A	7, 23, 39, 55				
1A	8, 24, 40, 56				
1B	9, 25, 41, 57				
2B	10, 26, 42, 58				
3B	11, 27, 43, 59				
4B	12, 28, 44, 60				
5B	13, 29, 45, 61				
6B	14, 30, 46, 62				
Specifications		< +/- 8.5	< 50	< +/- 14	

Table 3-5 48cm Phantom CT# Brightness Uniformity, Noise & Center Smudge Row Performance Data Sheet (Pro 16, LS 16)

Row	Images	Brightness Uniformity (AvXo - AvXc)	Noise (AvSDo)	Center Smudge Row Values	Comments
7B	15, 31, 47, 63				
8B	16, 32, 48, 64				
Specifications		< +/- 8.5	< 50	< +/- 14	

Table 3-5 48cm Phantom CT# Brightness Uniformity, Noise & Center Smudge Row Performance Data Sheet (Pro 16, LS 16)

Row	Images	Brightness Uniformity (AvXo - AvXc)	Noise (AvSDo)	Center Smudge Row Values	Comments
2A	1, 5, 9, 13				
1A	2, 6, 10, 14				
1B	3, 7, 11, 15				
2B	4, 8, 12, 16				
Specifications		< +/- 8.5	< 70	< +/- 14	

Table 3-6 48cm Phantom CT# Brightness Uniformity, Noise & Center Smudge Row Performance Data Sheet (Ultra or Plus)

6.4.3 Failure Recommended Actions

6.4.3.1 Series Means (AvXo - AvXc or AvSDo) Failure Recovery

Specifications

Each Row of the series must pass 48cm Series Means (for the first series scan parameters) specifications:

- AvXo - AvXc: < +/- 8.5
- AvSDo: < 50.0 (Pro16, LS 16)
< 70.0 (Ultra, Plus)

Recommended Recovery

- 1.) Repeat Detailed Cal for the 48cm Phantom.
- 2.) Repeat Sections 6.4.1 & 6.4.2, to verify Image Performance.

6.4.3.2 Center Smudge Failure Recovery

Specifications

80% the Rows must pass Center Smudge specifications when re-scanning:

Center Smudge: Smudge Factor < +/- 14.0

Recommended Recovery

- 1.) If one image of one Row fails (Row fails once):

- Re-scan the 48cm Phantom acquiring two series of 64 images using the same protocol settings as listed in [Table 3-3](#) (on [page 64](#)) (**Pro 16**) or [Table3-4](#) (**LS 16, Ultra, Plus**).
 - Analyze the two 64 re-scanned image series using the Image Analysis IMGSER 48CM -> 16X1.25/120KV/400MA -> AUTO tool.
 - Verify that all the 128 re-scanned images do not fail Series Means (AvXo - AvXc and AvSDo) or Center Smudge.
- 2.) If more than one image of one Row fails (Row fails more than once) or multiple rows are failing:
- Repeat Detailed Cal for the 48cm Phantom.
 - Re-scan the 48cm Phantom acquiring three series of 64 images using the same protocol settings as listed in [Table 3-3](#) (on [page 64](#)).
 - Analyze the three re-scanned image series using the Image Analysis IMGSER 48CM -> 16X1.25/120KV/400MA -> AUTO tool.
 - Verify that all the 192 re-scanned images do not fail Series Means (AvXo - AvXc and AvSDo) or Center Smudge.

6.4.3.3 Band or Streak Artifact Failure Recovery

Specifications

- Band Artifact: Band Factor< +/- 8.0
- Streak Artifact: Streak Factor< +/- 4.0

Recommended Recovery

- 1.) Troubleshoot Band or Streak artifact failures, as described in the *System Service Manual*.
- 2.) Repeat Detailed Cal for the 48cm Phantom.
- 3.) Repeat Sections 6.4.1 & 6.4.2, to verify Image Performance.

6.5 20cm QA Phantom Image Series Image Performance Verification

6.5.1 Acquiring the 20cm QA Phantom Image Series

- 1.) Mount the Phantom Holder on the head-end of the table.
- 2.) Mount the 20cm QA Phantom on the Phantom Holder.
- 3.) Align, level, & center the 20cm QA Phantom.
 - Align black line on phantom using the internal laser lights.
 - Level phantom using bubble level and the Z Axis knob on the Phantom Holder.
 - Center phantom using the CENTER PHANTOM procedure in the left head SCANNER UTILITIES selection and the X and Y Axis knobs on the Phantom Holder.
- 4.) Set up the system to scan three 20cm QA Phantom image series with a Recon of the 1st series.
 - a.) On the Exam Rx desktop, select NEW PATIENT.
 - b.) Type the following entries in the listed Patient Information following fields:
 - * Patient ID: **Service**
 - * Name: **20cm QA Phantom Image Series**
 - c.) From the Protocol Selection display, click on the Service Tab under Anatomical Selector.
 - d.) On the Service Protocol Selection window, click on MANUFACTURING.

- e.) On the Service Category Protocol List, click on the appropriate Image Series selection as follows:

System	Protocol - First	Protocol - Second
HP60	Image Series QA	(none)
HP80	Image Series QA	(none)
HP100	Image Series 20cmQA (item # 45.8)	Image Series 20cmQA (item # 45.9)

- f.) On the ExamRx protocol parameter display, select the 1st Series.
g.) Set internal Landmark.
- 5.) Acquire the 1st 20cm QA Phantom image series and one Recon series (MTF and Contrast, Visible Lines).
6.) Acquire the 3rd 20cm QA Phantom image series.
7.) Acquire the last 20cm QA Phantom image series.

6.5.2 20cm QA Phantom Image Series Image Performance Verification

1st QA Phantom Image Series (4 Image MTF Average and Contrast Scale) Image Performance Verification

- 1.) Launch the Image Analysis Tool.
- From the Global Control Palette, click on the Service Desktop.
 - From the Service Desktop upper navigational bar, click on IMAGE QUALITY TESTS.
 - In the left navigational area directory, click on IMAGE ANALYSIS.
- Note: During the Image Analysis process, you will need to switch between the Service Browser screen (to select the image series to analyze) and the Image Analysis screen (to run a particular Auto 1x analysis test). Use ALT/F1 to bring a window to the front. Use ALT/F3 to send a window to the back.
- 2.) Using the Auto 1x Tool on the Image Analysis screen, generate a QA#1 MTF and QA#1 Contrast Scale report for the 1st series of the 20cm QA Phantom acquisition.
- From the Service Browser window, select the 1st series of the 20cm QA Phantom series acquired in section 6.5.1.
 - On the Image Analysis Tool window, click on the AUTO 1X diamond shaped button. (See [Figure 3-2, on page 63.](#))
 - Click on the AUTO 1X rectangular button, select the IMGSER 20CMQA test from the pull-down menu, slide cursor to the right to select QA1 MTF 2X10/120KV/260MA/1S from the test pull-down menu.
 - Click on the ACCEPT button.
- 3.) Review the Image Analysis Report data and record the Per Image MTF, 4 Image MTF Average, and Per Image Contrast Scale data for each row in Table 10-7.
- Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS. (See [Figure 3-3, on page 63.](#))
 - Record Per Image MTF and Per Image Contrast Scale data for each image in [Table 3-8](#).

- c.) Record the 4 Image MTF Average in [Table 3-8](#).

Image	MTF	MTF 4-slice average	Contrast Scale	Comments
1		N.A.		
2		N.A.		
3		N.A.		
4		N.A.		
Specifications	N.A.	0.65 to 1.0	110.0 to 130.0	N.A.

Table 3-7 20cm QA#1 Phantom High Contrast Spatial Resolution Image Performance (MTF and Contrast Scale)

2nd QA Phantom Image Series (4 Bone Retro Image Visible Lines) Image Perf. Verification

- 1.) Using the Auto 1x Tool on the Image Analysis screen, generate a Per Image QA#1 Lines report for the 2nd series of the 20cm QA Phantom acquisition.
 - a.) From the Service Browser window, select the 1st image of the 2nd series of the 20cm QA Phantom series acquired in section 6.5.1 (on [page 68](#)).
 - b.) Click on the AUTO 1X rectangular button, select the IMGSER 20CMQA test from the pull-down menu, and slide cursor to the right to select QA1 LI 2X10/120KV/260MA/1S.
 - c.) Click on the ACCEPT button. The tool displays a Visible Lines pop-up window.
 - d.) On the Visible Lines pop-up window, click on the VISIBLE LINE button.
- Note: The Image Analysis Tool automatically sets the Window/Level for optimal viewing. If required, adjust Window/Level using the center mouse button.
- e.) From the Visible Line pull-down menu, select the letter (A through F) that matches the smallest line pair pattern that you can discern in the Image View Port.
- f.) On the Visible Lines pop-up window, click on the OK button.
- 2.) Review the Image Analysis Report data and record the Per Image QA#1 Visible Lines data for the 1st image in [Table 3-8](#).
 - a.) Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS. (Refer to [Figure 3-3](#), on [page 63](#).)
 - b.) Record the Per Image QA#1 Visible Lines data for the 1st image in [Table 3-8](#).
- 3.) Repeat Steps 1 and 2, for each of the remaining three images in the 2nd 20cm QA Image Series.

Image	Line Patterns Visible	Comments
1		
2		
3		
4		
Specifications	B, C, D, E, F	N.A.

Table 3-8 20cm QA#1 Phantom High Contrast Spatial Resolution Image Performance (Visible Lines)

3rd QA Phantom Image Series (4 Image Visible Holes) Image Performance Verification

- 1.) Using the Auto 1x Tool on the Image Analysis screen, generate a Per Image QA#2 Holes report for the 3rd series of the 20cm QA Phantom acquisition.

- a.) From the Service Browser window, select the 1st image of the 3rd series of the 20cm QA Phantom series acquired in section 6.5.1.
- b.) Click on the AUTO 1X rectangular button, select IMGSER 20CMQA from the pull-down menu, and slide cursor to the right to select QA2 HO 2X10/120KV/260MA/1S.
- c.) Click on the ACCEPT button. The tool displays a Visible Hole pop-up window.
- d.) On the Visible Hole pop-up window, click on the VISIBLE HOLE button.
- Note: The Image Analysis Tool automatically sets the Window/Level for optimal viewing. If required, adjust Window/Level using the center mouse button.
- e.) From the Visible Hole pull-down menu, select the number (1 through 5) that matches the smallest hole that you can discern in the pattern centered in the image displayed in the Image View Port.
- f.) On the Visible Hole pop-up window, click on the OK button.
- 2.) Review the Image Analysis Report data and record the Per Image QA#2 Visible Holes data for the 1st image in [Table 3-9](#).
- a.) Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS. (Refer to [Figure 3-3](#), on page 63.)
- b.) Record the Per Image QA#2 Visible Holes data for the 1st image in [Table 3-9](#).
- 3.) Repeat Steps 1 and 2 for the 3rd, 5th, and 7th images in the 3rd 20cm QA Image Series.

Image	Visible Holes Viewable at Window 20	Contrast Factor	Comments
1			
3			
5			
7			
Specifications	See Table 6-9	2.0 to 12.0	N.A.

Table 3-9 20cm QA#2 Phantom Low Contrast Detectability Image Performance (Visible Holes)

Contrast Factor Range (Box 1 Means - Box 2 Means)	Visible Number of Holes		Smallest Visible Hole Size
	Lower Limit *	Upper Limit *	
2.00 to 3.99	2	5	7.5 mm
4.00 to 7.99	3	5	5.0 mm
8.00 to 12.00	4	5	3.0 mm

* Required Number of Visible Holes depends on the Contrast Factor

Table 3-10 20cm QA#2 Phantom Visible Hole Specifications

Last QA Phantom Image Series (QA#3 Small) Image Performance Verification

- 1.) Using the Auto 1x Tool on the Image Analysis screen, generate a QA#3 Small report for the last series of the 20cm QA Phantom acquisition.
- a.) From the Service Browser window, select the last series of the 20cm QA Phantom series acquired in section 6.5.1 (on [page 68](#)).
- b.) Click on the AUTO 1X rectangular button, select IMGSER 20CMQA from the pull-down menu, slide cursor to the right to select QA3 SM 2X10/120KV/260MA/1S from the test pull-down menu, and continue to slide cursor to the right to select AUTO. (Refer to

Figure 3-3, on page 63.)

- c.) Click on the ACCEPT button.
- 2.) Review the Image Analysis Report data and record the QA3 Small data for the last 20cm QA Image Series in Table 3-11.
 - a.) Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS. (Refer to Figure 3-3, on page 63.)
 - b.) Record the QA3 Small data (Row 2A1A and Row 2B1B Series Means AvXc and AvXo - AvXc), QA3 (AvSDc), and the Center Smudge Row data in Table 3-11.

Box Size = 196 mm² to 256 mm²

15 mm (+/- 1 mm) x 15 mm (+/- 1 mm)

31 (+/- 2 pixels) x 31 (+/- 2 pixels)

Box Positions:

Box 1	=	0 mm x 0 mm
Box 2	=	0 mm x -80 mm
Box 3	=	80 mm x 0 mm
Box 4	=	0 mm x 80 mm
Box 5	=	-80 mm x 0 mm

Row	Images	AvXc	AvXo	AvXo - AvXc	AvSDo	AvSDc	Center Smudge Row Value	Comments
2A1A	1, 3, 5, 7				N.A.			
1B2B	2, 4, 6, 8				N.A.			
Specifications		+3.0 to -3.0	N.A.	+3.0 to -3.0	N.A.	+ 2.9 to +3.5	+2.2 to -2.2	

Table 3-11 20cm QA#3 Phantom CT#, Brightness Uniformity, Center Noise & Center Smudge Row Performance Data Sheet

- 3.) Review the last 20cm QA Phantom images acquired in Section 6.5.1 for Rings, Bands, and Streaks using the Image Works Desktop.
 - a.) From the Global Control Palette, click on the IMAGE WORKS DESKTOP.
 - b.) From the Image Works Browser window, select the last 20cm QA Phantom series acquired in section 6.5.1.
 - c.) From the Image Works Browser window, click on the VIEWER button.
 - d.) While paging through the eight images in the series, analyze images for any Ring, Band, or Streak artifacts. Adjust Window/Level using the center mouse button, as required.
 - e.) Note any image that appears to have a Ring, Band, or Streak artifact.
- 4.) Verify any images noted above (step 3e) meet 20cm QA Phantom Ring, Band, or Streak Image Performance requirements.
 - a.) From the Global Control Palette, click on the Service Desktop.
 - b.) From the Service Browser window, select an image of the 4th 20cm QA Phantom series acquired in section 6.5.1 that appeared to have a Ring, Band, or Streak while reviewing the series in Image Works.
 - c.) On the Image Analysis Tool window, click on the AUTO 1X rectangular button, select the IMGSER 20CMQA test from the pull-down menu, slide cursor to the right to select QA3 SM 2X10/120KV/260MA/1S from the test pull-down menu, and continue to slide cursor to the right to select RING, BAND, or STREAK.
 - d.) Click on the ACCEPT button.

Note: If required, adjust Window/Level using the center mouse button.

- e.) Position and size the Ring, Band, or Streak ROI, using the left cursor button.

Note: To ensure specifications are properly applied, do not adjust the Reference ROIs for the Ring, Band, and Streak artifact tests. The Reference ROIs are adjustable after the 1st Accept Modification click.

- f.) Click on ACCEPT MODIFICATION twice to generate a report.
- g.) Verify the Overall Test Pass/Fail Indicator Window of the Report display indicates PASS.
- h.) Repeat steps b through g for each image noted in Step 3e.

6.5.3 Failure Recommended Actions

6.5.3.1 1st Image Series (4 Image MTF Average) Failure Recovery

Specifications

The 4 Image MTF Average must pass specifications:

4 Image MTF Average: 0.65 to 1.00

Recommended Recovery

- 1.) Repeat Detailed Cal for the 20cm QA Phantom.
- 2.) Repeat Auto CT# Adjust for the 20cm QA Phantom.
- 3.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.

6.5.3.2 2nd Image Series (Visible Lines) Failure Recovery

Specifications

The Largest 5 line pair patterns (coded F, E, D, C, and B) must be visible for each of the four images in this series.

Recommended Recovery

Note: The most common failure for this test is that the phantom has air bubbles that are obscuring the line pair patterns.

- 1.) Carefully inspect the 20cm QA Phantom for air bubbles. If required, refill the phantom with water, to eliminate all air bubbles.
- 2.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.

6.5.3.3 3rd Image Series (Visible Holes) Failure Recovery

Specifications

The number of visible holes in this image series must pass specifications as follows:

- Contrast Factor = 2.0 to 3.99:
Minimum of 2 holes must be visible (10mm & 7.5mm)
- Contrast Factor = 4.0 to 7.99:
Minimum of 3 holes must be visible (10mm, 7.5mm & 5mm)
- Contrast Factor = 8.0 to 12.0:
Minimum of 4 holes must be visible (10mm, 7.5mm, 5mm, & 3mm)

Recommended Recovery

- 1.) Repeat Detailed Cal for the 20cm QA Phantom.
- 2.) Repeat Auto CT# Adjust for the 20cm QA Phantom.
- 3.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.

6.5.3.4 4th Image Series Failure Recovery

Series Means

SPECIFICATIONS

Both Rows (2A1A, 1B2B) of the series must pass QA#3 Series Means specifications:

- AvXc: < +/- 3.0
- AvXo - AvXc: < +/- 3.0

RECOMMENDED RECOVERY

- 1.) Repeat Detailed Cal for the 20cm QA Phantom.
 - 2.) Repeat Auto CT# Adjust for the 20cm QA Phantom.
 - 3.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.
-

QA#3 (AvSDc)

SPECIFICATIONS

Both Rows (2A1A, 1B2B) of the series must pass QA#3 AvSDc specifications:

- AvSDc (< 5K Scans): 2.90 to 3.50
- AvSDc (> 5K Scans): 2.80 to 3.60

RECOMMENDED RECOVERY

- 1.) Repeat Detailed Cal for the 20cm QA Phantom.
 - 2.) Repeat Auto CT# Adjust for the 20cm QA Phantom.
 - 3.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.
-

Center Artifact or Center Smudge

SPECIFICATIONS

All eight images of the series must pass 20cm QA#3 Center Artifact and Center Smudge specifications:

- Center Artifact Factor: +/- 3.5
- Center Smudge Factor: +/- 2.2

RECOMMENDED RECOVERY

- 1.) Repeat Detailed Cal for the 20cm QA Phantom.

- 2.) Repeat Auto CT# Adjust for the 20cm QA Phantom.
- 3.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.

Ring, Band, or Streak Artifact Failure Recovery

SPECIFICATIONS

- Ring Artifact: Ring Factor < +/- 4.8
- Band Artifact: Band Factor +/- 2.8 from 0cm to 8.5cm
< +/- 2.8 > 8.5cm
- Streak Artifact: Streak Factor < +/- 4.0

RECOMMENDED RECOVERY

- 1.) Troubleshoot Ring, Band or Streak artifact failures as described in the Service Manual.
- 2.) Repeat Detailed Cal for the 20cm QA Phantom.
- 3.) Repeat Sections 6.5.1 & 6.5.2, to verify Image Performance.

Section 7.0

System Functional Test

Use the system tests in the following sections to exercise all aspects of the system and to ensure system integrity before releasing to the customer. Although the means, standard deviation, and resolution specifications do not apply during system functional tests, treat any artifact or image anomaly as a failure.

If you encounter a failure during the system tests:

- Record any evidence of artifacts, such as rings, streaks, shading, cupping, noise, or center artifacts.
- Correct artifacts, system test, or image series failures when they occur. Any delay in repairs could increase the number of retests.

1.) Place the QA phantom on the cradle.

- Drive the table to an elevation of 100.
- Align the line on the phantom with the internal laser lights.

Never scan above 50mA without first placing a phantom in the field of view. Levels in excess of 50mA can cause temporary radiation damage to the detector that lasts several hours. If you acquire image series cals with a radiation damaged detector, the cals may cause artifacts in subsequent image series scans.

2.) Select the service protocol, SYSTEM SCAN/CUST QUAL RELI.

3.) Run each series.

Note: **Stop the service protocol after the second helical series. It is not necessary to proceed past that point in the protocol.**

4.) Using Diagnostic Data Analysis, review the MSD Plots for each AIR scan.

5.) Complete the scans.

Section 8.0

Save System State

Use the following commands to create the System State DVD.

- 1.) Load a DVD into the mod drive on the front of the console.

- 2.) If you are not on the Service Desktop, click on the SERVICE DESKTOP icon,



- 3.) Click on the PM icon.



- 4.) Select SYSTEM STATE to open the System State Save/Restore menu.

- 5.) Select ALL

- 6.) Select SAVE

- 7.) When the save operation completes, select FILE and QUIT from the pull down menu.

- 8.) Remove the MOD from the drive

This page intentionally left blank

Chapter 4

Customer Options Installation & Verification

Note: Only use the Installation manual that arrives with your system for installation. Any other revisions of this manual may not exactly match your system.

Section 1.0

CT Options

- ☐ Injector functional tests completed.
- ☐ AWW functional tests completed.
- ☐ Filming/Camera/DASM functional tests completed.
- ☐ UPS functional tests completed.
- ☐ Network items installed and functional tests completed.
- ☐ Verify that all customer software options are installed and functional.
 - * Direct 3D
 - * SmartScore Pro
 - * CT Perfusion
- ☐ Auxiliary Monitor
 - * Flat Panel
 - * CRT

Section 2.0

Install Options

Refer to:

- GE Prints and schematics for mechanical (physical) location of option
- FDO shipment for identification of items
- Installation Specialist for installation instructions if they differ from print

2.1 Camera (Filming Device)

Refer to documentation shipped with camera

- Chapter 3 of this manual
- DICOM 2210573 GE Document
- DICOM Print 2152913

2.2 Injector

Refer to documentation shipped with the injector.

Complete a Functional test of the injector.

- The position of the ceiling mount assembly must allow the ceiling stand movement and gantry to tilt, typically 20 degrees, without interference.




Figure 4-1 Ceiling Mount Position

2.3 Advantage Windows Workstation (AWW)

Refer to the directions provided:

- Pre-install 2111833
- Service 2111831

2.4 Uninterruptible Power System (UPS)

TBD

2.5 Other Options

Refer to CT-2211224-100 *Lightspeed Options* for all other options.

Section 3.0

DICOM Network Introduction

LightSpeed systems support two basic Networking Protocols:

- Advantage NET (IC, Signa 4.X, CT-HLA, CT/I ...)
- DICOM (CT/I, CT Synergy, Advantage Workstations, ...)

DICOM NETWORK INTRODUCTION

DICOM networks basically operate on the **tasks** or services that various devices on the network use or provide. These services are labeled as Application Entity Titles (AE Titles). The CT scanner system is a **user** of six DICOM Network Services and is a **provider** of two DICOM Services:

AS A DICOM SERVICE USER:

- Send or **Push** images to another network device.
- Send or **Push** images to a DICOM Printer.
- Review image database on another device and retrieve or **Pull** selected images from that device (Query/Retrieve User).
- Send or **Push** images to a an image storage device and obtain confirmation that the images have been archived (Storage Commitment).
- Obtain Patient Worklist Information from the Hospital HIS/RIS System.
- Store images on MOD media.

AS A DICOM SERVICE PROVIDER:

- Receive **Pushed** images from another network device
- Allow another network device to review the image database and to retrieve or **Pull** selected images (Query/Retrieve Provider)

For each DICOM Service that the CT system will be a **User** (except for storing images on MOD media), you must **declare** this device on the CT system using three menu selections. For some devices, you must declare not only the device, but each service (AE Title) that the device provides. For example, you may be required to declare a PACS System twice on the CT system: once as a destination to **push** images and, second, as destination that provides storage commitment capability after images have been **pushed**.

For each DICOM Service that the CT system will be a **Provider**, you must **declare** the CT system on the network device that will be using these services.

Information required to complete configuring a hospital DICOM network is provided by the hospital network administrator (hostnames, IP Addresses) and the DICOM Conformance Statement document (AE Titles, Port Numbers) provided with each DICOM compatible network device on the network.

Section 4.0 Before You Start

4.1 Network Physical Requirements

Before setting up the CT scanner system on the hospital network, verify the following physical items are complete:

- Scanner console, monitor, keyboard, and mouse are installed and connected.
- CT system power is ON
- Hospital Ethernet network RJ45 Class IV twisted pair cable is connected to the scanner console network receptacle.
- Hospital network connection is operational and is running 10baseT or 100baseT.

4.2 Network Identity Information

To declare the CT system on the network, ensure the following network identity information is available from the Hospital Network Administrator:

- Hostname (No more than 16 Characters)
- Internet Protocol (IP) Address
- Subnet Net Mask IP Address (if applicable)
- Broadcast Address (if applicable)

4.3 Scanner to DICOM Remote Hosts Network Information

To declare DICOM remote hosts (PACS systems, archival devices, review workstations) on the CT system, ensure the following information is available for each remote host:

From the Hospital Network Administrator:

- Hostname
- Internet Protocol (IP) Address
- Network Protocol (DICOM for CT Systems)

From the Remote Host Device DICOM Conformance Statement Document:

- DICOM Application Entity Title or AE Title (DICOM service that remote host provides or uses)
- DICOM Listening Port Number

4.4 Scanner to DICOM HIS/RIS Interface Network Information

To declare DICOM Hospital HIS/RIS Interface devices (Mitra and others) on the CT System, ensure the following information is available:

From the Hospital Network Administrator: *Internet Protocol (IP) Address*

From the HIS/RIS Interface Device DICOM Conformance Statement Document:

- DICOM Application Entity Title or AE Title (DICOM Service that the HIS/RIS interface provides)
- DICOM Listening Port Number

4.5 Scanner to DICOM Printers Network Information

To declare DICOM on the CT System, ensure the following information is available for each printer:

From the Hospital Network Administrator:

- Hostname
- Internet Protocol (IP) Address

From the Printer DICOM Conformance Statement Document:

- DICOM Application Entity Title or AE Title (DICOM service that remote host provides or uses)
- DICOM Listening Port Number

Section 5.0

Declaring the System on the Hospital Network

5.1 Enter Configuration Routine

- 1.) On the OC, open a Unix shell window.
- 2.) Enter root as a superuser:
Type: `su -` **ENTER** at the prompt.
Type: `#bigguy` **ENTER** at the password prompt.
- 3.) Change directory to scripts:
Type: `cd /user/g/scripts` **ENTER** at the root prompt.
- 4.) Launch the Install Utility:
Type: `reconfig` **ENTER** at the prompt.
The OC displays the Install Utility Window as shown in [Figure 4-2](#).




Figure 4-2 Install Utility Window

- 5.) Enter the Configuration Routine:

Using the mouse, click on the CONFIG button.

The OC displays the System Configuration - System Settings screen, as shown in [Figure 4-3](#).

Figure 4-3 System Settings Screen

5.2 Configure Network Settings

This screen provides the ability to declare the CT system on a hospital network. Key information such as Host Name, IP Address, Net Mask (for CT systems on a subnet) must be obtained from the hospital network administrator.

- 1.) Select the NETWORK button to display the Network Settings screen as shown in [Figure 4-4](#).
- 2.) Enter the Suite Name.

The Suite Name is a means of identifying this particular CT system as a part of a group of CT Systems in a suite configuration. This Suite Name will appear on all image headers.

The Suite Name must start with a letter, followed by three alphanumeric characters (total MUST be four characters long). The name of the OC interface will be `<Suite Name>_oc` and the SBC interface will be `<Suite Name>_sbc`.

Figure 4-4 Networks Settings Screen

- 3.) Enter the hospital provided Host Name.
The Host Name identifies the network hostname and AE Title of the CT system.
The Host Name:
 - **MUST NOT** be <Suite Name>_oc or <SUITE NAME>_OC.
 - **MUST NOT** exceed 16 Characters.
 - **MUST** only contain the following characters: A through Z, a through z, 0 through 9, - and _
- 4.) Enter the hospital provided IP Address.
- 5.) Enter the hospital provided Net Mask (if the CT system is on a subnet).
- 6.) Enter the Broadcast Address:
The Broadcast Address should be the same as the IP Address except for the bits of the host id portion (last digit group) set to 1s or 0s depending on the configuration of the network. The standard default is 1s but older SunOS machines used 0s.

Example: If the IP Address is 192.100.9.17, the Broadcast Address should be 192.100.9.255 if the network is configured to use 1's to specify the broadcast address.
If the network contains genesis based scanners or other SunOS 3.5 or 4.1 computers, the Broadcast Address should be 192.100.9.0.
- 7.) Enter the hospital provided Default Gateway IP Address in the Default Gateway field (if applicable). If the site network does not use a default gateway, leave the field blank.
- 8.) Select NIS (Yellow Pages database) Advanced Option only if requested by the hospital network administrator as follows:
 - a.) Select ADVANCED OPTIONS button on the Network Settings screen.
 - b.) Select Use NIS? button.
 - c.) Enter the hospital provided Domain Name.
- 9.) Record all the Network parameters in the *Software Installation Procedures* Document, or on the worksheet in [2.2 on page 31](#).

5.3 Initiate System Reconfiguration

- 1.) Select ACCEPT on the System Configuration Screen.

The system loads the application software, OS patches, and kernel changes, and configures the system on both the OC and the SBC.

This loading process takes approximately 15 minutes. While the load is going on, the results are displayed in a shell window, which closes when the loading process is complete. All the window output is logged to a file named:

`/var/adm/install.log.YYYYMMDDWWHHMMSS.`

(Where `YYYYMMDDWWHHMMSS` is the Date/Time that the loading process was started.)

- 2.) When the loading process and configuration changes are complete, the system displays a prompt to reboot. Click on YES.
- 3.) The system will automatically login as ctuser after the reboot. Select OK on the Autostart Disabled popup message.
- 4.) To startup Applications, in the console shell window, type **startup** ENTER.

Section 6.0

Declaring Remote Hosts on the CT System

6.1 Enter Remote Host Configuration Screen

- 1.) On the OC, select the IMAGE WORKS icon.
- 2.) Select NETWORK.



6.2 Declaring Advantage NET Remote Hosts on the Scanner

Use Advantage NET Protocol networks to communicate with older CT or MR Systems (MR Signa 4.x, CT-HLA, CT/I Systems, and Workstations that support the Advantage NET protocol). Advantage NET Protocol does not offer full compatibility with LightSpeed DICOM formats.

Repeat the following procedure for each Advantage NET Remote Host device that the customer expects to have this CT system communicating with.

- 1.) Select REMOTE HOSTS from the pull down menu. The system displays the Remote Host Parameter Screen as shown in [Figure 4-5](#).

Remote host parameters

Host name

Network address

Network protocol: Advantage NET
DICOM

Port number: 4005

AE Title

Comment

Archive Node: ☐ Auto ☐ Yes ☐ No

Access to local host:

send images? ☐ Yes ☐ No

query/retrieve images? ☐ Yes ☐ No

Custom search? ☐ On ☐ Off

Save Cancel

Figure 4-5 Advantage Net Network Protocol Parameter Settings

- 2.) Enter the hospital provided Host name.
- 3.) Enter the hospital provided Network Address (IP Address).

- 4.) Select ADVANTAGE NET as the Network Protocol.
The systems automatically de-highlights the remaining parameter fields on the Remote Host parameter selection screen. These are dedicated DICOM protocol parameters and do not apply to Advantage NET type devices.
- 5.) Select SAVE to store the parameter settings of the remote host.

6.3 Declaring DICOM Remote Hosts on the CT Scanner

Use DICOM protocol networks to communicate to DICOM devices such as CT/i, CT Synergy, DLX, MR Lx, and third party hosts.

Repeat the following procedure for each DICOM remote host device that the customer expects to have this CT system communicating with.

- 1.) Select REMOTE HOSTS from the pull down menu. The system displays the Remote Host Parameter screen as shown in [Figure 4-6](#).

Figure 4-6 DICOM Network Setting Protocol Parameter Settings

- 2.) Enter the hospital provided Host name.
- 3.) Enter the hospital provided Network Address (IP Address).
- 4.) Select DICOM as the Network Protocol.
The system automatically highlights the remaining parameter fields on the Remote Host parameter selection screen. These are dedicated DICOM Protocol parameters.
- 5.) Enter the TCP/IP Listening Port Number from the DICOM Conformance Statement provided with the device.

- 6.) Enter the **AE Title** from the DICOM Conformance Statement provided with the device.
Application Entity Titles (also known as ACR-Nema or Dicom Name) refer to the DICOM Network Services that a device provides to the CT System. For most devices, the AE Title is the same as the hostname (CT systems are equipped with this feature).
However, some devices such as PACS systems may have separate AE Titles and port numbers for each of the services that the PACS system provides. In these cases, you must enter a separate remote host (same hostname and IP Address) for each of the independent AE Title Services that the host provides (one host as an image **push-to** destination, another host as a **query/retrieve** provider, and another host as a **storage/commitment** provider).
Be sure to review the DICOM Conformance Statement for each device that will provide a remote host network service for the CT system (image **push-to** or store destination, Query/Retrieve, and Storage Commitment) to ensure that each service is correctly configured.
- 7.) Select the correct **Archive Node** choice for the device. The Archive Node selection field defines the ability of the remote host to act as a DICOM Storage/Commitment provider and indicate to the operator that a study/series/image was archived. Select:
 - AUTO to have the CT system automatically check to see if the designated remote host is a DICOM Storage/Commitment Provider.
 - YES if the device is the hospital designated DICOM Storage/Commitment Provider. During an Application Study Archive process, the local browser screen will indicate **Archive Status = Y** to the operator.
 - NO if the device is not a DICOM Storage/Commitment Provider.
- 8.) Select the correct **Access to local host:** settings. These two selections allow you to selectively block the remote host from using the LightSpeed DICOM services as a provider (image **push-to** destination, and a **Query/Retrieve** provider).
 - **Send Images?** Set to YES if the customer wants the CT system to be able to have images **pushed** to the system from the applicable remote host. Set to NO if the customer wants to block an image **push** from the applicable remote host.
 - **Query/retrieve images?** Set to YES if the customer wants the remote host to be able to review the image database (query) and **pull** selected images from the database. Set to NO if the customer does not want the remote host to have this ability.
- 9.) Select the correct **Custom search?** setting. This selection allows the CT scanner to selectively search through the remote host's image database when the operator is using remote browser screen to **query** the remote host. The search parameters that the CT system allows the customer to use are: last name contains, patient ID, exam number, accession number, and exam date.
 - Select ON if the device supports custom searches as part of the devices **Query/Retrieve** DICOM Provider service.
 - Select OFF if the device does not support custom searches.
- 10.) Record all the remote host network parameters for each remote host in the *Software Installation Procedures* Document.
- 11.) Select SAVE to store the parameter settings of the remote host.

Section 7.0

Declaring the CT System on Remote Hosts

7.1 Declaring the Scanner on Advantage NET Protocol Devices/Systems

Refer to the appropriate service manual provided with the Advantage NET Protocol device or system to find instructions how to declare the CT System as an Advantage NET remote host.

7.2 Declaring the Scanner on DICOM Protocol Devices/Systems

Refer to the appropriate Service Manual provided with the DICOM protocol device or system to find instructions how to declare the CT System as a DICOM remote host.

The CT System provides two DICOM Services as a provider to remote hosts:

- A remote host can **push** images to the CT image database.
- A remote host can review the CT image database (query) and **pull** selected images (retrieve).

Use the following parameter information to configure the DICOM device/system to either **push** images to the CT scanner and/or perform a **Query/Retrieve** operation:

- **Hostname**: Provided by the Hospital Network Administrator. Exactly the same scanner assigned hostname entered in Network Configuration Screen.
- **Application Entity Title**: Exactly the same entry as the Hostname.
- **Network Address**: Provided by the Hospital Network Administrator. Exactly the same scanner assigned IP Address entered in Network Configuration Screen.
- **Network Protocol**: DICOM 3.0.
- **Port Number**: For all DICOM service that the CT System provides, use 4006.
- **Provider Type**: This field concerns the LightSpeed DICOM **Query/Retrieve** provider capability. All CT systems are wstudy root systems, which allow queries at the exam, series, and image level.
- **Support Worklist**: This field concerns whether a DICOM **Query/Retrieve** provider capable device or system supports a filter search of the image database. All CT systems support a filtered search of the image database as part of the LightSpeed DICOM **Query/Retrieve** provider capability.

Section 8.0 DICOM HIS/RIS Setup

8.1 Prerequisites

Most hospital HIS/RIS systems are not DICOM compatible and require a DICOM HIS/RIS Worklist Interface to provide patient scheduling information to the CT system. Contact your local HNS support engineer to determine exactly what DICOM HIS/RIS Interface is appropriate for the customer.

In addition, the CT system must have the ConnectPRO software option installed to utilize the DICOM Protocol Worklist capability.

8.2 Loading ConnectPRO Software Option on the CT System

- 1.) If you are not on the Service Desktop, click on the SERVICE DESKTOP icon.



- 2.) Click on the UTILITIES icon.



- 3.) Click on INSTALL.

- 4.) Select INSTALL OPTIONS and click START. The console displays the Software Options window as shown in Figure 4-7.




Figure 4-7 Options Window when First Selected

- 5.) Insert the ConnectPRO Options MOD into the MOD drive.
- 6.) Click on OK to continue.
- 7.) On the Software Option window, select the CONNECTPRO option in the Available Options window.
- 8.) Click on the INSTALL button.

The console may display a message box during the software loading operation. When the system has completed loading the software:

- the Installed Options window displays the ConnectPRO option, and
- the console displays the ConnectPro Setup window as shown in [Figure 4-8](#).




Figure 4-8 ConnectPro Setup Screen

- 9.) Enter the hospital provided HIS Server IP Address.
- 10.) Enter the HIS Server AE Title from the DICOM HIS/RIS Interface device DICOM Conformance Statement document.
- 11.) Enter the HIS Server AE Port # from the DICOM HIS/RIS Interface device DICOM Conformance Statement document.
- 12.) Record all the ConnectPRO HIS/RIS Network parameters in the *Software Installation Procedures* document.
The system will automatically load the LightSpeed CT Server AE Title (Hostname of the system).
- 13.) Click on the ACCEPT button. The system will check valid setup entries, execute a perl script that makes changes to the configuration files for HIS/RIS, and return to the Software Option window shown in [Figure 4-7](#).
- 14.) Click on the QUIT button and the subsequent OK button in the message window.
- 15.) Remove the MOD from the MOD drive, and write protect the side containing the ConnectPRO option.

Section 9.0 DICOM Filming Devices Setup

9.1 Prerequisites

Before configuring DICOM filming devices (cameras, printers) on the CT System, ensure the following are complete:

- Filming Device Service Representative to assist in camera/printer setup for best image quality film presentation.
- Hospital DICOM network is operational.
- Filming device is connected to the DICOM network with the correct filmer DICOM interface.
- Filming device is DICOM protocol compatible.
- Filming device DICOM Conformance Statement document is available.

Note: **Filmer DICOM Application Entity Titles may be site specific. Make sure that you check with the Filming Device Service Representative and the hospital network administrator to ensure you are using the correct AE Title for the destination filming device.**

9.2 Declaring DICOM Filming Devices on the CT System



NOTICE Potential For Data Loss

Empty all filming queues before modifying camera parameters.

This section contains procedures for recording important Camera setup information. Use the table(s) at the end of this section to record information from the setup screens.

- 1.) Click on the SERVICE DESKTOP button.
- 2.) On the Desktop Toolbar select UTILITIES -> INSTALL -> INSTALL CAMERA. The Install Camera window appears, along with a warning message pop-up box, to remind you that all filming queues must be empty before you begin to update or delete a camera.
- 3.) The Graphical User Interface displayed shows a list of cameras installed (See Figure 4-10). First, you must click OK in the warning message box. See Figure 4-9.




Figure 4-9 Warning Screen

- 4.) Now you are asked a series of questions.
- a.) To add a new camera, click the ADD button (See Figure 4-10).




Figure 4-10 Printer Configuration GUI

- b.) A dialog window for the camera type (DASM/DICOM) appears. If no DASM is detected during the OC boot, the DASM button will be disabled (Figure 4-11). If a DASM is present and has not been detected, reboot the OC and run the camera configuration tool again.




Figure 4-11 Dialog Box for camera Type (with and without DASM)

- 5.) To add a new laser camera, click DASM in the camera type dialog box. This brings up a list of available camera models. Select the appropriate model from the list and click SELECT (See Figure 4-12). Now you must configure it.




Figure 4-12 Camera Model Dialog (with DASM)

- a.) DASM Interface is automatically detected as either Analogue or Digital
- b.) Two Laser Options are available for laser cameras: SLIDES and ZOOM. Set this option only if the camera being installed supports slides and zoom. Setting the option allows it to be enabled or disabled at the application level.
- c.) Camera manufactures provide two (2) Magnification Type options for cameras. The SMOOTH resolution blurs the image, while the SHARP resolution makes the image pixels more pronounced. The default is smooth.

Comment:

To film good images, and have them look like images filmed by other GE CT products, the following camera settings are suggested:

Kodak: SMOOTH

Dupont/Sterling: SMOOTH

3M/Imation (Laser Camera): SHARP

3M/Imation (Dry View): SMOOTH

Agfa: SMOOTH

- d.) Select the appropriate File Format. Select ON from the drop down list boxes on the menu. Valid film formats are determined by the camera manufacture. IMATION for example, doesn't support 4x4, 2x4 or 1x2 and AGFA does not support 2x4) The DICOM print convention designates film formats by column and row (e.g. 12 on 1 film is 3x4).

When finished setting parameters, click on DONE and proceed to step 8.




Figure 4-13 Laser Camera Configuration

- 6.) To add a new DICOM camera, click on ADD and then DICOM in the dialog box that appears.
 - a.) A list of camera models appears (See Figure 4-14). Select the appropriate model from the list and click SELECT. Clicking SELECT presets all the parameters to that models except the Network parameters.




Figure 4-14 Camera Model Dialog (DICOM)

*Comment:
It's advised to
recheck the
preset
information with
the camera
manufacturer's
representative.*

- Selection of a different camera model clears the Image Quality parameters, because these are camera manufacture dependent.
- b.) Enter the Network Parameters (See Figure 4-15)
- > Device Name A unique name used to identify the camera.
 - > Host Name DICOM print server host name, as defined by the hospital.
 - > IP Address DICOM print server IP address, as defined by the hospital.
 - > AE Title DICOM print server application entity title, as defined by the print server. *You should consult the manufacturers DICOM Conformance Statement.*

Note: The Application Entity Title for the Camera may be site specific. Make sure that you check with the Camera Manufacturer's Representative and the hospital network administrator to ensure you are using the correct AE Title for the destination DICOM Print Camera.

- > TCP/IP Listen Port DICOM print server TCP/IP listen port, as defined by the server. *You should consult the manufacturers DICOM Conformance Statement.*
- > Comments Optional comments used by the DICOM print server.

Figure 4-15 DICOM Camera Configuration

- c.) Medium Type specifies the type of film being used. Currently, only BLUE FILM and CLEAR FILM are supported.

- d.) Set Destination to the final location for film output: either MAGAZINE or PROCESSOR.
- e.) Orientation selects film orientation. Only PORTRAIT is currently supported.
- f.) Set the Magnification Type. This parameter selects the algorithm used to interpolate pixels for proper film resolution. Set this parameter after consulting the camera manufacture to ensure optimal image quality. Choices are describe below:
 - > None No interpolation. This option is not suported by all cameras.
 - > Replicate Adjacent pixels are interpolated. This can result in "pixelized" images. *This algorithm is not normal preferred.*
 - > Bilinear A 1st order interpolation of pixels. Results in images usaually described as blurred. *This algorithm is not normal preferred.*
 - > Cubic A 3rd order interpolation. Used with a large number of possible formulations. Camera manufactures define parameters called "smoothing type" to set coefficients used in this algorithm. The implementation of these "smoothing soefficients" is camera dependent.
- g.) Select the Standard Film Formats. Select the film format by choosing ON in the pull-down menu box located below each selection. See Figure 4-15. Valid film formats are set by the camera manufacture. IMATION for example, doesn't support 4x4, 2x4 or 1x2 and AGFA does not support 2x4) The DICOM print convention designates film formats by column and row (e.g. 12 on 1 film is 3x4).
- h.) After the camera has been configured, click the ADVANCED button. This creates the camera device file for you automatically and pops up the Advanced Parameters screen. See Figure 4-16.

Comment: For most Camera Manufacturers, the preferred selection is CUBIC.

The screenshot shows a dialog box titled "Camera Attribute Dialog". It contains several sections of controls:

- Image Quality Parameters** (Section Header)
- Configuration**: A text field containing "PERCEPTION_LUT=KANAMC".
- Maximum Density**: A text field containing "320".
- Minimum Density**: A text field containing "32".
- Smoothing Type**: A text field containing "140".
- Empty Density**: A text field containing "Black".
- Border Density**: A text field containing "Black".
- Film Size**: A text field containing "<empty>".
- Trim**: A text field containing "Yes".
- Priority**: A text field containing "High".
- At the bottom, there are two buttons: "Done" and "cancel".

Figure 4-16 Advanced Parameters (Camera Attribute Dialog)

- 7.) Advanced camera parameters control the image quality of films.
- Note: For more information on the proper settings for these parameters, please see the Camera's DICOM Print Device Conformance Statement or the Camera Manufacturer Representative.

You may need to refer to a copy of the Conformance Statement as you are working with the Camera Manufacturer's Representative, to correctly set up the DICOM Print Camera I/Q and Time-out Settings.

- a.) **Configuration** - This parameter is camera manufacturer dependent as is typically used to specify the image contrast. The Configuration field may be up to 1024 characters long. The field will scroll automatically as text is entered. To review your entry, simply click and hold the middle mouse button, while the cursor is in the field, and drag the mouse towards the right (or left) as needed.

Note: Recommended Configuration Setting Values:

Agfa Drystar (MG3000) **PERCEPTION_LUT=KANAMORI (100)**
Imation Dryview (8700) **LUT=0,7**
Kodak Laser Printer 190CS434\CN0\PD1.20

- b.) **Smoothing Type** - Set Smoothing Type to ON, and input the selected value. This parameter is used when the magnification type is CUBIC. It represents the coefficient for the image resolution algorithm. This parameter is camera manufacturer dependent, and should be re-verified with your radiology department.

Note: **Recommended Smoothing Type Starting Values and Ranges:**

Agfa DryStar (MG3000) Start Value:140 Range:137-150
Imation Dryview (8700) Start Value:3 Range:3-13
Kodak Laser Printer 190 Start Value:Enhanced Range:Normal

- c.) **Minimum and Maximum Density** - Used to set brightness of the images on film. The range of values is 0-4095, although the valid range for a specific camera is manufacture dependent. For **Maximum Density**, input the correct value into the text box. For **Minimum Density**, set it to ON and input the correct value in the text box.

Note: **Recommended Minimum and Maximum Density Starting Values:**

Agfa Drystar (MG3000) Min.:20 or 23 Max:300
Imation Dryview (8700) Min.:(Blank) Max:300
Kodak Laser Printer 190 Min.:20 Max:300

- d.) **Empty Image Density** - This parameter sets the density for empty film viewports. Typically, BLACK is used but WHITE is an available option. The minimum and maximum density values are used as the representation.
- e.) **Border Density** - This sets the density for the border used around the film viewports. Typically, BLACK is used but WHITE is an available option. The minimum and maximum density values are used as the representation.
- f.) **Film Size** - Allows the system to specify a particular film size, if selected.
- g.) **Trim** - YES produces a white (clear) box surrounding each image.
- h.) **Priority** - This sets the print priority.
- i.) If you have completed entry of advanced parameters, click DONE.

CAMERA DATA TABLES: TO LOCATE INSTALL CAMERA INFORMATION: CLICK ON THE SERVICE DESKTOP BUTTON. ON THE DESKTOP TOOLBAR SELECT UTILITIES -> INSTALL -> INSTALL CAMERA. THE INSTALL CAMERA WINDOW APPEARS. SELECT EACH OF THE CAMERAS THAT ARE INSTALLED FROM THE LIST OF INSTALLED CAMERAS, AND CLICK ON UPDATE TO VIEW THE CAMERA'S SETTINGS. RECORD THE VALUES USED TO SET UP EACH CAMERA IN THE TABLES THAT FOLLOW. EXTRA TABLES

ARE PROVIDED FOR MULTIPLE CAMERAS

Note: You can determine this information by looking at the contents of the following files:

- For a DASM Camera: `/usr/g/ctuser/app-defaults/devices/camera.dev`
- For a DICOM Print Camera: `/usr/g/ctuser/app-defaults/devices/name.cfg`
where, *name.cfg* is the camera device name from the printer configuration GUI.

Example: `more <filename from above> ENTER`

DASM CAMERA #1 SETUP

GUI SETTING	SELECTIONS	VALUE
Camera Type	Model Type of Camera	
DASM Type	Digital or Analog	☐ Digital ☐ Analog
Options	Slides or Zoom	☐ Slides ☐ Analog
Film	Smooth or Sharp	☐ Smooth ☐ Sharp
Film Format Available	1x1, 2x1, 2x2, 3x2, etc.	
Film Format Default	1x1, 2x1, 2x2, 3x2, etc.	

Table 4-1

DICOM CAMERA #1

GUI SETTING	SELECTIONS	VALUES
DICOM Camera Type	Model Type of Camera	
Film Format Available	1x1, 2x1, 2x2, 3x2, etc.	
Network Parameters	Host Name	
	IP Address	
	AE Title	
	TCP Listen Port	
	Comments	
	Destination	☐ Magazine ☐ Processor
Special Set Up	Orientation	☐ Portrait ☐ Landscape
	Medium Type	☐ Blue ☐ Clear
	Magnification Type	☐ None ☐ Replicate ☐ Bilinear ☐ Cubic
*Advanced Parameters - IQ	Smoothing Type	☐ ON ☐ OFF Value:
	Configuration	
	Minimum Density	☐ ON ☐ OFF Value:
	Maximum Density	
	Empty Density (Black/White)	☐ Black ☐ White

*To view Advanced DICOM Camera Settings, you must click on ADVANCED.

Table 4-2 DICOM Camera #1

GUI SETTING	SELECTIONS	VALUES
	Border Density (Black/White)	☐ Black ☐ White
	TRIM	☐ YES ☐ NO
	Priority	☐ HI ☐ MED ☐ LOW
	Film Size	

NOTES

*To view Advanced DICOM Camera Settings, you must click on ADVANCED.

Table 4-2 DICOM Camera #1

DICOM CAMERA #2

GUI SETTING	SELECTIONS	VALUES
DICOM Camera Type	Model Type of Camera	
Film Format Available	1x1, 2x1, 2x2, 3x2, etc.	
Network Parameters	Host Name	
	IP Address	
	AE Title	
	TCP Listen Port	
	Comments	
	Destination	☐ Magazine ☐ Processor
Special Set Up	Orientation	☐ Portrait ☐ Landscape
	Medium Type	☐ Blue ☐ Clear
	Magnification Type	☐ None ☐ Replicate ☐ Bilinear ☐ Cubic
*Advanced Parameters - IQ	Smoothing Type	☐ ON ☐ OFF Value:
	Configuration	
	Minimum Density	☐ ON ☐ OFF Value:
	Maximum Density	
	Empty Density (Black/White)	☐ Black ☐ White
	Border Density (Black/White)	☐ Black ☐ White

*To view Advanced DICOM Camera Settings, you must click on ADVANCED.

Table 4-3 DICOM Camera #2

GUI SETTING	SELECTIONS	VALUES
	TRIM	☐ YES ☐ NO
	Priority	☐ HI ☐ MED ☐ LOW
	Film Size	

NOTES

*To view Advanced DICOM Camera Settings, you must click on ADVANCED.

Table 4-3 DICOM Camera #2

DICOM CAMERA #3

GUI SETTING	SELECTIONS	VALUES
DICOM Camera Type	Model Type of Camera	
Film Format Available	1x1, 2x1, 2x2, 3x2, etc.	
Network Parameters	Host Name	
	IP Address	
	AE Title	
	TCP Listen Port	
	Comments	
	Destination	☐ Magazine ☐ Processor
Special Set Up	Orientation	☐ Portrait ☐ Landscape
	Medium Type	☐ Blue ☐ Clear
	Magnification Type	☐ None ☐ Replicate ☐ Bilinear ☐ Cubic
*Advanced Parameters - IQ	Smoothing Type	☐ ON ☐ OFF Value:
	Configuration	
	Minimum Density	☐ ON ☐ OFF Value:
	Maximum Density	
	Empty Density (Black/White)	☐ Black ☐ White
	Border Density (Black/White)	☐ Black ☐ White
	TRIM	☐ YES ☐ NO
	Priority	☐ HI ☐ MED ☐ LOW
	Film Size	

NOTES

*To view Advanced DICOM Camera Settings, you must click on ADVANCED.

Table 4-4 DICOM Camera #3

9.3 Troubleshooting Tips

The following is a summary of troubleshooting information for DICOM print that was gathered during software testing and validation of the DICOM print feature.

There is also a significant amount of additional troubleshooting procedures, and the theory of the DICOM print feature in the System Service Manual. Should you have problems installing a DICOM print camera, first read the information in System Service Manual.

ERROR BRINGING UP THE CAMERA INSTALLATION/FILMING APPLICATION

- **Symptom:** After creating/modifying the DICOM print camera the install camera interface does not come up and the filming application indicates it cannot bring up the film composer.
Cause: The configuration field contains invalid information such as a backslash (\) as the final character in the field or brackets ({}).
- **Solution:** The camera.dev file in `~ctuser/app-defaults/devices` must be manually edited to remove the offending characters in the set configuration line. Invalid characters include \{ }

CONFIGURATION INFORMATION FIELD

- **Symptom:** Cannot view the entire configuration field (> 25 characters)
- **Solution:** Hold down the middle mouse button and move the field contents

NEED TO SET DICOM PRINT ATTRIBUTES NOT SUPPORTED BY SOFTWARE

- **Symptom:** User wants the white border around each image box ON/OFF permanently for this system and it cannot be set as the default for the camera.
- **Solution:** Using your favorite editor, add the following line to the camera.dev file located in `~ctuser/app-defaults/devices` after the DICOM print device has been otherwise configured.
For Trim Off - set TRIM NO
For Trim On - set TRIM YES
- **Symptom:** DICOM print camera supports multiple film sizes and the user only wants to print if the film size is correct for LightSpeed 5.X (14x17). [Otherwise the camera will queue the films or return an error causing the queue to pause (based upon the DICOM print camera specifications).]
- **Solution:** Using your favorite editor, add the following line to the camera.dev file located in `~ctuser/app-defaults/devices` after the DICOM print device has been otherwise configured.
To force a 14x17 film size - set filmSize 14INX17IN

NEED TO PREVENT DICOM PRINT ATTRIBUTES FROM BEING SENT TO DICOM PRINT CAMERA

- **Symptom:** Some DICOM print attributes are optional, and may result in fatal errors. For example, the Fuji camera does not support the Empty Image Density parameter for the film box.
- **Solution:** Using your favorite editor, add the following line(s) to the camera.dev file located in `~ctuser/app-defaults/devices` after the DICOM print device has been otherwise configured.
 - To prevent sending the Smoothing Parameter set FB_Smooth FALSE

- | | |
|--|-----------------|
| - To prevent sending the Border Density set | FB_Border FALSE |
| - To prevent sending the Empty Image Density set | FB_EID FALSE |
| - To prevent sending the Minimum Density set | FB_MinD FALSE |
| - To prevent sending the Trim Parameter set | FB_Trim FALSE |

ERROR TRYING TO CONNECT TO THE DICOM PRINT CAMERA

- **Symptom:** DICOM print server can be reached (ping), but Application error indicates "Unable to start filming interface" and the help message talks about running the install.dasm (Association Error)
- **Solution:** The system is unable to complete the association. Check the AE Title and the Port number of the DICOM print server and correct them through the Install Camera procedure.

FILM COMPOSER ERROR NOT USABLE

- **Symptom:** Film composer error says "unrecognized status - code 0"
- **Solution:** Review the log file, the attention and status windows. These areas have the correct filming status (for example, **film jam** and **supply empty**).

DEBUGGING CONNECTION ISSUES DIFFICULT

- **Symptom:** The timeouts for the DICOM print are very long, which means one needs to wait a long time before you know the application is not working.
- **Solution:** The timeouts for the DICOM print were setup to ensure that the system would work regardless of whether the DICOM print camera was on a LAN or a WAN halfway around the world. The DICOM print timeouts for the association and DIMSE classes (for example, **N-GET**, **N-DELETE**) can be modified within the DICOM print camera installation. They can be reduced down to 90 seconds.

DICOM PRINT ERROR ON N-GET TIMEOUT CONFUSING

- **Symptom:** When the N-GET timeout goes off, the error message in the prslog file will be "Could not get printer status, invalid command sequence for N-GET".
- **Solution:** When the user sees the above error they may want to consider that the issue may be an inactivity timer on the N-GET DIMSE service.

DICOM PRINT CAMERA SLIDE SUPPORT

- **Symptom:** Current implementation of DICOM print does not allow selection of slide format.
- **Solution:** Feature not currently supported. Possibly in future releases.

CONFUSION ON FILM FORMAT NOTATION

- **Symptom:** GEMS Laser Camera and DICOM Print film format notations are opposite.
- **Solution:**
 - GEMS Laser Camera film format notation has always been row x col (for example, 12 on 1 = 4x3)
 - DICOM Print Standard film format notation is col x row (for example, 12 on 1 = 3x4)

Section 10.0

Network Connections

BROAD-BAND

Broad-band is considered the standard network connection for LightSpeed 5.X. (A dial-up modem is optional.) Broad-band connections should use one of the following Category 5 patch cables:

CAT Num	GE Part Num	Length
K9000WB	2215028-10	20 m
K9000KP	2215028-5	10 m
K9000JR	2215028-4	5 m
K9000WA	2215028-9	3 m

The CT system is connected to the network through the Console.

- A patch cable (not to exceed 10 feet) should be provided by the customer, and it is used to connect the console to a wall box. (See Notes on [Figure 4-17](#))
- Some customer-site units may require cable duct-work or conduit to route connecting network cables to the workstation, camera and console.
- The run from the hospital switch to the CT wall outlet must not exceed 290 ft. (88m). Bandwidth performance is degraded when the length reaches 300 ft. (91m) or greater.
- For the optional modem: **Two phone lines should be provided by the facility.** One line is for use with a modem and must be an analog line. The second line is a voice only line.




Figure 4-17 Console Rear Bulkhead

US PROCESS OVERVIEW

The United States network connectivity requirement for this product is broad-band. The US process relies on the Install Specialist to select a Customer Champion and identify an IT contact for the site. Together, those individuals then complete a site assessment to gauge what tasks are needed to fulfill the connection.

Anyone can contact the GE Connectivity team at 800.321.7937, Option #3, with questions.

CUSTOMER BROAD-BAND RESPONSIBILITIES

Provide GEMS Installation Specialist with an accurate site address, telephone number, contact name, and e-mail address for the:

- Customer Champion
 - Co-ordinate VPN activities between Radiology/Cardiology and the Information Technology (IT) departments
 - Act as a focal point in assuring site broad-band infrastructure meets GEMS requirements for connection as determined by a mutual assessment with the GEMS Connectivity team.
- IT Contact
 - Complete an equipment assessment with GEMS Connectivity team to determine site readiness for broad-band
 - Work with the Customer Champion to complete any identified infrastructure changes
 - Provide IP addresses for new CT equipment
 - Provide a VPN compatible appliance that will support the IPSec tunneling protocol and 3DES data encryption
 - To utilize an Internet Service Provider that supports static routing



GE Medical Systems

Remote Service Broadband - Customer Site Assessment

Site Name: _____ FE Name: _____
City, State: _____ FE Phone: _____
Date: _____ FE Email: _____

- | | Yes | No |
|---|---|--------------------------|
| 1. Does your site currently have a persistent (24x7) Internet connection? | ☐ | ☐ |
| 2. Is the GEMS Diagnostic Imaging equipment on the Local Area Network and will it be accessible to the Internet? | ☐ | ☐ |
| 3. Does your site have a VPN device today? | ☐ | ☐ |
| 4. Is the VPN device one of the models below? <i>If Yes, please select the model from the options below.</i> | ☐ | ☐ |
| ☐ a) Cisco Pix Firewalls
☐ b) Cisco Routers
☐ c) Cisco 3000 Series (Altiga acquisition)
☐ d) Checkpoint Firewalls Software Version 4.1 and higher
☐ e) Nortel Contivity Software Version 3.2 or higher
☐ f) Redcreek | ☐ g) Symantec (Raptor) firewalls
☐ h) Firebox
☐ i) Linux S/WAN
☐ j) Sidewinder
☐ k) Netscreen
☐ l) None
☐ m) Other _____ | |

**If No, the GEMS Connectivity Support Team can help determine device compatibility.*

5. Does your VPN device support "triple DES" Encryption? ☐ Yes ☐ No
6. Has approval been given to install this VPN connection? ☐ Yes ☐ No
- Site Approver's Name _____
7. Provide your VPN Installer information, this is the person who will be contacted to schedule the VPN install.

Customer Installer Name: _____
Installer Telephone Number: _____
Installer e-mail address: _____

Notes: _____

Field Engineer needs to provide compatible system information:

System ID	IP Address	Gateway Address
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____

[Additional System and IP Address Spaces Available on Page 2](#)

If you have questions or need assessment support contact your Zone Champ or:

Joe Gracz - HQ Support 1-262-524-5261
Joseph.Gracz@med.ge.com

Once you have completed both pages of this form, please send it to:

a) Judy Heyer judy.heyer@med.ge.com
b) Judy Heyer Fax# 414-918-4707

[Use the send button on page 2](#)



Field Engineer needs to provide compatible system information:

[illegible]☐ Send Now





Figure 4-18 LightSpeed System Interconnection Runs

Chapter 5

Finalization

Section 1.0

Gantry Cover Alignment Adjustment Guide

1.1 Overview

This section explains the adjustment capability available for the Gantry covers and guidelines for performing adjustments.

1.2 Tools Required

3mm, 5mm, 8mm, Hex wrenches

1.3 Adjustment Guide

1.3.1 Front/Rear Cover Adjustment

The front and rear covers are held in a fixed vertical position by the cover locking mechanisms at the vertical middle of each cover on each side. The only adjustment capability is found on each of the cover cantrells (see [Figure 5-1](#)), one near each corner of the front and rear covers. Adjustments are best done at zero tilt.



Top Cantrell same
for all top latches



Bottom Cantrell same
for all bottom latches

Adjustment screw on
end of all brackets

Figure 5-1 Cantrells

- 1.) Remove the Gantry side covers using an 8mm hex wrench to release the bottom latches.

- 2.) Disable gantry rotation, 120VAC and HVDC via the service switch panel.
- 3.) Disconnect the fan power via the white molex connector (one for each top cover). Remove the top covers by lifting up and pulling to the side of the gantry.
- 4.) Remove the scan window to avoid creases or kinks during cover movements.
- 5.) Using an 5mm hex wrench, adjust the bolt on the gantry end of the cover cantrells (see [Figure 5-1](#)) to lengthen or shorten the cantrell arm that will push or pull the cover corner. The distance between the inside edges of the front and rear covers will be typically 27" + 1/8" (689mm). Distance should remain the same as measured along the inside edges from top to bottom with both covers hanging level as seen with a level on the inside vertical edge.

1.3.2 Scan Window

Position the scan window in the opening to verify that it seats all the way around with no gaps. The scan window should seat easily if the front and rear covers have been adjusted properly. If not, go back and readjust such that the scan window seats properly. There is no easy solution other than adjusting and looking for fit.

1.3.3 Top Cover Adjustment

The top covers rest in a top bracket that is mounted to the stationary gantry frame and subsequently just rest on top of the front/rear covers. There are also two alignment fingers on the outer edge of the top covers that need to sit in brackets on the front/rear covers.



Screws on both sides
allow up/down
adjustment only

Figure 5-2 Top Cover Bracket

- 1.) Set the top covers back on the gantry and look for proper fit. The top covers should rest on the front/rear covers all along the edges. If they do then skip the rest of this section.
- 2.) If the top covers do not rest on the gantry at the top then lift them back off and use a 5mm hex wrench to loosen the bolts that hold the top cover bracket for adjusting vertical alignment to allow the top covers to rest on the front and rear covers.
- 3.) The brackets on the front/rear covers for the fingers on the outer edge of the top covers are adjustable using a 3mm hex wrench and sliding the bracket till it lines up with the top cover finger. (See [Figure 5-3](#))



Adjustment bolts for
aligning bracket to
top cover finger

Figure 5-3 Top Cover Fingers

- 4.) Verify the top cover tapered edges fit over the lip along the top edge of the front/rear covers. If not, go back to Section 1.3.1 and readjust the cantrells as necessary.
- 5.) When done adjusting the top covers, reconnect the fan power molex connections.

1.3.4 Side Covers

The side covers just hang from the top covers by two fingers that are not adjustable. When set into the top covers, the side covers should hang straight down with the tapered edges fitting over top of the lip of the front/rear covers.

1.3.5 Finish

- 1.) Re-Enable gantry rotation via the Axial Enable switch on the service switch panel.
- 2.) Replace the side covers and latch using a 8mm hex wrench on the side cover bottom latches.
- 3.) Run an axial scan to ensure proper system operation prior to turning system back over to the customer.

Section 2.0

Customer Touch Leakage Test

2.1 Personnel Requirements

REQUIRED PERSONS	PRELIMINARY REQS	PROCEDURE	FINALIZATION
1	mins	1 hrs	mins

2.2 Overview

This procedure must be completed after all options have been installed. It covers three safety and leakage current checks:

- Patient Touch current test (completed after installation)
- System Ground resistance measurement (completed during installation)
- Ground current typical (completed after installation - optional)

2.3 Preliminary Requirements

2.3.1 Tools and Test Equipment

ITEM	QTY	PART#
Standard service tool kit	1	
Fluke 87	1	
AMP Clamp-on AC Probe	1	2338920
Dale 600 Leakage Current Meter	1	46-328406G1
Dale 600 Leakage Current Meter Ultra Sound Kit	1	46-285652G1
Dale 600 Leakage Current Meter European 220 VA	1	46-328406G2

2.3.2 Consumables

No consumables required.

2.3.3 Replacement Parts

No replacement parts required.

2.3.4 Safety



WARNING



POTENTIAL FOR SHOCK

GROUND WIRES WILL HAVE GROUND CURRENT PRESENT WITH POWER "ON".
FOLLOW APPROPRIATE SAFETY PROCEDURES FOR WORKING WITH AN
ENERGIZED SYSTEM.

2.3.5 Required Conditions

No required conditions.

2.4 Procedure

2.4.1 Patient Touch Leakage Current Test Procedure

- 1.) See [Figure 5-4](#) for the usage of the Dale 600 meter to measure leakage current.




Figure 5-4 Using Dale 600 to Measure Leakage Current

- 2.) Plug the Dale 600 Meter into the outlet nearest the Table. (Table base covers must be removed to use table outlet.) Confirm the outlet is correctly wired per the three LED indicators on the Meter.

- 3.) Connect the black lead to the chassis plug and the red lead to the external plug on the top of the Dale 600 meter. Set the function switch to external and display readings will be in micro-amps.

The black lead will be connected to the table base ground buss and the red lead is then connected to the devices (components) under test.

- 4.) Leakage current cannot exceed the following and is tested with power on:

a.) **Critical care areas (invasive) - 10µa**

b.) General care areas - 20µa

c.) Not intended for patient area - 50µa

- 5.) Testing must be completed between the system reference ground point (table base) to unit reference ground points (i.e. gantry and table, see illustration 1).

- 6.) Test all conductive surfaces and components within patient reach or within 6 feet or 1.9m around table and 7.5 feet or 2.3m above. Measure at table maximum travels. On some site wall outlet cover plates and sinks may become an issue.

- 7.) Test all Optional components such as in room monitors, injector, overhead monitor suspensions, and table options.

Record these results in the data sheet. To be completed at install and during PM inspections.

Gnd Bus to	Install <10µA	6-month PM <10µA	6-month PM <10µA
Table gnd points			
Gantry gnd points			
Injector gnd points			
Boom in Room			
Monitors			
Sinks			

- 8.) Test conditions: Table max elevation Min - Max travel; Patient face up and face down, and head first feet first. Table min elevation 7.2' patient access to all conductive surfaces Including: IV poles, any smart step monitors and stands, table bearing rails and all other conductive surfaces. Be aware of Static discharge: from scan window, keypads, display, and touch pads or other plastic surfaces.

- 9.) Procedure Hints:

a.) Look for items that have abnormal measurements, high or low.

b.) These could indicate mis-wiring, loose connections, or poor connections due to corrosion, painted surfaces, etc.

c.) High leakage could indicate a wiring error such as a neutral connected to the ground.

d.) Fluctuating ground currents could indicate a short, poor connection, or facilities ground problem causing leakage currents from other areas of the facility to flow through our system grounds.




Figure 5-5 CT Leakage Current Map

2.4.2 Ground Resistance Checks Procedure (done during mechanical install)

Use Fluke 87 to measure ground resistance.

- 1.) Use a Fluke 87 or equivalent RMS Meter to verify the presence of less than 0.5 ohm of resistance between each of the following points:

FROM	TO	
PDU Ground Bus	Vault Ground	☐ Check box when complete
PDU Ground Bus	Table/Gantry raceway ground point	☐ Check box when complete
Table/Gantry raceway ground point	Gantry Chassis	☐ Check box when complete
Table/Gantry raceway ground point	Table Chassis	☐ Check box when complete
Table/Gantry raceway ground point	Operator Console Chassis	☐ Check box when complete
All Display or Computing Options (if any)	Operator Console Chassis	☐ Check box when complete

Table 5-1 Resistance Verification - Site Ground

- 2.) Connect the meter leads to the Fluke 87 meter.
- 3.) Set the function switch to resistance ohms.
- 4.) The black and red leads will be connected per Table 5-1.
- 5.) All ground resistance testing is done with power off. Ground current will cause errors in the resistance readings.

- 6.) Use lockout/tag out procedures.
- 7.) Maximum ground resistance is 0.5 ohms impedance.
- 8.) Using the table footswitch ground bar as a reference. Check the ground resistance to all 5 system grounds.

Record the measurements in the data sheet:

SYSTEM GROUND BUS	TYPICAL READING	SITE DATA
Gantry Ground Stud	0.5 Ohms	
Console Ground Stud	0.5 Ohms	
PDU Ground Stud	0.5 Ohms	
Table Ground Stud	0.5 Ohms	

Hints:

- Look for undersized ground wires and repair.
- Ground resistance readings should not fluctuate. If so this indicates an intermittent




Figure 5-6 Measurement Points

Chapter 6

Forms and Checklists

This chapter includes the following sections:

- [Section 1.0 - Mechanical Vendor Installation List](#)
- [Section 2.0 - Electrical Calibration Installation Checklist](#)
- [Section 3.0 - GE Form 4879 Installation Data Verification](#)
- [Section 4.0 - Install Completion Checklist](#)
- [Section 5.0 - Electronic Forms](#)

This page intentionally left blank

Section 1.0

Mechanical Vendor Installation List

Vendor Company Name

- ☐ GE FE
- ☐ Mid-West
- ☐ Jentree
- ☐ Revels
- ☐ AMS
- ☐ AK Associates
- ☐ All Others

Install Trained

- ☐ Yes
- ☐ No
- ☐ Somewhat

Install Start Date _____

Install Completion Date _____

Hours Spent _____

Number of Trips _____

FDO _____

CLEAN UP

- ☐ Move Customer boxes to one corner or counter.
- ☐ Place Field Engineer Material (phantoms, hoist, kits, tools) into the service cabinet.
- ☐ Put all documentation (including software, HHS doc) in the purple box and leave by the console.

REMOVE TRASH

- ☐ Remove and recycle cardboard as required.
- ☐ Place skids and wood into the dumpster.

RETURN DOLLIES (USA ONLY)

- ☐ Check the packing list found in the purple box for dolly return location.
DO NOT return the console shipping skid to Milwaukee.

INSTALL COVERS

- ☐ Recheck Gantry and Table anchor for 75ft-lb.
- ☐ Install PDU covers.
- ☐ Install table foot-switch assembly and covers as required in your area.
- ☐ Install console covers and align as needed for proper cover fit.
- ☐ Install gantry base covers, and rear cable box cover as required.

CLEAN THE EQUIPMENT

- ☐ Use the cleaning supplies in the installation support kit to clean the equipment.

TOUCH UP NICKS

- ☐ Use the paint supplies found in the installation support kit to touch up nicks in the equipment.

COMPLETE PAPERWORK

- ☐ Collect all Product Locators and store in purple box.
- ☐ Complete the Field Engineer sign-off procedure with FE.
- ☐ Complete and sign this list.

SIGNATURE

Lead Mechanical Installer _____

Field Engineer _____

Mechanical Vendor installation comments _____

Short shipped? ☐ Yes ☐ No

Correct Documentation? ☐ Yes ☐ No ☐ Missing

Equipment Inventory Process

- ☐ OK - Found all items
- ☐ Items in different boxes
- ☐ Open all boxes to find
- ☐ Couldn't find all items

Field Engineer comments _____

Return to: george.farrington@med.ge.comCT Service Engineering
Suhail.altal@med.ge.comProject Leader, Installation Services

ELECTRONIC VERSION OF THIS FORM

An electronic version of this form is available. Use of the form requires Microsoft® Word. To complete and submit this form electronically, see [Section 5.0 - Electronic Forms](#).

Section 2.0

Electrical Calibration Installation Checklist

FE Name _____ FDO _____ System ID _____

Install Start Date _____ Install Completion Date _____

Hours Spent _____ Number of Trips: ☐ 1 trip ☐ 2 trips ☐ 3 or more trips

CT SYSTEM

- ☐ Complete functional tests.
- ☐ Complete power and ground audit.
- If not: ☐ TBD Later ☐ Not Required ☐ Scheduled by PG Leader
- ☐ Install seismic kit (if required in your area).
- ☐ Completed all required calibrations.

CT OPTIONS

- | | | |
|---|--|---------------------------------------|
| • Complete injector functional tests. | ☐ Install Completed | ☐ Not Required |
| • Complete AWW functional tests. | ☐ Install Completed | ☐ Not Required |
| • Complete Filming/Camera/DASM functional tests. | ☐ Install Completed | ☐ Not Required |
| • Complete UPS functional tests. | ☐ Install Completed | ☐ Not Required |
| • Complete Network items installed and functional tests. | ☐ Install Completed | ☐ Not Required |
| • Verify that all customer software options are installed and functional. | ☐ Install Completed | ☐ Not Required |
| • Are Remote Video Connections needed | ☐ Install Completed | ☐ Not Required |

Table 6-1 CT Options

SYSTEM CLEANUP

- ☐ Clean system with supplies shipped with your system.
- ☐ Touch-up nicks and scratches (as needed).
- ☐ Install pads and stickers (as needed).
- ☐ Store customer materials appropriately.
- ☐ Store service documents, tools, and materials appropriately.

DOLLIES RETURN

- ☐ Confirm dollies are returned.

INSTALL COMPLETION MATERIAL CHECKS

- ☐ All HHS documentation completed.
- ☐ Write Install related PQRs as needed.
- ☐ Complete all dispatching activities (03-04-10 codes).
- ☐ Complete customer acceptance checks/test.
- ☐ Complete system transfer and notify appropriate GE personnel.
- ☐ Communicate with the customer and address installation issues.

SIGNATURE

Field Engineer _____

Field Installation Comments / Issues _____

Alignment Calibration Required? ☐ Yes ☐ No

Correct Documentation Shipped? ☐ Yes ☐ No ☐ Missing

Return to: George.Farrington@med.ge.comCT Service Engineering
William.Gibson@med.ge.comHHS

ELECTRONIC VERSION OF THIS FORM

An electronic version of this form is available. Use of the form requires Microsoft® Word. To complete and submit this form electronically, see [Section 5.0 - Electronic Forms](#).

Section 3.0

GE Form 4879 Installation Data Verification



NOTICE Only use the Installation manual that arrives with your system for installation. Any other revisions of this manual may not exactly match your system.

3.1 Installation Site History

3.1.1 RECORDS KEEPING AND DOCUMENTATION - IMPORTANT!

- Locate the HHS data, sent from the factory, in the software collector box.
- Retain a copy of this HHS data and the data collected at the site, on site in the service cabinet.
- All sites that are required to submit an FDA 2579 form must send a copy of all HHS test information to the HHS administrator along with a completed GE 4879 and FDA 2579 form. This applies to both GEE and Local FEs who complete VCT installations.
- A generator RECAL is not required on VCT installations unless a certified component is replaced.
- If any one of the calibration procedures fails, data collected is different, or you replace any Certified component in the High Voltage section, YOU MUST RECALIBRATE THE SYSTEM.
- To recalibrate the system, refer to procedures in the System Service manual.
- Complete all installation check list items as proof the procedure was completed.

3.1.2 Component Tractability - IMPORTANT!

- Complete the Product Locator Report and mail it. Retain a copy on site with the HHS data records.
- Retain any additional information, per your local LCT procedures.

Completed By: GE Energy Healthcare FE Other

Date: _____

Name: _____

3.1.3 Installation Procedures Traceability - IMPORTANT!

PROCEDURE	COMPLETED BY (CIRCLE ONE)	TEST DATE	NAME (PRINT)
Mechanical Procedures Book 1	GE Energy Healthcare FE		
Electrical Procedures Book 2	GE Energy Healthcare FE		
IQ & Quality Procedures Book 2	GE Energy Healthcare FE		
GE 4879	GE Energy Healthcare FE		
GE 4879	GE Energy Healthcare FE		

PROCEDURE	COMPLETED BY (CIRCLE ONE)	TEST DATE	NAME (PRINT)
FDA e-2579	GE Energy Healthcare FE		
FDA e-2579	GE Energy Healthcare FE		

3.1.4 Installation Test & Tools Traceability - IMPORTANT!

Where Installed	
City	State
Customer's Telephone Number	Room No.
System ID #	GON #
Master Control - Console	
Model #	Serial #
Gantry	
Model #	Serial #
Installation Completion Date	
Test Equipment History	
DVM Manufacturer	DVM Model #
DVM Serial #	Cal Due Date
Leakage Meter Manufacturer	Model #
Serial #	Cal Due Date
Amp Meter Manufacturer	Model #
Serial #	Cal Due Date
Other - Manufacturer	Model #
Serial #	Cal Due Date

3.2 System X-Ray Indicators and Warning Labels

3.2.1 X-Ray On Indicators

- 1.) Perform several scans.
- 2.) Verify that the X-ray ON lights are on during the scans.
- 3.) Use a mirror to check the x-ray indicator light on the gantry rear cover

3.2.2 Operator Indicators - HHS Requirement

LIGHTS ON	LIGHT LOCATIONS
☐	SCIM
☐	Gantry Front
☐	Gantry Rear
☐	Room Warning Light

Initials: _____ Date: _____

X-Ray Indicators on the SCIM, Front and Back of Gantry Illuminate During X-Ray.

3.3 Warning Labels

3.3.1 Laser Warning labels

- 1.) Laser warning labels appear on the gantry lower right corner near the floor, and near each of the laser window opening on the gantry cover
- 2.) Obtain and install all warning labels in the appropriate language for the country installed.



Initials: _____ Date: _____

All laser warning labels are present.

3.3.2 Operator Use Warning Label - SCIM

Make sure the X-Ray warning label appears in the correct location on the SCIM.



Initials: _____ Date: _____

Warning labels are present.

3.3.3 Appropriate Language Warning Labels Verification

Check that all indicators, cautions and warning labels have been installed per the procedure in CT installation book 2, Chapter 5 Section 3.4.

Initials: _____ Date: _____

All Appropriate Language indicators, cautions and warning labels are installed.

3.4 Tomographic Plane Indication Accuracy

- 1.) Record the scan location (shown on the image annotation) of the image with the darkest scan plane indicator (darkest long bar).
- 2.) If your system meets all the installation and alignment specifications, the image at scan location zero (S0.0) should contain the scan plane indicator.

Specification:

(Must be within +/- 1mm)

If scan location S1.0 or scan location I1.0 has the darkest bar, the system still meets the specification. The scan plane deviation should equal S0.0 +1.0mm.



Repair: If necessary, adjust the internal alignment light position to meet the S0.0 +1.0mm requirement.

LANDMARK	DARKEST BAR LOCATION	DATA
Internal		
External		

Initials: _____ Date: _____

Tomographic plane indicator accuracy passed.

3.5 Table/Gantry Alignment Procedure

Repeat this procedure until the table edges line up (± 1 mm). If needed, a scout can be completed to check table horizontal presentation.

Check the two scout scans.

Specifications:

Molding strips should be parallel within +/- 3 mm. Cradle should be level within ± 1 mm.

Repair:

Repeat table to gantry alignment, and repeat scan test.

CRADLE LEVEL	DATA	PASS
Across Cradle		☐
Length of Cradle		☐
CRADLE ALIGNMENT		
Cradle Front min length	Edge to edge	☐
Cradle Rear max length	Edge to edge	☐
Cradle Center	From cradle CL	☐

Tighten the anchors and torque to 74.6 N-m (55 ft.-lb.).

Gantry	Completed	Table	Completed
8" Hilti QB	☐	8" Hilti QB	☐

Contractor Anchored Systems

Contractor name		Anchor type		Meets

Initials: _____ Date: _____

Table cradle alignment accuracy passed.

3.6 Check Alignment Lights - Test

- ☐ Internal Axial Lights
- ☐ External Axial Lights
- ☐ Coronal Lights

Initials: _____ Date: _____

Table cradle alignment Light accuracy passed.

3.7 Interference Test

Interference Test Requirement:

No tilt motion shall cause the gantry tilting frame to touch the stationary base covers for any tilt angle.

Initials: _____ Date: _____

All interference tests were completed and all tests passed.

3.8 System Functional Test

Use the system tests in the following sections to exercise all aspects of the system and to ensure system integrity before releasing to the customer.

Initials: _____ Date: _____

All functional tests were completed and all tests passed.

3.9 IQ Section - 5.X Image Quality Series

Complete the image series listed in [Chapter 3, Image Quality](#), and record the values in the site installation manual.

Note: IQ Sections may be slightly different for Pro16, LS16, Ultra and Plus systems.

3.10 Documentation Section - System Paperwork & Product Locator

3.10.1 Installation Verification

Copy or submit e-copied of these documents to the HHS administrator. Leave a copy on site as a record of system installation and test completion.

☐ **Mechanical Installation Completion Form**

To be completed by the mechanical installation team leader GEE or FE

☐ **Electrical Installation Completion Form**

To be completed by the electrical installation team leader GEE or FE

☐ **GE 4879 Data Sheets**

Note: More than one form may be submitted for the same installation by the different installation teams. (For GEE completed work and FE completed work)

To be completed by the installation team leader. All parts that was completed.

A separate GE 4879 will be completed when the Image Quality testing is completed. This document is sent to the HHS administrator.

☐ **GE Manufacturing HHS Data Sheets**

Complete and copy by the installation team leader These document are sent with this data form to the HHS administrator.

GE Shipped Documentation

All shipped documentation was received.

☐ Customer Documentation

☐ FE Documentation

3.10.2 Product Locator

☐ **Cards**

Collect and update product locator.

Leave a copy or one of the cards on site

3.10.3 Regulatory Information Distribution



Document Distribution

- 1.) A copy of all items from section 1 above
- 2.) A copy of all items from section 2 above
- 3.) Mail to HHS administrator



HHS FDA 2579

Note:

More than one form may be submitted for the same installation by the different installation teams. (GEE completed work and FE completed work)

- 1.) Complete the FDA e-2579
- 2.) When completed submit to HHS administration. Correct all errors. Do Not print this form. A printable version will be sent to you from HHS administration for your records.
- 3.) Some states require a State Registration Number to complete this form. If you have questions concerning your state, contact the HHS administrator.

This page intentionally left blank

Section 4.0

Install Completion Checklist

4.1 CT System


- ☐ Functional tests completed.
- ☐ Power and ground audit completed.
- ☐ Seismic kit installed (if needed in your area).

4.2 CT Options

- ☐ Injector functional tests completed.
- ☐ AWW functional tests completed.
- ☐ Filming/Camera/DASM functional tests completed.
- ☐ UPS functional tests completed.
- ☐ Network items installed and functional tests completed.
- ☐ Verify that all customer software options are installed and functional.

4.3 System Cleanup

- ☐ Clean system with supplies shipped with your system.
- ☐ Touch-up nicks and scratches (as needed).
- ☐ Install pads and stickers (as needed).
Specifically for LS16, Ultra & Plus, replace the caution labels (two) on the table frame with appropriate language labels from the 2199652 label set, as needed. The table comes with the labels shown as:



- ☐ Store customer materials appropriately.
- ☐ Store service documents, tools, and materials appropriately.

4.4 Dollies Return

- ☐ Console is shipped on a pallet. Do Not return pallet to GEMS.


4.5 Install Completion Material Checks

- ☐ Complete all HHS documentation. Complete Install PQRs as needed.
- ☐ Complete all dispatching activities (03-04-10 codes).
- ☐ Complete customer acceptance checks/test.
- ☐ Complete system transfer and notify appropriate GE personnel.
- ☐ Communicate with the customer and address installation issues.

Section 5.0 Electronic Forms

Several of the forms in this chapter may be completed and submitted electronically by following the procedure described below.

- 1.) To select and open the desired form, click on the appropriate link below. Either Microsoft® Word or Excel will launch, depending upon the type of form.
 - a.) Microsoft® Word documents:
 - * [Mechanical Vendor Installation List](#)
 - * [Electrical Calibration Installation Checklist](#)
 - b.) Microsoft® Excel spreadsheet:
 - * [HHS Data Sheet](#)
- 2.) A warning box similar to the samples below may appear. Click YES or OPEN as appropriate.



- 3.) Complete the form (TAB to move between fields).



NOTICE

Be certain to save a copy to a local hard drive.

- 4.) Submit the form, by choosing FILE > SEND TO > MAIL RECIPIENT. Enter the e-mail addresse(s) shown at the end of the signature section of the form in the Send To field.

This page intentionally left blank

Appendix A

Additional Characterization Procedures

For information related to alignment, setup, and calibration procedures, please refer to the appropriate LightSpeed 5.X Service Methods publication.

This page intentionally left blank

Appendix B

System Configuration Data Sheets

REQUIREMENT

Record valuable system information in the data sheets that follow. Consult with your customer or network administrator to obtain the information. Understanding how the customer plans to use their CT scanner, and their network and filming expectation reduces the time required to reconfigure the system.

- [Table 6-2 Manual Film Composer Options, on page 141](#)
- [Table 6-3 System Network Configuration, on page 141](#)
- [Table 6-4 Networking Application \(Image transfer\) Configuration, on page 142](#)
- [Table 6-5 DASM Laser Camera Configuration, on page 143](#)
- [Table 6-6 DICOM Print Camera Configuration, on page 143](#)
- [Table 6-7 DICOM Print Camera Advanced Configuration, on page 144](#)

MANUAL FILM COMPOSER OPTIONS

MANUAL FILM COMPOSER OPTIONS

Slide Format (if available):	
Greyscale:	
Auto Printing:	
Auto Clear Page:	
Icon Labels:	
Expose Order:	
No. of Copies:	

Table 6-2 Manual Film Composer Options

SYSTEM NETWORK CONFIGURATION

SYSTEM NETWORK CONFIGURATION			
	FIELD NAME:	SETENV NAME:	FIELD VALUE:
System Settings:	Service ID	SERVICE_ID	
	Hospital Name	HOSPITAL_NAME	
	Exam Number *	* ask customer or checklog	
	DAS Type	DASTYPE	
	PDU Type	PDUTYPE	
Network Settings:	Gateway Host Name	GATEWAY_HOSTNAME	
	Gateway IP	GATEWAY_IP	

Table 6-3 System Network Configuration

SYSTEM NETWORK CONFIGURATION			
	FIELD NAME:	SETENV NAME:	FIELD VALUE:
	Gateway Net Mask	GATEWAY_NETMASK	
	Gateway Broadcast Mask	GATEWAY_BROADCAST	
	Suite Name	SUITEID	
Option	Network Printer IP Address		
Option	HIS Server IP Address		
Option	HIS Server AE Title		
Option	HIS server AE Port		
Option	CT Server AE Title		
Option	Connect Pro IP Address		

Table 6-3 System Network Configuration (Continued)

NETWORK APPLICATION (IMAGE TRANSFER) CONFIGURATION

Record the network application (image transfer) configuration.

NETWORKING APPLICATION (IMAGE TRANSFER) CONFIGURATION				
AE TITLE OR HOST NAME	NETWORK ADDRESS	NETWORK PROTOCOL	PORT NUMBER	COMMENTS

Table 6-4 Networking Application (Image transfer) Configuration

HOST ETHERNET ADDRESS

_____ : _____ : _____ : _____ : _____

CAMERA APPLICATION CONFIGURATION

Record the camera application configuration for the DASM or DICOM print camera.

DASM LASER CAMERA CONFIGURATION

Camera Type:	
DASM Type:	
Film Smooth/Sharp Setting:	
Options:	
Valid Film Formats:	
Default Film Formats:	

Table 6-5 DASM Laser Camera Configuration

DICOM PRINT CAMERA CONFIGURATION

Camera Type:	
Host Name:	
IP Address:	
AE Title:	
TCP/IP Listen Port:	
Comments (Optional):	
Valid Film Formats:	
Default Film Formats:	
Destination:	
Orientation:	
Medium Type:	
Magnification Type:	

Table 6-6 DICOM Print Camera Configuration

DICOM PRINT CAMERA ADVANCE CONFIGURATION	
Smoothing Type:	
Configuration:	
Minimum Density:	
Maximum Density:	
Empty Density:	
Border Density:	
Association Timeout:	
Session Timeout:	
N-Set Timeout:	
N-Action Timeout:	
N-Create Timeout:	
N-Delete Timeout:	
N-Get Timeout:	

Table 6-7 DICOM Print Camera Advanced Configuration

CONFIGURATION

Note: Type the text shown in **boldface**, and press the ENTER key on the keyboard.

NEXT STEPS

Resume installation following instructions in [Chapter 2: Restore System State \(Section 2.3\)](#).

AppendixC

Symbols


SYMBOL	PUBLICATION	DESCRIPTION
	417-5032	Alternating Current
	335-1	Three-phase Alternating Current
	335-1	Three-phase Alternating Current with neutral conductor
		Direct Current
	417-5019	Protective Earth (Ground)
	348	Attention, consult ACCOMPANYING DOCUMENTS
	417-5008	OFF (Power: disconnection from the mains)
	417-5007	ON (Power: connection to the mains)
		Warning, HIGH VOLTAGE
		Emergency Stop
		Type B

Table 6-8 Symbols

SYMBOL	PUBLICATION	DESCRIPTION
	417-5339	X-ray Source Assembly Emitting
	417-5009	Standby
		Start
		Table Set
		Abort
		Intercom
		(on Operator Console) Power On: light on Standby: light off

Table 6-8 Symbols



GE MEDICAL SYSTEMS

***GE MEDICAL SYSTEMS-AMERICAS: FAX 262.312.7434
3000 N. GRANDVIEW BLVD., WAUKESHA, WI 53188 U.S.A.***

***GE MEDICAL SYSTEMS-EUROPE: FAX 33.1.40.93.33.33
PARIS, FRANCE***

***GE MEDICAL SYSTEMS-ASIA: FAX 65.291.7006
SINGAPOR***