

INSTALLER: LEAVE THIS MANUAL WITH THE APPLIANCE.
CONSUMER: RETAIN THIS MANUAL FOR FUTURE REFERENCE.
NEVER LEAVE CHILDREN OR OTHER AT RISK INDIVIDUALS ALONE WITH THE APPLIANCE.



INSTALLATION AND OPERATING INSTRUCTIONS

CERTIFIED UNDER CANADIAN AND AMERICAN NATIONAL STANDARDS, CR97-003, CAN1-2.21-M85, IAS U.S. 4-96.

OUTDOOR GAS FIREPLACE

CERTIFIED FOR CANADA AND UNITED STATES USING ANSI/CSA METHODS.

SAFETY INFORMATION

! WARNING

If the information in these instructions are not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- WHAT TO DO IF YOU SMELL GAS:
 - Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the supplier.

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.




Serial No. XXXXXXXX000000
MODEL NO. []

GSS42N

NATURAL GAS MODEL

GSS42P

PROPANE GAS MODEL



WARNING: FOR OUTDOOR USE ONLY

! WARNING

HOT GLASS WILL CAUSE BURNS.



DO NOT TOUCH GLASS UNTIL COOLED.

NEVER ALLOW CHILDREN TO TOUCH GLASS.



Wolf Steel Ltd., 24 Napoleon Rd., Barrie, ON, L4M 0G8 Canada /
103 Miller Drive, Crittenden, Kentucky, USA, 41030


Phone (705)721-1212 • Fax (705)722-6031 • www.napoleonfireplaces.com • ask@napoleonproducts.com

TABLE OF CONTENTS

1.0	INSTALLATION OVERVIEW	2
2.0	INTRODUCTION	3
2.1	DIMENSIONS	4
2.2	GENERAL INSTRUCTIONS	4
2.3	GENERAL INFORMATION	5
2.4	RATING PLATE INFORMATION	5
3.0	INSTALLATION	6
3.1	GAS INSTALLATION	6
3.2	GAS INLET LOCATIONS	7
3.3	OPTIONAL WALL SWITCH INSTALLATION	7
3.4	COMBUSTION AND VENTILATION AIR	8
4.0	FRAMING	8
4.1	CLEARANCE TO COMBUSTIBLES	8
4.2	MINIMUM ENCLOSURE CLEARANCES	10
4.3	MINIMUM MANTEL CLEARANCES	11
4.4	NAILING TAB	11
5.0	FINISHING	12
5.1	ANDIRON AND GRATE ASSEMBLY	12
5.2	LOG PLACEMENT	12
5.3	GLOWING EMBERS	13
5.4	CHARCOAL LUMPS/LAVA ROCK	13
5.5	HOOD	14
5.6	LOGO PLACEMENT	14
6.0	OPTIONAL REMOTE INSTALLATION	15
7.0	OPERATION	16
8.0	ADJUSTMENT	17
8.1	VENTURI ADJUSTMENT	17
8.2	FLAME CHARACTERISTICS	17
9.0	MAINTENANCE	18
10.0	REPLACEMENTS	19
11.0	TROUBLESHOOTING	21
12.0	WARRANTY	23

NOTE: Changes, other than editorial, are denoted by a vertical line in the margin.

1.0 INSTALLATION OVERVIEW




2.0 INTRODUCTION

WARNING

- **THIS APPLIANCE IS HOT WHEN OPERATED AND CAN CAUSE SEVERE BURNS IF CONTACTED.**
- Do not operate appliance before reading and understanding operating instructions. Failure to operate appliance according to operating instructions could cause fire or injury.
- Any changes to this appliance or its controls can be dangerous and is prohibited.
- Risk of burns. The appliance should be turned off and cooled before servicing.
- Do not install damaged, incomplete or substitute components.
- Risk of cuts and abrasions. Wear protective gloves and safety glasses during installation. Sheet metal edges may be sharp.
- Do not burn wood or other materials in this appliance.
- Provide adequate ventilation and combustion air. Provide adequate accessibility clearance for servicing and operating the appliance. Never obstruct the front opening of the appliance.
- If appliance keeps shutting off, have it serviced. Keep burner and control compartment clean.
- Do not allow wind to blow directly into the appliance. Avoid any drafts that alter burner flame patterns.
- Children and adults should be alerted to the hazards of high surface temperature and should stay away to avoid burns or clothing ignition.
- Young children should be carefully supervised when they are in the same area as the appliance. Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at risk individuals in the vicinity of the appliance. To restrict access to an appliance, install an adjustable safety gate to keep toddlers, young children and other at risk individuals away from hot surfaces.
- Clothing or other flammable material should not be placed on or near the appliance.
- Furniture or other objects must be kept a minimum of 4 feet away from the front of the appliance.
- Ensure you have incorporated adequate safety measures to protect infants/toddlers from touching hot surfaces.
- Even after the appliance is off, it will remain hot for an extended period of time.
- Check with your local hearth specialty dealer for safety screens and hearth guards to protect children from hot surfaces. These screens and guards must be fastened to the floor.
- Any safety screen or guard removed for servicing must be replaced prior to operating the appliance.
- It is imperative that the control compartments, burners and circulating blower and its passageway in the appliance and venting system are kept clean. The appliance should be inspected before use and at least annually by a qualified service person. The appliance area must be kept clear and free from combustible materials, gasoline and other flammable vapors and liquids.
- Under no circumstances should this appliance be modified.
- Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
- Keep the packaging material out of reach of children and dispose of the material in a safe manner. As with all plastic bags, these are not toys and should be kept away from children and infants.
- This appliance must not be installed indoors or within any structure that prevents or inhibits the exhaust gases from dissipating in the outside atmosphere.

3.14A

2.1 DIMENSIONS



2.2 GENERAL INSTRUCTIONS

! WARNING

**ALWAYS LIGHT THE PILOT WHETHER FOR THE FIRST TIME OR IF THE GAS SUPPLY HAS RAN OUT,
WITH THE GLASS DOOR OPENED OR REMOVED.**

NEVER OBSTRUCT THE FRONT OPENING OF THE APPLIANCE.

**OBJECTS PLACED IN FRONT OF THE APPLIANCE MUST BE KEPT A MINIMUM OF 48" FROM THE
FRONT FACE OF THE APPLIANCE.**

FIRE RISK. EXPLOSION HAZARD.

**HIGH PRESSURE WILL DAMAGE VALVE. DISCONNECT GAS SUPPLY PIPING BEFORE PRESSURE
TESTING GAS LINE AT TEST PRESSURES ABOVE 1/2 PSIG. CLOSE THE MANUAL SHUT-OFF VALVE
BEFORE PRESSURE TESTING GAS LINE AT TEST PRESSURES EQUAL TO OR LESS THAN 1/2 PSIG.**

**USE ONLY WOLF STEEL APPROVED OPTIONAL ACCESSORIES AND REPLACEMENT PARTS WITH
THIS APPLIANCE. USING NON-LISTED ACCESSORIES (BLOWERS, DOORS, LOUVRES, TRIMS, GAS
COMPONENTS, VENTING COMPONENTS, ETC.) COULD RESULT IN A SAFETY HAZARD AND WILL
VOID THE WARRANTY AND CERTIFICATION.**

**THE APPLIANCE IS ONLY FOR USE WITH THE TYPE OF GAS INDICATED ON THE RATING PLATE.
THIS APPLIANCE IS NOT CONVERTIBLE FOR USE WITH OTHER GASES.**

THIS GAS APPLIANCE SHOULD BE INSTALLED AND SERVICED BY A QUALIFIED INSTALLER to conform with local codes. Installation practices vary from region to region and it is important to know the specifics that apply to your area, for example in Massachusetts State:

- The appliance off valve must be a "T" handle gas cock.
- The flexible connector must not be longer than 36 inches.

The installation must conform with local codes or, in absence of local codes, the National Gas and Propane Installation Code CSA B149.1 in Canada, or the National Fuel Gas Code, ANSI Z223.1 / NFPA 54 in the United States.



We suggest that our gas hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Gas Specialists

The appliance and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5 kPa). The appliance must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.5 kPa).

When the appliance is installed directly on combustible material other than wood flooring, the appliance shall be installed on a metal or wood panel extending the full width and depth.

2.3 GENERAL INFORMATION

FOR YOUR SATISFACTION, THIS APPLIANCE HAS BEEN TEST-FIRED TO ASSURE ITS OPERATION AND QUALITY!

RATES AND EFFICIENCIES		
	NATURAL GAS	PROPANE GAS
Altitude	0 - 2,000*	0 - 2,000*
Maximum Input	65,000 BTU/hr	65,000 BTU/hr
Minimum Inlet Gas Supply Pressure	4.5" Water Column	11" Water Column
Maximum Inlet Gas Supply Pressure	7" Water Column	13" Water Column
Manifold Pressure Under Flow Conditions	3.5" Water Column	10" Water Column

* When the appliance is installed at elevations above 2,000ft, and in the absence of specific recommendations from the local authority having jurisdiction, the certified high altitude input rating shall be reduced at the rate of 4% for each additional 1,000ft.

It is highly recommended to protect the logs from moisture (rain, snow). Cover the enclosure opening when not in use.

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

No external electricity (110 volts or 24 volts) is required for the gas system operation.

Expansion / contraction noises during heating up and cooling down cycles are normal and are to be expected.

2.4 RATING PLATE INFORMATION

For rating plate location, see "INSTALLATION OVERVIEW" section.

This illustration is for reference only. Refer to the rating plate on the appliance for accurate information.



3.0 INSTALLATION

3.1 GAS INSTALLATION

! WARNING

RISK OF FIRE, EXPLOSION OR ASPHYXIATION. ENSURE THERE ARE NO IGNITION SOURCES SUCH AS SPARKS OR OPEN FLAMES.

SUPPORT GAS CONTROL WHEN ATTACHING GAS SUPPLY PIPE TO PREVENT DAMAGING GAS LINE.

ALWAYS LIGHT THE PILOT WHETHER FOR THE FIRST TIME OR IF THE GAS SUPPLY HAS RUN OUT WITH THE GLASS DOOR OPENED OR REMOVED. PURGING OF THE GAS SUPPLY LINE SHOULD BE PERFORMED BY A QUALIFIED SERVICE TECHNICIAN. ASSURE THAT A CONTINUOUS GAS FLOW IS AT THE BURNER BEFORE CLOSING THE DOOR. ENSURE ADEQUATE VENTILATION. FOR GAS AND ELECTRICAL LOCATIONS, SEE "DIMENSION" SECTION.

ALL GAS CONNECTIONS MUST BE CONTAINED WITHIN THE APPLIANCE WHEN COMPLETE.

HIGH PRESSURE WILL DAMAGE VALVE. DISCONNECT GAS SUPPLY PIPING BEFORE TESTING GAS LINE AT TEST PRESSURES ABOVE 1/2 PSIG.

VALVE SETTINGS HAVE BEEN FACTORY SET, DO NOT CHANGE.


Installation and servicing to be done by a qualified installer.

- A. Move the appliance into position and secure.
- B. If equipped with a flex connector the appliance is designed to accept a 1/2" gas supply. Without the connector it is designed to accept a 3/8" gas supply. The appliance is equipped with a manual shut off valve to turn off the gas supply to the appliance.
- C. Connect the gas supply in accordance to local codes. In the absence of local codes, install to the current CAN/CSA-B149.1 Installation Code in Canada or to the current National Fuel Gas Code, ANSI Z223.1 / NFPA 54 in the United States.
- D. When flexing any gas line, support the gas valve so that the lines are not bent or kinked.
- E. The gas line flex-connector should be installed to provide sufficient movement for shifting the burner assembly on its side to aid with servicing components.
- F. Check for gas leaks by brushing on a soap and water solution. **Do not use open flame.**

30.1A

3.2 GAS INLET LOCATIONS

There are five gas inlet locations on the ventless firebox enclosure. One on each side of the appliance, two at the rear, and one on the bottom. Using the following illustrations identify the preferred inlet and remove corresponding knock out.




3.3 OPTIONAL WALL SWITCH INSTALLATION

WARNING

DO NOT CONNECT EITHER THE WALL SWITCH, THERMOSTAT OR GAS VALVE DIRECTLY TO 110 VOLT ELECTRICITY.

For ease of accessibility, an optional remote wall switch or millivolt thermostat may be installed in a convenient location. Route a 2 strand, solid core millivolt wire from the valve to the wall switch or millivolt thermostat. The recommended maximum lead length depends on wire size:

WIRE SIZE	MAX. LENGTH
14 gauge	100 feet
16 gauge	60 feet
18 gauge	40 feet



Disconnect the existing wires from terminals 1 and 3 (from the ON/OFF switch) and replace with the leads from the wall switch / millivolt thermostat.

3.4 COMBUSTION AND VENTILATION AIR

This appliance is intended for installation on an outdoor patio or in your yard. It must never be installed inside the warm air envelope of your structure.

It is highly recommended that this appliance be installed in a “sheltered” area. Direct wind will cause an erratic flame and possible pilot or main burner outage.

An erratic flame could also lead to excessive carboning (black soot), this condition is not a safety issue but is visually undesirable.

Typical installation may include covered patio, screened porch, gazebo or on an outside wall of a house.

*** If installing a propane appliance the propane cylinder must always be on the exterior of such a structure.**

NOTE: Ensure the area has adequate ventilation.

4.0 FRAMING

4.1 CLEARANCE TO COMBUSTIBLES

 WARNING RISK OF FIRE!	
IN ORDER TO AVOID THE POSSIBILITY OF EXPOSED INSULATION OR VAPOUR BARRIER COMING IN CONTACT WITH THE APPLIANCE BODY, IT IS RECOMMENDED THAT THE WALLS OF THE APPLIANCE ENCLOSURE BE “FINISHED” (IE: DRYWALL / SHEETROCK), AS YOU WOULD FINISH ANY OTHER OUTSIDE WALL OF A HOME. THIS WILL ENSURE THAT CLEARANCE TO COMBUSTIBLES IS MAINTAINED WITHIN THE CAVITY.	
DO NOT NOTCH THE FRAMING AROUND THE APPLIANCE STAND-OFFS. FAILURE TO MAINTAIN AIR SPACE CLEARANCE MAY CAUSE OVER HEATING AND FIRE. PREVENT CONTACT WITH SAGGING OR LOOSE INSULATION OR FRAMING AND OTHER COMBUSTIBLE MATERIALS. BLOCK OPENING INTO THE CHASE TO PREVENT ENTRY OF BLOWN-IN INSULATION. MAKE SURE INSULATION AND OTHER MATERIALS ARE SECURED.	
WHEN CONSTRUCTING THE ENCLOSURE ALLOW FOR FINISHING MATERIAL THICKNESS TO MAINTAIN CLEARANCES. FRAMING OR FINISHING MATERIAL CLOSER THAN THE MINIMUMS LISTED MUST BE CONSTRUCTED ENTIRELY OF NON-COMBUSTIBLE MATERIALS. MATERIALS CONSISTING ENTIRELY OF STEEL, IRON, BRICK, TILE, CONCRETE, SLATE, GLASS OR PLASTERS, OR ANY COMBINATION THEREOF ARE SUITABLE. MATERIALS THAT ARE REPORTED AS PASSING ASTM E 136, STANDARD TEST METHOD FOR BEHAVIOUR OF MATERIALS IN A VERTICAL TUBE FURNACE AT 750°C AND UL763 SHALL BE CONSIDERED NON-COMBUSTIBLE MATERIALS.	
MINIMUM CLEARANCE TO COMBUSTIBLES MUST BE MAINTAINED OR A SERIOUS FIRE HAZARD COULD RESULT.	
THE APPLIANCE REQUIRES A MINIMUM ENCLOSURE HEIGHT. MEASURE FROM THE APPLIANCE BASE.	
IF STEEL STUD FRAMING KITS WITH CEMENT BOARD ARE PROVIDED, THEY MUST BE INSTALLED.	


71.1

Minimum Clearance to Combustibles construction from appliance and vent surfaces:

Framing	0" to stand-offs (rear and sides only) Use a steel header for the top and two steel studs on the sides.
Finishing	1" to back and sides
Non-combustible finishing	18" to top 4" to sides of appliance opening Non-combustible finishing material (ie. cement board, brick, stone, tile) may be used to finish the front of the appliance.
Recessed depth	22 1/4"
Enclosure top	58 1/2" from bottom of appliance
Clearance to ceiling	84" from bottom of appliance.

It is recommended that the walls of the appliance enclosure be finished. This would ensure that clearance to combustibles is maintained within the cavity.

It is best to frame your appliance after it is positioned. Use 2x4's and frame to local building codes.




!WARNING


USE ONLY NON-COMBUSTIBLE MATERIAL SUCH AS CEMENT BOARD, CERAMIC TILE, MARBLE, ETC. WHEN FINISHING TO THE APPLIANCE. DO NOT USE WOOD OR DRYWALL.

*From top of unit.

** An outdoor sealant must be used along the edge of the fireplace and the non-combustible material to keep water from entering the chase.



4.2 MINIMUM ENCLOSURE CLEARANCES



This appliance requires a minimum enclosure height of 58 1/2"

For temperature requirements, the enclosure space around and above the fireplace must be left unobstructed.

4.3 MINIMUM MANTEL CLEARANCES

⚠️ WARNING



RISK OF FIRE, MAINTAIN ALL SPECIFIED AIR SPACE CLEARANCES TO COMBUSTIBLES. FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE A FIRE OR CAUSE THE APPLIANCE TO OVERHEAT. ENSURE ALL CLEARANCES (I.E. BACK, SIDE, TOP, VENT, MANTEL, FRONT, ETC.) ARE CLEARLY MAINTAINED.

WHEN USING PAINT OR LACQUER TO FINISH THE MANTEL, THE PAINT OR LACQUER MUST BE HEAT RESISTANT TO PREVENT DISCOLOURATION.

73.1


We recommend all mantels made from non-combustible material. If using combustible materials, follow the chart below.

NOTE: Mantel temperatures will rise above normal temperatures and may be hot to the touch.



4.4 NAILING TAB


To install the appliance face flush with the finished surface, position the framework to accommodate the thickness of the finished surface. Bend out the six nailing tabs, attached on top and on either side of the appliance and secure to the 2x4 framing. The tabs will facilitate the installation of either a $\frac{1}{2}$ " or $\frac{3}{4}$ " finished surface thickness.



5.0 FINISHING

5.1 ANDIRON AND GRATE ASSEMBLY

- A. With the 2 andirons laying face down, secure the grate overtop using 2 of the 1" hex head screws (supplied in the manual baggie).
- B. Install the grate/andiron assembly to the burner base using 4 x 1" hex head screws (supplied in the manual baggie).



5.2 LOG PLACEMENT

! WARNING


FAILURE TO POSITION THE LOGS IN ACCORDANCE WITH THESE DIAGRAMS OR FAILURE TO USE ONLY LOGS SPECIFICALLY APPROVED WITH THIS APPLIANCE MAY RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.

LOGS MUST BE PLACED IN THEIR EXACT LOCATION IN THE APPLIANCE. DO NOT MODIFY THE PROPER LOG POSITIONS, SINCE APPLIANCE MAY NOT FUNCTION PROPERLY AND DELAYED IGNITION MAY OCCUR.


THE LOGS ARE FRAGILE AND SHOULD BE HANDLED WITH CARE.

76.1A


PHAZER™ logs and glowing embers exclusive to Napoleon, provide a unique and realistic glowing effect that is different in every installation. Take the time to carefully position the glowing embers for a maximum glowing effect. Log colours may vary. During the initial use of the appliance, the colours will become more uniform as colour pigments burn in during the heat activated curing process.




- A. Place the rear log #1 onto the locating pins along the back edge of the burner.



- B. Position log #2 onto the locator pins on the burner. Ensure the port cavity on the underside of the log is positioned such that it runs over the ports allowing them to be exposed.



- C. Place the end of log #3 on the right side of the knot of log #1. The "Y" in the log should straddle the knot on top of log #2.



- D. Place locating pin in the end of log #4 into the hole in log #2. Place the locating pin on the underside of the "Y" in log #4 into the hole in log #1.



- E. Position the slot in the bottom of log #5 onto the bracket beside the burner on the right, and against the back side of the andiron with the charred face of the log to the front.

IMPORTANT

IT IS HIGHLY RECOMMENDED TO PROTECT THE LOGS FROM MOISTURE.
COVER THE FIREBOX WHEN NOT IN USE.

5.3 GLOWING EMBERS

Glowing embers (not supplied) may be used to enhance the flame's appearance.

5.4 CHARCOAL LUMPS/LAVA ROCK

- A. Place lava rock around the base of the fireplace, making sure not to block any burner ports or valve access. Retain a small amount of lava rock for step C.
- B. Place formed charcoal lumps around the front and sides of the unit.
- C. Use remaining lava rock to blend with the charcoal lumps.




5.5 HOOD

WARNING

DO NOT OPERATE WITHOUT HOOD IN PLACE. THE APPLIANCE HOOD MUST NOT BE MODIFIED OR REPLACED WITH ANOTHER HOOD.


NOTE: Remove the hood from the inside of the appliance by cutting the strap holding it in place.

- A. Line the 3 tabs on the back of the hood up with the 3 slots in the appliance front.
- B. Tilt the hood to insert the tabs into the slots and allow the hood to come forward and rest against the firebox.




5.6 LOGO PLACEMENT

Remove the backing of the logo supplied. Centre the logo on the front of the appliance, $\frac{1}{2}$ " in from the left side, as shown.



6.0 OPTIONAL REMOTE INSTALLATION



- A. Remove the battery pack from the receiver, then by pulling down remove the receiver cover slide the receiver into the hole located at the rear of the burner base. Secure using the two screws provided.
- B. Secure the faceplate to the receiver with two of the screws provided.
- C. Insert the battery pack (with batteries installed) through the opening in the faceplate and into the receiver. The battery pack is secured and released with a catch mechanism, push the receiver into the catch to secure.
- D. Insert the slide switch into its marked position on the faceplate.
- E. Replace the existing switch wires connected to the terminals on the valve marked TH/TP and TH with those running from the receiver.

NOTE: The remote switch on the side of the unit is no longer operational.

7.0 OPERATION

!WARNING

IF YOU DO NOT FOLLOW THESE INSTRUCTIONS EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.

When lit for the first time, the appliance will emit an odor for a few hours. This is a normal temporary condition caused by the “burn-in” of paints and lubricants used in the manufacturing process and will not occur again. After extended periods of non-operation such as following a vacation or a warm weather season, the appliance may emit a slight odor for a few hours. This is caused by dust particles in the heat exchanger burning off. In both cases, sufficiently ventilate the area.

FOR YOUR SAFETY READ BEFORE LIGHTING:

- A. This appliance is equipped with a pilot which must be lit by hand while following these instructions exactly.
- B. Before operating smell all around the appliance area for gas and next to the floor because some gas is heavier than air and will settle on the floor.
- C. Use only your hand to turn the gas control knob. Never use tools. If the knob will not turn by hand, do not try to repair it. Call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and replace any part of the control system and any gas control which has been under water.

WHAT TO DO IF YOU SMELL GAS:

- Do not use a mobile or land phone.
- If you cannot reach your gas supplier, call the fire department.
- Do not try to light any appliance.
- Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
- Turn off all gas to the appliance.

LIGHTING INSTRUCTIONS:

1. Stop! Read the above safety information on this label.
2. Turn the gas knob clockwise  to off.
3. Wait five (5) minutes to clear out any gas. If you smell gas including near the floor, **STOP!** Follow “B” in the above safety information on this label. If you don't smell gas go to the next step.
4. If the appliance is equipped with flame adjustment valve turn clockwise  to off.
5. Find pilot located in front of back log.
6. Turn gas knob counter-clockwise  to pilot.
7. Depress and hold gas knob while lighting the pilot with the push button igniter. Keep knob fully depressed for one minute, then release. If pilot does not continue to burn repeat steps 3 through 7.
8. With pilot lit, turn gas knob counter-clockwise  to on.
9. If equipped with flame adjustment valve, push and turn knob to high.
10. If equipped with remote on-off switch, main burner may not come on when you turn the valve to on or high. Remote switch must be in the on position to ignite burner.

TO TURN OFF GAS:

Push in gas control knob slightly and turn clockwise  to off. DO NOT FORCE.

8.0 ADJUSTMENT

8.1 VENTURI ADJUSTMENT


! WARNING

CARBON CAN BE DISTRIBUTED IN SURROUNDING LIVING AREA IF THE AIR SHUTTER IS IMPROPERLY ADJUSTED.

This appliance has an air shutter that has been factory set open according to the chart below:

Regardless of venturi orientation, closing the air shutter will cause a more yellow flame, but can lead to carboning. Opening the air shutter will cause a more blue flame, but can cause flame lifting from the burner ports. The flame may not appear yellow immediately; allow 15 to 30 minutes for the final flame colour to be established.


AIR SHUTTER ADJUSTMENT MUST ONLY BE DONE BY A QUALIFIED INSTALLER!




GSS42	
NG	1/8"
LP	1/4"

8.2 FLAME CHARACTERISTICS

It's important to periodically perform a visual check of the pilot and burner flames. Compare them to the illustrations provided. If any flames appear abnormal call a service person.



FLAME MUST ENVELOP UPPER 3/8" TO 1/2" OF THERMOCOUPLE & THERMOPILE



9.0 MAINTENANCE

!WARNING

TURN OFF THE GAS AND ELECTRICAL POWER BEFORE SERVICING THE APPLIANCE.

APPLIANCE MAY BE HOT, DO NOT SERVICE UNTIL APPLIANCE HAS COOLED.

DO NOT USE ABRASIVE CLEANERS.

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing. This appliance and its venting system should be inspected before use and at least annually by a qualified service person. The appliance area must be kept clear and free of combustible materials, gasoline or other flammable vapors and liquids. The flow of combustion and ventilation air must not be obstructed.

1. In order to properly clean the burner and pilot assembly, remove the logs, rocks and/or glass to expose both assemblies.
2. Keep the control compartment, media, burner, air shutter opening and the area surrounding the logs clean by vacuuming or brushing, at least once a year.
3. Check to see that all burner ports are burning. Clean out any of the ports which may not be burning or are not burning properly.
4. Check to see that the pilot flame is large enough to engulf the flame sensor and/or thermocouple / thermopile as well as reaches the burner.
5. Replace the cleaned logs, rocks or glass. Failure to properly position the media may cause carboning which can be distributed in the surrounding living area.
6. Check to see that the main burner ignites completely on all openings when turned on. A 5 to 10 second total light-up period is satisfactory. If ignition takes longer, consult your local authorized dealer / distributor.

40.16

Stainless steel tends to oxidize or stain in the presence of chlorides and sulfides, particularly in coastal areas and other harsh environments, such as the warm, highly humid atmosphere around pools and hot tubs. These stains could be perceived as rust, but can be easily removed or prevented. To provide stain prevention and removal, wash all stainless steel surfaces every 3-4 weeks or as often as required with fresh water and/or stainless steel cleaner.

CLEANING THE STAINLESS STEEL SURFACE:

Do not use abrasive cleaners or steel wool on the stainless steel parts. Doing so will scratch the finish. Surfaces should be cleaned with warm soapy water while the metal is still warm to the touch. To clean stainless surfaces, use a stainless steel or non-abrasive cleaner. Always wipe in the direction of the grain. Over time, stainless steel parts discolour when heated, usually to a golden or brown hue. This discolouration is normal and does not affect the performance of the appliance.

81.1

10.0 REPLACEMENTS

⚠ WARNING

FAILURE TO POSITION THE PARTS IN ACCORDANCE WITH THIS MANUAL OR FAILURE TO USE ONLY PARTS SPECIFICALLY APPROVED WITH THIS APPLIANCE MAY RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.

**** THIS IS A FAST ACTING THERMOCOUPLE. IT IS AN INTEGRAL SAFETY COMPONENT. REPLACE ONLY WITH A FAST ACTING THERMOCOUPLE SUPPLIED BY WOLF STEEL LTD.**

Contact your dealer or the factory for questions concerning prices and policies on replacement parts. Normally all parts can be ordered through your Authorized dealer / distributor.

FOR WARRANTY REPLACEMENT PARTS, A PHOTOCOPY OF THE ORIGINAL INVOICE WILL BE REQUIRED TO HONOUR THE CLAIM.

When ordering replacement parts always give the following information:

- Model & Serial Number of appliance
- Installation date of appliance
- Part number
- Description of part
- Finish

*** IDENTIFIES ITEMS WHICH ARE NOT ILLUSTRATED. FOR FURTHER INFORMATION, CONTACT YOUR AUTHORIZED DEALER.**

41.2

COMPONENTS


REF NO.	PART NO.	DESCRIPTION
1	W357-0001	PIEZO IGNITER
2	W680-0015	THERMOPILE
3	W680-0014	THERMOCOUPLE**
4	W010-1194	NATURAL GAS PILOT ASSEMBLY
4	W010-1201	PROPANE GAS PILOT ASSEMBLY
5	W455-0070	NATURAL GAS PILOT INJECTOR
5	W455-0068	PROPANE GAS PILOT INJECTOR
6	W725-0028	NATURAL GAS VALVE
6	W725-0029	PROPANE GAS VALVE
7*	W750-0188	WIRE, HARNESS
8*	W456-0023	#23 NATURAL GAS BURNER ORIFICE
8*	W456-0043	#43 PROPANE GAS BURNER ORIFICE
9*	W660-0009	ON/OFF SWITCH
10	W010-1739	BURNER, PAN ASSEMBLY
11*	W240-0005	ELECTRODE LEAD
12*	W385-0334	NAPOLEON® LOGO
13	W335-0048	HOOD
14	W330-0060	HINGE, FEMALE
15	W330-0059	HINGE, FEMALE
16	W330-0062	HINGE, MALE
17*	W325-0028	DOOR HANDLE
18	W300-0093	GLASS
19*	W010-1747	ASSY, MAGNET BRACKET
20	GL-644	LOG SET
21	W135-0205	BACK LOG (#1)
22	W135-0206	MIDDLE LOG (#2)
23	W135-0207	RIGHT LOG (#3)
24	W135-0208	LEFT LOG (#4)
25	W135-0218	CROSSOVER LOG (#5)

COMPONENTS

REF NO.	PART NO.	DESCRIPTION
26	W185-0023	GRATE
27	W715-0629	ANDIRONS
28*	W550-0006	LAVA ROCK
29*	W550-0002	CHARCOAL LUMPS

ACCESSORIES

REF NO.	PART NO.	DESCRIPTION
30	GD840KT	BRICK KIT
31*	W361-0016	GLOWING EMBERS
32*	F40	REMOTE CONTROL



11.0 TROUBLESHOOTING


WARNING

ALWAYS LIGHT THE PILOT WHETHER FOR THE FIRST TIME OR IF THE GAS SUPPLY HAS RAN OUT, WITH THE GLASS DOOR OPEN OR REMOVED.

TURN OFF THE GAS AND ELECTRICAL POWER BEFORE SERVICING THE APPLIANCE.

APPLIANCE MAY BE HOT, DO NOT SERVICE UNTIL APPLIANCE HAS COOLED.

DO NOT USE ABRASIVE CLEANERS.

SYMPTOM	PROBLEM	TEST SOLUTION
Main burner goes out; pilot stays on.	Pilot flame is not large enough or not engulfing the thermopile.	<ul style="list-style-type: none"> - Turn up the pilot flame. - Replace pilot assembly.
	Thermopile shorting.	<ul style="list-style-type: none"> - Clean thermopile connection to the valve. Reconnect. - Replace thermopile / valve.
	Remote wall switch wire is too long; too much resistance in the system.	<ul style="list-style-type: none"> - Shorten wire to connect length or wire gauge.
	Faulty thermostat or switch.	<ul style="list-style-type: none"> - Replace.
Main burner goes out; pilot goes out.	Refer to "MAIN BURNER GOES OUT; PILOT STAYS ON"	
The gas valve has an interlock device which will not allow the pilot burner to be lit until the thermocouple has cooled. Allow approximately 60 seconds for the thermocouple to cool.	System is not correctly purged.	<ul style="list-style-type: none"> - Purge the gas line.
	Out of propane gas.	<ul style="list-style-type: none"> - Fill the tank.
	Pilot flame is not large enough.	<ul style="list-style-type: none"> - Turn up the pilot flame.
	Pilot flame is not engulfing the thermocouple	<ul style="list-style-type: none"> - Gently twist the pilot head to improve the flame pattern around the thermocouple.
	Thermocouple shorting / faulty.	<ul style="list-style-type: none"> - Loosen and tighten thermocouple. - Clean thermocouple and valve connection. - Replace thermocouple. - Replace valve.
	Faulty valve.	<ul style="list-style-type: none"> - Replace.
Pilot burning; no gas to main burner; gas knob is on 'HI'; wall switch / thermostat is on.	Thermostat or switch is defective	<ul style="list-style-type: none"> - Connect a jumper wire across the wall switch terminals; if main burner lights, replace switch / thermostat.
	Wall switch wiring is defective.	<ul style="list-style-type: none"> - Disconnect the switch wires & connect a jumper wire across terminals 1 & 3; if the main burner lights, check the wires for defects and/or replace wires.
	Main burner orifice is plugged.	<ul style="list-style-type: none"> - Remove stoppage in orifice.
Pilot will not light.	Faulty valve.	<ul style="list-style-type: none"> - Replace.
	No spark at pilot burner.	<ul style="list-style-type: none"> - Check if pilot can be lit by a match. - Check that the wire is connected to the push button igniter. - Check if the push button igniter needs tightening. - Replace the wire if the wire insulation is broken or frayed. - Replace the electrode if the ceramic insulator is cracked or broken. - Replace the push button ignitor
	Out of propane gas.	<ul style="list-style-type: none"> - Fill the tank.
	Spark gap is incorrect.	<ul style="list-style-type: none"> - Spark gap should be 0.150" to 0.175" (5/32" to 11/64" approx.) from the electrode tip and the pilot burner. To ensure proper electrode location, tighten securing nut (finger tight plus 1/4 turn).
	No gas at the pilot burner.	<ul style="list-style-type: none"> - Check that the manual valve is turned on. - Check the pilot orifice for blockage. - Replace the valve. - Call the gas distributor.

SYMPTOM	PROBLEM	TEST SOLUTION
Pilot goes out while standing; Main burner is in 'OFF' position.	Gas piping is undersized.	<ul style="list-style-type: none"> - Turn on all gas appliances and see if pilot flame flutters, diminishes or extinguishes, especially when main burner ignites. Monitor appliance supply working pressure. - Check if supply piping size is to code. Correct all undersized piping.
Flames are consistently too large or too small. Carboning occurs.	Unit is over-fired or underfired.	<ul style="list-style-type: none"> - Check pressure readings: - Inlet pressure can be checked by turning screw (A) counter-clockwise 2 or 3 turns and then placing pressure gauge tubing over the test point. Gauge should read 7" (minimum 4.5") water column for natural gas or 13" (minimum 11") water column for propane. Check that main burner is operating on 'HI'. - Outlet pressure can be checked the same as above using screw (B). Gauge should read 3.5" water column for natural gas or 10" water column for propane. Check that main burner is operating on 'HI'. - AFTER TAKING PRESSURE READINGS, BE SURE TO TURN SCREWS CLOCKWISE FIRMLY TO RESEAL. DO NOT OVER TORQUE. - Leak test with a soap and water solution.
Carbon is being deposited on logs or combustion chamber surfaces.	<p>Air shutter has become blocked.</p> <p>Flame is impinging on the logs or combustion chamber.</p>	<ul style="list-style-type: none"> - Ensure air shutter opening is free of lint or other obstructions. - Check that the logs are correctly positioned. - Open air shutter to increase the primary air. - Check the input rate: check the manifold pressure and orifice size as specified by the rating plate values.
White / grey film forms.	Sulphur from fuel is being deposited on glass, logs or combustion chamber surfaces.	<ul style="list-style-type: none"> - Clean the glass with a recommended gas appliance glass cleaner. - DO NOT CLEAN GLASS WHEN HOT. - If deposits are not cleaned off regularly, the glass may become permanently marked.
Remote wall switch is in 'OFF' position; main burner comes on when gas knob is turned to 'ON' position.	<p>Wall switch is mounted upside down.</p> <p>Remote wall switch is grounding.</p> <p>Remote wall switch wire is grounding.</p> <p>Faulty valve.</p>	<ul style="list-style-type: none"> - Reverse. - Replace. - Check for ground (short); repair ground or replace wire. - Replace.

42.10_2

12.0 WARRANTY

NAPOLEON® gas appliances are manufactured under the strict Standard of the world recognized
ISO 9001 : 2008 Quality Assurance Certificate.

NAPOLEON® products are designed with superior components and materials, assembled by trained craftsmen who take great pride in their work. The burner and valve assembly are leak and test-fired at a quality test station. Once assembled the complete appliance is thoroughly inspected by a qualified technician before packaging to ensure that you, the customer, receives the quality product that you expect from NAPOLEON®.

NAPOLEON® GAS APPLIANCE 5 YEAR LIMITED WARRANTY

All stainless steel components of your new NAPOLEON® gas appliance are warranted against defects for five years.

All parts such as gas valves, logs, gasketing are covered and NAPOLEON® will provide replacement parts free of charge during the first year of the limited warranty.*

Labour related to warranty repair is covered free of charge during the first year. Repair work, however, requires the prior approval of an authorized company official. Labour costs to the account of NAPOLEON® are based on a predetermined rate schedule and any repair work must be done through an authorized NAPOLEON® dealer.

* Construction of models vary. Warranty applies only to components included with your specific appliance.

CONDITIONS AND LIMITATIONS

NAPOLEON® warrants its products against manufacturing defects to the original purchaser only. Registering your warranty is not necessary. Simply provide your proof of purchase along with the model and serial number to make a warranty claim. NAPOLEON® reserves the right to have its representative inspect any product or part thereof prior to honouring any warranty claim. Provided that the purchase was made through an authorized NAPOLEON® dealer your appliance is subject to the following conditions and limitations:

Warranty coverage begins on the date of original installation.

This limited warranty applies only while the unit remains at the site of original installation, and only if the unit is installed in Canada or the United States.

This factory warranty is nontransferable and may not be extended whatsoever by any of our representatives.

Installation must be done in accordance with the installation instructions included with the product and all local and national building and fire codes. This limited warranty does not cover damages caused by misuse, lack of maintenance, accident, alterations, abuse or neglect and parts installed from other manufacturers will nullify this warranty.

This limited warranty further does not cover any scratches, dents, corrosion or discolouring caused by excessive heat, abrasive and chemical cleaners, mechanical breakage of logs and embers.

In the first year only, this warranty extends to the repair or replacement of warranted parts which are defective in material or workmanship provided that the product has been operated in accordance with the operation instructions and under normal conditions.

After the first year, with respect to this Limited Warranty, NAPOLEON® may, at its discretion, fully discharge all obligations with respect to this warranty by refunding to the original warranted purchaser the wholesale price of any warranted but defective part(s).

After the first year, NAPOLEON® will not be responsible for installation, labour or any other costs or expenses related to the reinstallation of a warranted part, and such expenses are not covered by this warranty.

Notwithstanding any provisions contained in this Limited Warranty, NAPOLEON'S responsibility under this warranty is defined as above and it shall not in any event extend to any incidental, consequential or indirect damages.

This warranty defines the obligations and liability of NAPOLEON® with respect to the NAPOLEON® gas appliance and any other warranties expressed or implied with respect to this product, its components or accessories are excluded.

This limited warranty does not cover damages resulting from the use of components not supplied with the appliance, or the use of fuel other than those specified.

Any damages to appliance due to weather, long periods of dampness, condensation, damaging chemicals or cleaners will not be the responsibility of NAPOLEON®.

The bill of sale or copy will be required together with a serial number and a model number when making any warranty claims from your authorized dealer. The warranty registration card must be returned within fourteen days to register the warranty.

NAPOLEON® reserves the right to have its representative inspect any product or part thereof prior to honouring any warranty claim.

All parts replaced under the Limited warranty policy are subject to a single claim.

All parts replaced under the warranty will be covered for a period of 90 days from the date of their installation.

The manufacturer may require that defective parts or products be returned or that digital pictures be provided to support the claim. Returned products are to be shipped prepaid to the manufacturer for investigation. If a product is found to be defective, the manufacturer will repair or replace such defect.

Before shipping your appliance or defective components, your dealer must obtain an authorization number. Any merchandise shipped without authorization will be refused and returned to sender.

Shipping costs are not covered under this warranty.

Additional service fees may apply if you are seeking warranty service from a dealer.

Labour, travel, diagnostic tests, shipping and other related charges are not covered by this warranty.

ALL SPECIFICATIONS AND DESIGNS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE DUE TO ON-GOING PRODUCT IMPROVEMENTS.
NAPOLEON® IS A REGISTERED TRADEMARK OF WOLF STEEL LTD.



Other products available from your
Authorized Napoleon® Fireplace Dealer...



Patio Heaters



Fireplace Mantels



HVAC Products



Electric Fireplaces



Outdoor Living Products



Fireplace Accessories

Contact your Authorized Napoleon® dealer or visit napoleonfireplaces.com for more information.

ou visitez le napoleonfoyers.com.

Pour de plus amples renseignements, contactez votre détaillant Napoleon® autorisé

Accessoires de foyer



Produits de divertissement extérieurs



Foyers électriques



Produits HVAC



Manteaux de foyer



Chauffes-patios




Autres produits offerts chez votre
détailleur de foyers Napoleon® autorisé . . .

FOYERS DE QUALITÉ

NAPOLÉON®

SYMPOME PROBLEME SOLUTIONS

Vérfifiez la pression : Pour vérifier la pression d'arrivée, tournez deux ou trois fois la vis (A) vers la gauche, puis emboutissez le tube du manomètre sur la pointe dessai. Le manomètre doit indiquer "7" (minimum 4,5") de colonne d'eau pour le propane. Assurez-vous que le gaz naturel ou 13" (minimum 11") de colonne d'eau pour le propane. Assurez-vous que le brûleur principal fonctionne à "HI".	-	La pression doit être vérifiée de la même façon lorsque vous ouvrez l'ouverture du vollet d'air n'est pas bloquée par des fibres ou autres obstructions.	-	Le vollet d'air est bloqué.	Du carbone se dépose sur les bûches ou la chambre de combustion.
Assurez-vous que l'ouverture du vollet d'air n'est pas bloquée pour des fibres ou autres obstructions.	-	Vérfiez pour des fuites en appliquant une solution d'eau savonneuse.	-	Vérfiez pour des fuites en appliquant une solution d'eau savonneuse.	Vérfiez si les bûches sont positionnées correctement.
Assurez-vous que l'ouverture du vollet d'air n'est pas bloquée par des fibres ou autres obstructions.	-	Au moins d'air primaire. Vérfiez si les bûches sont positionnées correctement.	-	Au moins d'air primaire. Vérfiez le débit d'air pour augmenter le volume d'air primaire.	La flamme effrite les bûches ou la chambre de combustion.
Assurez-vous que l'ouverture du vollet d'air n'est pas bloquée par des fibres ou autres obstructions.	-	Au moins d'air pour augmenter le débit d'air pour augmenter le volume d'air primaire.	-	Au moins d'air pour augmenter le débit d'air pour augmenter le volume d'air primaire.	Le souffre du combustible se dépose sur la vitre, les bûches ou les parois de la chambre de combustion.
Nettoyez la vitre avec un nettoyeur recommandé.	-	Nettoyez la vitre avec un nettoyeur recommandé.	-	Nettoyez la vitre avec un nettoyeur recommandé.	Une pellicule blanche ou grise se forme.
NE PAS NETTOYER LORSQU'ELLE EST CHAUDE.	-	Si vous ne nettoyez pas assez tôt, la peinture risque de rester marquée en permanence.	-	Si vous ne nettoyez pas assez tôt, la peinture risque de rester marquée en permanence.	Une pellicule blanche ou grise se forme.
EST A « OFF », LE BRÛLEUR PRINCIPAL S'ALLUME lorsqu'il est tenu à « ON ».	-	Le fil de l'interrupteur mural cause un court-circuit.	-	Le fil de l'interrupteur mural cause un court-circuit.	Le bouton du gaz coupe le brûleur principal.
L'interrupteur mural raccorde à l'envers.	-	Raccordez à l'envers.	-	Raccordez à l'envers.	L'interrupteur mural cause un court-circuit.
REEMPLACÉZ LA TERRE.	-	Remplacez.	-	Remplacez.	La souape est défectueuse.




SYMPOME PROBLEME SOLUTIONS

! AVERTISSEMENT

ALLUMEZ TOUJOURS LA VEILLEUSE, QUE CE SOIT POUR LA PREMIÈRE FOIS OU LORSQUE
L'APPARÉIL PROVISENEMENT EN GAZ EST ÉPUISÉ, AVEC LA PORTE VITREE OUVERTE OU RETIRÉE.
COUPEZ L'ALIMENTATION EN GAZ ET L'ALIMENTATION ÉLECTRIQUE AVANT DE PROCÉDER À
LENTRÉE D'APPAREIL.
L'APPAREIL PEUT ÊTRE CHAUD. N'EFFETUEZ AUCUN ENTRETIEN JUSQU'À CE QUE L'APPAREIL
SOIT REFROIDI.

N'UTILISEZ PAS DE NETTOYANTS ABRASIFS.



COMPOSANTS		
Nº REF.	Nº PIÈCE	DESCRIPTION
26	W185-0023	CHENET
27	W715-0629	BORNES DE CHENET
28*	W550-0006	PERRRES DE LAVE
29*	W550-0002	MORCEAUX DE CHARBON
30	GD840KT	PANNEAUX SIMILIBRIGUE
31*	W361-0016	BRASSES INCANDESCENTES
32*	F40	TELECOMMANDE

ACCESOIRES		
Nº REF.	Nº PIÈCE	DESCRIPTION
26	W185-0023	CHENET
27	W715-0629	BORNES DE CHENET
28*	W550-0006	PERRRES DE LAVE
29*	W550-0002	MORCEAUX DE CHARBON
30	GD840KT	PANNEAUX SIMILIBRIGUE
31*	W361-0016	BRASSES INCANDESCENTES
32*	F40	TELECOMMANDE

COMPOSANTS		
N° RÉF.	N° PIÈCE	DESCRIPTION
1	W357-0001	ALLUMEUR PIÈZO
2	W680-0015	THERMOPPILE
3	W680-0014	TERMOCOUPLE**
4	W010-1194	ASSSEMBLAGE DE VÉILLEUSE - GN
4	W010-1201	ASSSEMBLAGE DE VÉILLEUSE - PL
5	W455-0070	INJECTEUR DE VÉILLEUSE - GN
5	W455-0068	INJECTEUR DE VÉILLEUSE - PL
6	W725-0028	SOUAPPE - GAZ NATUREL
6	W725-0029	SOUAPPE - PROPANE
7*	W750-0188	HARNASIS DE FILS
8*	W456-0023	INJECTEUR DE BRÛLEUR - GN #23
8*	W456-0043	INJECTEUR DE BRÛLEUR - PL #43
9*	W660-0009	INTERRUPTEUR MARCHE/ARRÊT
10	W010-1739	ASSSEMBLAGE DE BRÛLEUR A PLATEAU
11*	W240-0005	FIL D'ÉLECTRODE
12*	W385-0334	LOGO NAPOLÉON®
13	W335-0048	HOTTE
14	W330-0060	CHARNIÈRE FEMELLE
15	W330-0059	CHARNIÈRE FEMELLE
16	W330-0062	CHARNIÈRE MALE
17*	W325-0028	POIGNEE DE PORTE
18	W300-0093	VITRE
19*	W010-1747	SUPPORT AIMANTÉ
20	GL-644	ENSEMBLE DE BUCHES
21	W135-0205	BUCHE ARRÊTER (#1)
22	W135-0206	BUCHE CENTRALE (#2)
23	W135-0207	BUCHE DROITE (#3)
24	W135-0208	BUCHE GAUCHE (#4)
25	W135-0218	BUCHE TRANSVERSALE (#5)

41.2

VOTRE DÉTAILLANT AUTORISE.

* IDENTIFIE LES ARTICLES QUI NE SONT PAS ILLUSTRES. POUR PLUS D'INFORMATION, CONTACTEZ

• Fini

• Description de la pièce

• Numéro de la pièce

• Date d'instillation de l'appareil

• Modèle et numéro de série de l'appareil

Lorsque vous commandez des pièces, donnez toujours l'information suivante :

POUR UN REMPLACEMENT DE PIÈCE SOUS GARANTIE, UNE PHOTOCOPIE DE LA DEMANDE.

ORIGINALE SERA REQUISE AFIN DE POUVOIR HONORER LA DEMANDE.

Normalement, toutes les pièces peuvent être commandées chez votre détaillant ailleurs.

Contractez votre détaillant pour les questions concernant les prix et la disponibilité des pièces de rechange.

SECURITE. REMPLACER UNIQUEMENT PAR UN TERMOCOUPLE A ACTION RAPIDE DE WOLF STEEL LTD.

** CECI EST UN TERMOCOUPLE A ACTION RAPIDE QUI CONSTITUE UN COMPOSANT ESSENTIEL DE

PIÈCES SPÉCIFIQUEMENT APPROUVEES POUR CET APPAREIL POUR CAUSER DES DOMMAGES MATERIELS

OMETTRE DE POSITIONNER LES PIÈCES CONFORMEMENT A CE MANUEL OU D'UTILISER UNIQUEMENT DES

PIÈCES SPÉCIFIQUEMENT APPROUVEES POUR CET APPAREIL POUR CAUSER DES DOMMAGES MATERIELS

OU DES BLESSURES CORPORELLES.

AVERTISSEMENT

9.0 ENTRETIEN

⚠ AVERTISSEMENT

COUPEZ L'ALIMENTATION EN GAZ ET L'ALIMENTATION ÉLECTRIQUE AVANT DE PROCÉDER À L'APPAREIL POUR ÉTRE CHAUD. ATTENDEZ QU'IL SOIT REFRIGÉRÉ AVANT D'EN FAIRE L'ENTRETIEN.

ATTENTION : Lors de l'entretien des contrôles, assurez-vous d'identifier chaque des fils avant de les débrancher. Une réinitialisation incorrecte des fils peut occasionner un mauvais fonctionnement et être dangereuse. Assurez-vous que l'appareil fonctionne adéquatement une fois l'entretien terminé. Cet appareil convient ne doit pas être obstrué.

1. Pour nettoyer le brûleur principal et la veilleuse adéquatement, il faut retirer les bûches, les roches ou la vitre afin de dégager les deux ensembles.

2. Gardez le compartiment des contrôles, les composants décoratifs, le brûleur, le vollet d'air et l'espace entourant les bûches propres en broasant l'asppirateur au moins une fois l'an.

3. Assurez-vous que tous les orifices des brûleurs produisent des flammes. Nettoyez tous les orifices qui n'ont pas de flamme ou dont la flamme ne brûle pas adéquatement.

4. Assurez-vous que la flamme de la veilleuse est assez puissante pour envelopper la sonde de flamme et/ou le thermocouple/thermopile et qu'elle atteigne le brûleur.

5. Remettez en place les bûches, les roches ou la vitre nettoyées. Omettre de positionner les composants décoratifs adéquatement peut causer des dépôts de carbone qui peuvent se déposer dans des endroits de séjour avoisinants.

6. Vérifiez si tous les orifices du brûleur principal sont allumés lorsque l'appareil est en marche. Un temps d'allumage total de 5 à 10 secondes est satisfaisant. Si l'allumage prend plus de temps, consultez votre détaillant autorisé.

N'utilisez pas de produits abrasifs ou de ligne d'acier sur les pièces en acier inoxydable de votre appareil, il est encore chaud au toucher. Pour nettoyer les surfaces en acier inoxydable, utilisez un nettoyant sans abrasif ou à acier inoxydable et frottez toujours dans le sens du grain. Les pièces en acier inoxydable vont décolorer de façon permanente sous l'effet de la chaleur pour habituellement prendre une teinte dorée ou brune. Cette décoloration est normale et n'affectera pas la performance de l'appareil.

NETTOYAGE DE LA SURFACE EN ACIER INOXIDABLE :

L'acier inoxydable a tendance à oxyder ou à tacher en présence de chlorures et de sulfures, particulièrement dans les zones cotières ainsi que dans les environnements chauds et humides tels que les piscines et les spas. Ces taches, considérées parfois comme de la rouille, peuvent être évitées et éliminées facilement. Pour ce faire, laissez les surfaces en acier inoxydable toutes les 3 à 4 semaines ou aussi souvent que nécessaire avec de l'eau fraîche ou un nettoyant à acier inoxydable.

81.1

NETTOYAGE DE LA SURFACE EN ACIER INOXIDABLE :

AVERTISSEMENT

DU CARBONE PEUT SE DÉPOSER DANS DES ENDROITS DE SÉJOUR AVoisinANTS SI LE VOLLET D'AIR N'EST PAS BIEN RÉGLÉ.

L'ouverture du vollet d'air a été préreglée en usine selon le tableau ci-dessous :

GS342	49.1	LE RÉGLAGE DU VOLLET D'AIR DOIT ÊTRE EXÉCUTÉ PAR UN TECHNICIEN OU INSTALATEUR QUALIFIÉ!
GN	1/8"	Il est important d'effectuer périodiquement une inspection visuelle de la flamme de la veilleuse et du brûleur.
PL	1/4"	Comparer à ces illustrations. Si des flammes paraissent normales, contactez un technicien de service.

49.5

OUVERTURE DU VOLLET
VENTURI
INJECTEUR
DU VOLLET D'AIR

Carbone. Plus le vollet est ouvert, plus la flamme est bleue et plus de dépôts de carbone. Plus la flamme est jaune et aura tendance à causer des dégâts de tendance à se détacher des orifices du brûleur. La flamme peut ne pas être jaune immédiatement; allouez de 15 à 30 minutes pour que la couleur finale de la flamme se stabilise.

Indépendamment de l'orientation du venturi, plus le vollet est fermé, plus la flamme est jaune et aura tendance à causer des dégâts de carbone. Plus la flamme est bleue et aura tendance à causer des dépôts de carbone. La flamme bleue est plus stable et permet de faire un réglage plus précis.

49.1

CARACTÉRISTIQUES DE LA FLAMME

LA FLAMME DOIT ENVELOPPER LA PARTIE SUPÉRIEURE DU THERMOCOUPLE ET DE LA THERMOPILE DE 3/8" À 1/2".

3/8" - 1/2"

54.2

47.9

FORCEZ PAS.

Enfonchez légèrement le bouton de contrôle du gaz et tournez vers la droite jusqu'à « OFF ». NE

INSTRUCTIONS POUR COUPER LE GAZ :

1. Arrêtez! Lisez les consignes de sécurité ci-dessus.
2. Tournez le bouton de contrôle du gaz vers la droite à « OFF ».
3. Attendez cinq (5) minutes pour que le gaz puisse s'échapper. Si vous détectez une odeur de gaz, y compris au niveau du plancher, ARRÉTEZ! et suivez les instructions ci-dessus. « Que faire si vous détectez une odeur de gaz » . Continuez à suivre les instructions ci-dessus. « Que faire si vous détectez une odeur de gaz » . Continuez à suivre les instructions ci-dessus.
4. Si l'appareil est muni d'une soufflerie d'aspiration, détournez le bouton de gaz enfoncé pendant une (1) minute, puis le bouton-pression d'ignition. Gardez le bouton de contrôle du gaz enfoncé pendant une (1) minute, puis relâchez-le. Si la veilleuse ne reste pas allumée, répétez les étapes 3 à 7.
5. Répétez la veilleuse située à l'avant de la bûche arrière.
6. Tournez le bouton de contrôle du gaz vers la gauche à « PILOT ».
7. Enfonchez et maintenez le bouton de contrôle du gaz pendant que vous allumez la veilleuse en appuyant sur le bouton-pression d'ignition. Gardez le bouton de contrôle du gaz enfoncé pendant une (1) minute, puis relâchez-le. Si la veilleuse ne reste pas allumée, répétez les étapes 3 à 7.
8. Lorsque la veilleuse est allumée, tournez le bouton de contrôle du gaz vers la gauche à « ON ».
9. Si l'appareil est muni d'un interrupteur à distance, le brûleur principal peut ne pas s'allumer quand vous tournez la soufflerie à « ON » ou à « HIGH ». L'interrupteur à distance doit être à « ON » pour que le brûleur s'allume.
10. Si l'appareil est muni d'un interrupteur à distance, le brûleur principal peut ne pas s'allumer quand vous tournez la soufflerie à « ON » ou à « HIGH ». L'interrupteur à distance doit être à « ON » pour que le brûleur s'allume.

INSTRUCTIONS D'ALLUMAGE :

- N'utilisez pas de téléphone cellulaire ou autre.
- Utilisez que votre main pour tourner le bouton de contrôle du gaz. N'utilisez jamais d'outils. Si le bouton ne tourne pas assez pour tourner le bouton de contrôle du gaz, tournez le bouton de manière à ce qu'il n'y a pas de fuite de gaz.
- N'utilisez pas de serviette ou de chiffon pour éteindre la flamme. N'utilisez jamais d'outils. Si le bouton de contrôle du gaz qui aurait été submergé.
- Utilisez pas cet appareil si une partie quelconque a été submergée. Contactez immédiatement un technicien de service qualifié pour l'inspecter et pour remplacer toute pièce du système de contrôle et du contrôle du gaz qui aurait été submergée.
- Utilisez pas cet appareil si une partie quelconque a été submergée. Contactez immédiatement un technicien de service qualifié pour l'inspecter et pour remplacer toute pièce du système de contrôle et du contrôle du gaz qui aurait été submergée.
- Utilisez pas de téléphone cellulaire ou autre.
- De la maison d'un voisin,appelez immédiatement votre fournisseur de gaz et suivez ses instructions.
- Si vous ne pouvez pas rejoindre votre fournisseur de gaz et suivez ses instructions.
- Coupez l'alimentation en gaz à l'appareil.
- N'allumez aucun appareil.

QUE FAIRE SI VOUS DÉTECTEZ UNE ODEUR DE GAZ :

- D. Utilisez pas cet appareil si une partie quelconque a été submergée. Contactez immédiatement un technicien de service qualifié pour l'inspecter et pour remplacer toute pièce du système de contrôle et du contrôle du gaz qui aurait été submergée.
- C. Utilisez que votre main pour tourner le bouton de contrôle du gaz. N'utilisez jamais d'outils. Si le bouton de gaz. Certains gaz sont plus lourds que l'air et se déposent au niveau du plancher.
- B. Avant d'allumer, sentez autour de l'appareil et près du plancher afin de vous assurer qu'il n'y a pas de fuite de gaz. Cela est une condition normale temporaire causée par le fonctionnement des bûches et l'évaporation des huiles lubrifiantes intérieures utilisées dans le processus de fabrication; elle ne se reproduira plus. Après de longues périodes sans utiliser l'appareil, comme à la suite de vacances ou à la fin de l'été, il se peut qu'une légère odeur se dégage pendant quelques heures. Ceci est causé par des particules de poussière brûlant dans l'échangeur de chaleur. Dans les deux cas évitez la zone.
- A. Cet appareil est muni d'une veilleuse qui doit être allumée manuellement tout en suivant ces instructions à la lettre.

POUR VOTRE SÉCURITÉ, LISEZ CE QUI SUIT AVANT D'ALLUMER L'APPAREIL :


- Cela est une condition normale temporaire causée par le fonctionnement des bûches et l'évaporation des huiles lubrifiantes intérieures utilisées dans le processus de fabrication; elle ne se reproduira plus. Après de longues périodes sans utiliser l'appareil, comme à la suite de vacances ou à la fin de l'été, il se peut qu'une légère odeur se dégage pendant quelques heures. Ceci est causé par des particules de poussière brûlant dans l'échangeur de chaleur. Dans les deux cas évitez la zone.
- POURRAIENT SE PROVOQUER, CAUSANT DES DOMMAGES MATERIELS, DES BLESSURES SI CES INSTRUCTIONS NE SONT PAS SUIVIES À LA LETTRE, UN INCENDIE OU UNE EXPLOSION CORPORELLES OU DES PERTE DE VIE.

AVERTISSEMENT

7.0 FONCTIONNEMENT

6.0 INSTALLATION DU SYSTÈME DE COMMANDE À DISTANCE

- A.** Enlever le bloc de batteries du récepteur, puis par tirer sur le couvercle du récepteur glisser le récepteur au trou à l'arrière de la base du brûleur. Fixez avec deux vis fourniés.
- B.** Fixez la plaque sur la boîte de dérivation avec deux vis fourniés.
- C.** Insérez les piles dans le bloc de batteries de commande à distance. Passez ensuite le bloc de batteries dans l'ouverture de la plaque, puis glissez-le dans le récepteur. Le boîte de batteries est retenu en place par un mécanisme de loquet. Pour fixer le bloc de batteries, poussez-le dans le mécanisme.
- D.** Insérez le commutateur à glisser à l'endroit indiqué sur la plaque.
- E.** Remplacez les fils de l'interrupteur existant, branchez aux bornes TH/TP et TH de la souape, par ceux qui partent de le récepteur.
- NOTE : L'interrupteur de commande à distance sur le côté de l'appareil n'est plus fonctionnel.**




NE FAITES PAS FONCTIONNER L'APPAREIL SANS AVOIR INSTALLE LA HOTTE. LA HOTTE DE L'APPAREIL NE DOIT PAS ETRE MODIFIEE NI REMPLACEE PAR UNE AUTRE HOTTE.

AVERTISSEMENT


NOTE : Retirez la hotte de l'intérieur de l'appareil en coupant la sangle qui la retient en place.

- A. Alignez les 3 languettes à l'arrière de la hotte avec les 3 fentes à l'avant appareil.
- B. Inclinez la hotte afin d'insérer les languettes dans les fentes. Laissez revenir la hotte vers l'avant pour qu'elle s'appuie sur la chambre de combustion.



5.6 MISE EN PLACE DU LOGO

Retirez le papier dorsal, puis apposez le logo sur le devant de l'appareil, à $\frac{1}{2}$ " du côté gauche, comme illustré.






5.4 MORCEAUX DE CHARBON ET PIERRES DE LAVE




Les briques incandescentes (non fournies) peuvent être utilisées pour rehausser l'apparence de la flamme.

5.3 BRAISES INCANDESCENTES

IMPORTANT
IL EST FORTEMENT RECOMMANDÉ DE PROTÉGER LES BUCHEES CONTRE L'HUMIDITÉ.
COUVRER L'OUVERTURE DE L'APPAREIL LORSQU'IL N'EST PAS EN FONCTION.




- A. Placez les pierres de lave autour de la base de l'appareil en vous assurant de ne pas bloquer les orifices du brûleur ou l'accès à la souape. Conservez une petite quantité de pierres de lave pour l'étape C.
- B. Placez les morceaux de charbon de bois autour de l'avant et des côtés de l'appareil.
- C. Placez l'extrême droite de la bûche #3 à droite du noeud de la bûche #1. La fourche de la bûche devrait contourner le noeud sur le dessus de la bûche #2.
- D. Insérez la tige de positionnement de l'extrême droite de la bûche #2. Insérez la tige de positionnement de la bûche #4 dans le trou de la bûche #1.
- E. Placez la ferme dans le bas de la bûche #5 l'arrière de la bûche du chenit.



5.0 FINITIONS

5.1 BORNES DE CHENET ET ASSEMBLAGE DU CHENET



Le chenet à l'aide de 2 des vis à tête hexagonale de 1" (fournies dans le sac du manuel).



5.2 DISPOSITION DES BÛCHES

! AVERTISSEMENT

PEUT CAUSER DES DOMMAGES MATERIELS OU DES BLESSURES CORPORELLES.	D'UTILISER UNIQUEMENT LES BÛCHES SPECIFIQUEMENT APPROUVÉES POUR CET APPAREIL.	LES BÛCHES DOIVENT ÊTRE PLACÉES CORRECTEMENT À L'INTÉRIEUR DE L'APPAREIL, NE CHANGEZ PAS LA POSITION DES BÛCHES CAR L'APPAREIL RISQUE DE NE PAS FONCTIONNER ADÉQUATEMENT ET UN RETARD INCANDESCENT RÉALISTE ET UNIQUE QUI EST DIFFÉRENT DANS CHAQUE INSTALLATION. PRENEZ LE TEMPS DE BIEN INSTALLER LES BÛCHES PHAZER® ET LES BÛCHES INCANDESCENTES, EXCLUSIVES AUX APPAREILS NAPOLÉON®, CRÉENT UN EFFET « ABSORBE » PENDANT LE PROCÉDÉ DE « CUISSON ».
LES BÛCHES SONT FRAGILES ET DEVRAIENT ÊTRE MANIPULÉES AVEC SOIN.		

B. Placez la bûche #2 sur les tiges de positionnement situées le long de l'arête du bûcheur.


A. Placez la bûche arrière #1 sur les tiges de bûcheur.



Les bûches PHAZER® et les bûches incandescentes, exclusives aux appareils Napoléon®, créent un effet incandescent réaliste et unique qui est différent dans chaque installation. Prenez le temps de bien installer les bûches incandescentes pour obtenir le meilleur effet possible. La couleur des bûches peut varier. Lors de la première utilisation de l'appareil, les couleurs deviendront plus uniformes à mesure que leurs pigments se ront absorbés.


76.1A

encocher dégagé bien les orifices du brûleur.
positionner la bûche de façon à ce que son positionnement du brûleur. Assurez-vous de positionnement situées le long de l'arête du bûcheur.



Pour installer la façade de l'appareil à égale distance avec la surface fine, positionnez les montants d'ossature de façon à prévoir l'épaisseur de la surface fine. Déplacez les six supports de fixation qui se trouvent sur le dessus et de chaque côté de l'appareil et fixez-les aux 2x4. Les supports de fixation facilitent l'installation d'une surface de finition de 1/2" ou de 3/4" d'épaisseur.

4.4 SUPPORT DE FIXATION



Nous vous recommandons d'installer une tablette faite d'un matériau incombusstible. Si le matériau est combustible, veuillez respecter les indications du tableau ci-dessous.

73.1


RISQUE D'INCENDIE. CONSERVEZ TOUS LES DÉGAGEMENTS AUX MATERIAUX COMBUSTIBLES SPECIFIQUES. NE PAS RESPECTER CES INSTRUCTIONS PEUT CAUSER UN INCENDIE OU UNE SURCHARGE. ASSUREZ-VOUS QUE TOUS LES DÉGAGEMENTS (ARRIÈRE, CÔTES, DESSUS, ÉVÉNTS, TABLETTE, FAÇADE, ETC.) SONT RESPECTÉS À LA LETTRE.
LORSQUE VOUS UTILISEZ DE LA PEINTURE OU DU VERNIS COMME FINITION POUR VOTRE TABLETTE, ASSUREZ-VOUS QU'ILS SOIENT RÉSISTANTS À LA CHALEUR AFIN DE PRÉVENIR LA DÉCOLORATION.
AVERTISSEMENT

4.3 DÉGAGEMENTS MINIMAUX DE LA TABLETTE


Afin de respecter les contraintes de température, l'espace à l'intérieur de l'enceinte, autour de l'appareil et au-dessus, doit démeurer sans obstruction.

L'encinte de l'appareil doit avoir une hauteur minimale de $58 \frac{1}{2}$ ".

MATERIAU INCOMBUSTIBLE
 MATERIAU COMBUSTIBLE




4.2 DÉGAGEMENTS MINIMAUX DE L'ENCEINTE



** Pour empêcher la pénétration d'eau dans l'enceinte, vous devez appliquer un scellant pour l'extérieur tout autour de l'appareil et le long des matériaux incombustibles.
* Du dessus de l'appareil.

LORSQUE VOUS FAITES LA FINITION JUSQU'A L'APPAREIL, N'UTILISEZ PAS DE BOIS NI DE CLOISON SÈCHE.
MARRE, ETC. N'UTILISEZ PAS DE BOIS NI DE CLOISON SÈCHE.

AVERTISSEMENT



Ossature conforme aux exigences des codes du bâtiment locaux.
Il est préférable de construire l'ossature après que l'appareil est en place. Utilisez des 2x4 et construisez

Il est conseillé d'installer l'appareil contre des murs fins. Ceci assurera que les dégagements aux matériaux combustibles sont maintenus.

Dégagements minimum de l'appareil et des surfaces d'évacuation aux matériaux combustibles :	Ossature	Finition	Ossature incombustible :	Profoundeur de l'enclos	Haut de l'enclos	Dégagement du plafond
0" aux espaces (à l'arrière et sur les cotés seulement)	Utilisez un linteau en acier dans le haut et deux montants en acier sur les cotés.	18" à l'arrière et sur les cotés	18" du dessus	22 1/4"	58 1/2" du bas de l'appareil	84" du bas de l'appareil.
Utilisez 0" aux espaces (à l'arrière et sur les cotés seulement)	Des matériaux de finition incombustibles (p. ex. : panneau de ciment, brique, pierre, tuile) peuvent être utilisés pour finir la façade de l'appareil.	4" sur les cotés de l'ouverture de l'appareil	4" du dessus	22 1/4"	22 1/4" du bas de l'appareil	22 1/4" du bas de l'appareil.
Des matériaux de finition incombustibles (p. ex. : panneau de ciment, brique, pierre, tuile) peuvent être utilisés pour finir la façade de l'appareil.	Utilisez un linteau en acier dans le haut et deux montants en acier sur les cotés.	Cotés.	Cotés.	Cotés.	Cotés.	Cotés.

AVERTISSEMENT	RISQUE D'INCENDIE!
AFIN D'ÉVITER LA POSSIBILITÉ QUÉ DE LISSATION OU UN COUPE-VAPEUR ENTRENT EN CONTACT AVEC L'EXTÉRIEUR DU CADRE, IL EST CONSEILLÉ D'INSTALLER L'APPAREIL CONTRE DES MURS FINIS (C.-A-D. PANNEAU DE GYPSÉ) COMME TOUT AUTRE MUR DE LA MAISON. CECI ASSURE RAU LE DÉGAGEMENT AVEC L'EXTÉRIEUR DU CADRE, LE RÉSERVOIR DE PROPANE DOIT TOUJOURS ÊTRE SITUÉ À L'EXTÉRIEUR DE LA STRUCTURE.	NE FAITES PAS D'ENTAILLES A LISSATURE AUTOUR DES ESPACES. NE PAS MAINTENIR LES DÉGAGEMENTS POUR CAUSER UNE SURCHAUFE ET UN INCENDIE. EMPÊCHEZ TOUT CONTACT AVEC DE LISSATION QUI S'AFFAISSE, AVEC LISSATURE OU AVEC TOUT AUTRE MATERIAU COMBUSTIBLE. BLOQUEZ L'ENTREE DE L'ENCINTE POUR EMPêCHER L'INFILTRATION D'AIR.
AFIN D'ÉVITER UN RISQUE D'INCENDIE, LES DÉGAGEMENTS MINIMAUX AUX MATERIAUX COMBUSTIBLES DOIVENT ÊTRE INSTALLEES.	L'ENCINTE DE L'APPAREIL DOIT RESPECTER LA HAUTEUR MINIMALE REQUISE. MESUREZ À PARTIR DE LA BASE DE L'APPAREIL.
AFIN D'ÉVITER UN RISQUE D'INCENDIE, LES DÉGAGEMENTS MINIMAUX AUX MATERIAUX COMBUSTIBLES DOIVENT ÊTRE INSTALLEES.	SI DES ENSEMBLES DE MONTANTS EN ACIER AVANT PANNEAU DE CIMENT SONT FOURNIS, ILS DOIVENT ÊTRE INSTALLEES.

7.1.1

4.1 DÉGAGEMENTS AUX MATERIAUX COMBUSTIBLES

4.0 OSSATURE

NOTE : Assurez-vous que l'emplacement possède une ventilation adéquate.

* Si vous installez un appareil alimenté au propane, le réservoir de propane doit toujours être situé à l'extérieur de la structure.




Des installations typiques peuvent comprendre des patios recouverts, des vérandas avec moustiquaires, des gazebos ou des installations contre le mur extérieur de la maison. Des flammes irrégulières peuvent aussi causer des dépôts de carbone excessifs (suie noire). Cette condition ne compromet pas la sécurité de l'appareil, mais est visuellement indésirable. Il est fortement recommandé d'installer cet appareil dans un endroit protégé. Les vents directs causent des flammes irrégulières et possiblement des panneaux de verrière et de brique principal.

Cet appareil est conçu pour être installé à l'extérieur tel que sur un patio ou dans votre cour. Il ne doit jamais être installé à l'intérieur d'une structure fermée et étanche.

3.4 AIR COMBURANT ET DE VENTILATION

EMPLACEMENTS DE L'ENTREE DU GAZ

Le caisson complete cinq emplacements pour l'entree du gaz. Un de chaque cote de l'appareil, deux à l'arriere, et l'autre à la base. A l'aide des illustrations suivantes, determinez l'emplacement ideal, puis enlevez la plaque pointonnée.



3.3 INSTALLATION DE L'INTERRUPTEUR MURAL OPTIONNEL

NE RACCORDEZ PAS L'INTERRUPTEUR MURAL, LE THERMOSTAT OU LA SOUPAPE DE GAZ À
L'ALIMENTATION ELECTRIQUE DE 110 VOLTS.

AVERTISSEMENT

Déconnectez les fils des bornes 1 et 3 (de l'interrupteur marche/arrêt) et remplacez-les par les fils de l'interrupteur mural/thermostat millivolt. Pour faciliter l'accès, un interrupteur mural ou un thermostat millivolt optionnel peut être installé à un endroit pratique. Passez un fil millivolt à deux brins (noyer solide) de la soupape à l'interrupteur mural ou au thermostat. La longueur maximale dépend du calibre du fil : Pour faciliter l'accès, un interrupteur mural ou un thermostat millivolt optionnel peut être installé à un endroit pratique. Passez un fil millivolt à deux brins (noyer solide) de la soupape à l'interrupteur mural ou au thermostat millivolt. La longueur maximale dépend du calibre du fil :

calibre 18	40 pieds
calibre 16	60 pieds
calibre 14	100 pieds

50.3

3.0 INSTALLATION

AVERTISSEMENT

RISQUE D'INCENDIE, D'EXPLOSION OU D'ASPHYXIE. ASSUREZ-VOUS AUSSI QU'IL Y AIT AU MOINS UNE SOURCE D'ALLUMAGE COMME DES ETINCELLES OU UNE FLAMME NUE.	SOUTENEZ LE CONTRÔLE DU GAZ ALLUMÉS LA VÉILLEUSE, QUE CE SOIT POUR LA PREMIÈRE FOIS OU LORSQUE DOIT ÊTRE EFFECTUÉE PAR UN TECHNICIEN QUALIFIÉ. ASSUREZ-VOUS QUE LA PORTE VITRÉE OU RETRIE. LA PURGE EST CONTINUE AVANT DE FERMER LA PORTE. ASSUREZ-VOUS D'UNE VENTILATION ADÉQUATE. POUR LES EMPLOACEMENTS DE L'ENTREE DU GAZ ET DE L'ENTREE ÉLECTRIQUE, VOIR LA SECTION « DIMENSIONS ».	LORSQUE LE BRANCHEMENT EST TERMINÉ, TOUS LES RACCORDES DE GAZ DOIVENT ÊTRE TROUVÉES À L'INTÉRIEUR DU FOUR.	LES PRESSIONS ÉLEVÉES ENDOMMAGERONT LA SOUPAPE. L'ALIMENTATION EN GAZ DOIT ÊTRE DÉBRANCHÉE PENDANT LES ESSAIS DE PRESSION DE CE SYSTÈME LORSQUE LES PRESSIONS D'ESSAI EXCÉDENT 1/2% LB/PO² (3,5 KPA).	L'INSTALLATION ET L'ENTRETIEN DOIVENT ÊTRE EFFECTUÉS PAR UN INSTALLATEUR QUALIFIÉ.	A.
Si l'appareil est muni d'un raccord flexible, celui-ci est conçu pour recevoir une conduite de gaz de 1/2". Sans raccord flexible, celui-ci est conçu pour recevoir une conduite de gaz de 3/8". L'appareil est muni d'une souffrance d'arrêt manuelle pour fermer l'alimentation en gaz.	B.				
Branchez le gaz en conformité avec les codes locaux. En l'absence de codes locaux, l'installation doit être conforme au Code d'installations du gaz CAN/CSA-B149.1 dans sa version pour le Canada ou le National Fuel Gas Code, ANSI Z223.1 / NFPA 54 pour les États-Unis.	C.				
Lorsque vous manipulez des conduites de gaz, soutenez la souffrance de gaz pour éviter que les conduites ne se plient.	D.				
Le raccord flexible de l'alimentation en gaz devrait être suffisamment mobile pour permettre de placer l'assemblage du brûleur sur le côté.	E.				
Vérifiez pour des fuites de gaz en appliquant une solution d'eau savonneuse. N'utilisez pas une flamme nue.	F.				

30.1A

flamme nue.

d'homologation fixée sur l'appareil.

Pour l'implacement de la plaque d'homologation, voir la section « VUE D'ENSEMBLE DE L'INSTALLATION ». Cette illustration est fournie à titre indicatif seulement. Pour les renseignements exacts, consultez la plaque.

INFORMATION SUR LA PLAQUE D'HOMOLOGATION

à fait normal et il faut s'y attendre.

Les bruits causés par l'expansion et la contraction lors des cycles de chauffage et de refroidissement sont tout système.

Aucune alimentation électrique extrême (110 volts ou 24 volts) n'est requise pour le fonctionnement du certificat.

Cet appareil est conçu pour fonctionner avec le type de combustible indiqué sur la plaque d'homologation. Cet appareil ne peut être converti à un autre type de combustible à moins d'utiliser un ensemble de conversion.

Il est fortement recommandé de protéger les livres contre l'humidité (pluie, neige). Recourez à un ouvrage approprié lorsqu'il n'est pas en fonction.


spécificités de l'autorité compétente locale, l'indice certifie du débit à haute altitude devra être réduit au taux de 4 % pour chaque 1 000 pieds supplémentaires.

RENDEMENTS ET EFFICACITÉS		
Altitude	GAZ NATUREL	GAZ PROPANE
Débit maximal	65 000 BTU/h	65 000 BTU/h
Pression minimale d'alimentation en gaz	4,5" de colonne d'eau	11" de colonne d'eau
Pression maximale d'alimentation en gaz	7" de colonne d'eau	13" de colonne d'eau
Pression au collecteur lorsqu'un gaz circule	3,5" de colonne d'eau	10" de colonne d'eau

POUR VOTRE SATISFACTION, CET APPAREIL A ETE MIS A L'ESSAI POUR CONFIRMER SON FONCTIONNEMENT ET SA QUALITE !

INFORMATION GÉNÉRALE

La soupape de l'appareil doit être débranchée de la ligne d'alimentation en gaz pendant les essais de pression de ce système lorsque les pressions déssai excèdent 1/2 lb/po² (3,5 KPa). L'appareil doit être séparé de la ligne d'alimentation en gaz en fermant la soupape d'arrêt manuelle pendant tout essai de pression du système d'alimentation en gaz lorsque la pression est de 1/2 lb/po² (3,5 KPa) ou moins. Lorsque l'appareil est installé directement sur une surface combustible autre que le bois, l'appareil devra être monté sur un panneau continu de métal ou de bois se prolongeant sur toute la largeur et la profondeur.



L'installation doit se conformer aux codes locaux. En l'absence de codes locaux, l'installation doit être conforme au Code d'installation du gaz naturel et du propane CSA B149.1 au Canada ou le National Fuel Gas Code, ANSI Z223.1 / NFPA 54 aux États-Unis.

- Le raccord flexible ne doit pas mesurer plus que 36 pouces.
- La soupape d'arrêt doit être un robinet à gaz avec une poignée en T.


Connaitre les normes spécifiques qui s'appliquent à votre région. Par exemple dans l'état du Massachusetts :

conformément aux codes locaux. Les pratiques d'installation peuvent varier d'une région à l'autre. Il est donc important de connaitre les normes spécifiques qui s'appliquent à votre région. Par exemple dans l'état du Massachusetts :

CE FOYER AU GAZ DEVRAIT ÊTRE INSTALLE ET ENTRETENU PAR UN INSTALLATEUR QUALIFIÉ en se

! AVERTISSEMENT	LES PRESSIONS ÉLEVÉES ENDOMMAGERONT LA SOUPAPE. L'ALIMENTATION EN GAZ DOIT ÊTRE DÉBRANCHÉE PENDANT LES ESSAIS DE PRESSION DE CE SYSTÈME LORSQUE LES PRESSIONS D'ESSAI EXCÉDENT $\frac{1}{2}$ LB/PO ² (3,5 KPa). FERMEZ LA SOUPAPE D'ARRÊT MANUELLE PENDANT TOUT ESSAI DE PRESSION DU SYSTÈME D'ALIMENTATION EN GAZ LORSQUE LA PRESSION EST DE 48" DE LA FACE VITREE DE L'APPAREIL.	LES OBJETS PLACÉS DEVANT L'APPAREIL DOIVENT ÊTRE GARDES À UNE DISTANCE D'AU MOINS $\frac{1}{2}$ LB/PO ² (3,5 KPa) OU MOINS.	N'OUBLIEZ JAMAIS L'OUVERTURE DE L'APPAREIL.	RISQUE D'INCENDIE OU D'EXPLOSION.	SECURITAIRE ET ANNULER LA GARANTIE ET LA CERTIFICATION.	CERT APPAREIL NE DOIT FONCTIONNER QU'AVEC LE TYPE DE GAZ SPÉCIFIÉ SUR LA PLAQUE D'HOMOLOGATION. CET APPAREIL NE PEUT ÊTRE CONVERTI À UN AUTRE TYPE DE GAZ.
-----------------	---	--	---	-----------------------------------	---	--

2.2 INSTRUCTIONS GÉNÉRALES



2.1 DIMENSIONS

2.2

gaz de combustion dans l'environnement extérieur.

Cet appareil ne doit pas être installé à l'intérieur ni dans une structure qui empêche la dissipation des démarques d'humidité.

Les matériaux d'emballage doivent être gardés hors de la portée des enfants et mis au rebut dès démarcation.

N'utilisez pas cet appareil si une partie quelconque a été submergée. Contactez immédiatement un technicien de service qualifié pour inspecter l'appareil et pour remplacer toute pièce du système de gazon sécuritaire.

Les matériaux d'emballage doivent être gardés hors de la portée des enfants et mis au rebut dès démarcation.

Cet appareil ne devra être modifié en aucun cas.

Gardez libre de tous matériaux combustibles, essence ou autres liquides et vapours inflammables.

Utilisation et au moins une fois l'an par un spécialiste en entretien. L'emplacement de l'appareil doit être d'air de l'appareil ainsi que le système d'évacuation. L'appareil doit être inspecté avant la première utilisation.

Il est primordial de garder propres les compartiments de contrôle, les brûleurs, la soufflerie, les bouches d'utiliser l'appareil.

Les grillages de sécurité ou écrans enlevés pour faire l'entretien devront être remis en place avant fixes au plancher.

Consultez votre détaillant local de foyer pour connaître les grillages de sécurité et les écrans offerts pour protéger les enfants des surfaces chaudes. Ces grillages de sécurité et ces écrans doivent être prolongé.

Même une fois que l'appareil est éteint, le pare-étincelles demarrera chaud pendant un temps toucher aux surfaces chaudes.

Assurez-vous de disposer de mesures de sécurité adéquates pour empêcher les jeunes enfants de l'appareil.

Les meubles ou autres objets doivent être gardés à une distance d'au moins 4 pieds du devant de Les vêtements et autres matériaux combustibles ne doivent pas être posés sur l'appareil ou à proximité.

Les enfants ou autres personnes à risque loin des surfaces chaudes.

Restez à l'accès à l'appareil, installez une barrière de protection ajustable pour garder les jeunes de protection est recommandée si il y a des personnes à risque à proximité de l'appareil. Une barrière

l'appareil. Les jeunes enfants et autres personnes sont sujets aux brûlures accidentelles. Une barrière

les jeunes enfants doivent être supervisées attentivement lorsqu'ils sont dans la même pièce que élèves et se tenir à distance afin d'éviter des brûlures ou que leurs vêtements ne s'enflamme.

Les enfants et les adultes devraient être informés des dangers due possètent les températures de surface l'apparence de la flamme.

Ne laissez pas le vent souffler directement dans l'appareil. Évitez les courants d'air qui modifient contrôles propres.

Si l'appareil s'éteint de façon répétitive, faites-le inspecter. Gardez le brûleur et le compresseur suffisant pour entraîner et opérer l'appareil. Nous vous recommandons de faire servir l'appareil.

Assurez-vous d'une quantité suffisante d'air de combustion et de ventilation. Prenez un accès

Ne brûlez pas de bois ou autres matériaux dans cet appareil.

Installez une barrière de métal peuvent être coupantes.

Risque de coupures et d'éraflures. Portez des gants protecteurs et des lunettes de sécurité lors de Risque de compositions endommagées ou incomplètes ni des composants substituts.

Toute modification appuyée à cet appareil ou aux contrôles peut être dangereux et est interdit.

d'utiliser l'appareil selon les instructions d'opération pourrait causer un incendie ou des blessures.


Ne faites pas fonctionner l'appareil avant d'avoir lu et compris les instructions d'opération. Omettre

BRÛLURES EN CAS DE CONTACT.

CET APPAREIL EST CHAUD LORSQU'IL FONCTIONNE ET PEUT CAUSER DE GRAVES

Avertissement

2.0 INTRODUCTION



1.0 VUE D'ENSEMBLE DE L'INSTALLATION

NOTE : Les changements, autres que de nature éditoriale, sont dénotés par une ligne verticale dans la marge.

2.0	INTRODUCTION
3	VUE D'ENSEMBLE DE L'INSTALLATION
4	DIMENSIONS
5	INSTRUCTIONS GÉNÉRALES
6	INFORMATION SUR LA PLAQUE D'HOMOLOGATION
7	EMPLACEMENTS D'ENTREE DU GAZ
8	BRANCHEMENT DU GAZ
9	INSTALLATION
10	4.0 OSSATURE
11	4.1 DEGAGEMENTS MINIMAUX DE L'ENCINETE
12	5.0 FINITIONS
13	5.1 BORNES DE CHENET ET ASSEMBLAGE DU CHENET
14	5.2 DISPOSITION DES BUCHES
15	5.3 BRASSES INONDÉS CÉTÉS
16	5.4 MORCEAU DE CHARBON ET PIERRES DE LAVE
17	5.5 HOTTE
18	5.6 MISER EN PLACE DU LOGO
19	6.0 INSTALLATION DU SYSTÈME DE COMMANDE À DISTANCE
20	7.0 FONCTIONNEMENT
21	8.0 REGLAGES
22	8.1 REGLAGES DU VENTURI
23	8.2 CARACTÉRISTIQUES DE LA FLAMME
24	9.0 ENTRÉE
25	9.1 RECHANGES
26	10.0 GUIDE DE DÉPANNAGE
27	11.0 GARANTIE
28	12.0 HISTORIQUE D'ENTRETIEN
29	13.0

TABLE DES MATIÈRES

Téléphone 705-721-1212 • Télécopieur 705-722-6031 • www.napoleonfoyers.com • ask@napoleon.on.ca

103 Miller Drive, Crittenton, Kentucky, USA, 41030

Wolf Steel Ltd., 24 Napoleon Rd., Barrie, ON, L4M 0G8 Canada /



NE JAMAIS LASSEZ LES ENFANTS TOUCHER LA VITRE.

AVANT QU'ELLE AIT REFRIDI.

NE PAS TOUCHER LA VITRE


DES BRÛLURES.

LA VITRE CHAUE CAUSERA



A! AVERTISSEMENT

AVERTISSEMENT : POUR USAGÉ EXTERIEUR SEULEMENT.



Cet appareil doit être utilisé uniquement avec le type de gaz indiqué sur la plaque signalétique. Cet appareil ne peut être converti à d'autres gaz, sauf si une troussede conversion est utilisée.

Si l'installation et l'entretien doivent être faits par un installateur qualifié, une agence d'entretien ou le fournisseur.

- Si vous ne pouvez pas rejoindre votre fournisseur de gaz,appelez le service des incendies.
- Appellez immédiatement votre fournisseur de gaz d'un téléphone voisin. Suivez ses instructions.
- Utilisez aucun interrupteur électrique dans votre immeuble.
- Ne touchez à aucun interrupteur électrique;
- N'allumez aucun appareil.
- QUE FAIRE SI VOUS DÉTECTEZ UNE ODEUR DE GAZ :
- Liquides et vapeurs inflammables à proximité de cet appareil ou tout autre appareil.
- N'entreposez pas et n'utilisez pas d'essence ou autres liquides corrosifs corporels ou des perbes de vie.

Si ces instructions ne sont pas suivies à la lettre, un incendie ou une explosion pourraient des blessures corporelles ou des pertes de vie, s'ensuivre, causant des dommages matériels, lettre, un incendie ou une explosion pourraient des blessures corporelles ou des pertes de vie.

CERTIFIÉ POUR LE CANADA ET LES ÉTATS-UNIS SELON LES MÉTHODES ANSI/CSA.

MODÈLE AU PROPANE

GSS42P

MODÈLE AU GAZ NATUREL

GSS42N

Foyer Extérieur au Gaz

HOMOLOGUÉ SELON LES NORMES NATIONALES CANADIENNES ET AMÉRICAINES CR97-003, CAN-1-2.1-M85 ET IAS U.S. 4-96.

INSTRUCTIONS D'INSTALLATION ET D'OPÉRATION

Foyers de Qualité



PROPRIÉTAIRE : CONSERVEZ CE MANUEL POUR CONSULTATION ULTRÉRIEURE.
NE LAISSEZ PAS LES ENFANTS OU AUTRES INDIVIDUS À RISQUE SELON LA PROXIMITÉ DE L'APPAREIL.

INSTALLATEUR : LAISSEZ CE MANUEL AVEC L'APPAREIL.