

Primo Ager V1.5 DIY Upgrade Instruction







Model: PAG-400



Contents

Introduction	3
Tools Needed	4
Step 0: Preparation: Format your MicroSD and download the Display firmware file	5
Step 1: Hardware Firmware Upgrade	6
1.1 Hardware Firmware Upgrade via OTA	6
1.2 Hardware Firmware Upgrade via USB	6
Step 2: Display Firmware Upgrade	10
Step 3: After Upgraded	15
Appendix	16
New Display	16
Warning of Electric Shock	22
Copyright	22
Disclaimer	22
Related Documents	22



Introduction

This instruction is for users to do a DIY upgrade of Primo Ager from V1.1x/1.2x/1.4x to V1.5x.

From V1.0/1.2 to V1.5x, the major changes involved:

- enhanced humidity control
- enhanced display program

For more information about new display program, please refer to Appendix > New Display.



Tools Needed

- Hex Keys
- MicroSD Card of storage size: 8GB, 16GB, or 32GB or less
- MicroSD card reader








Before you start the upgrading process, please read below.


Step 0: Preparation for display firmware

0.1 MicroSD card formatting

Insert your MicroSD card into your computer and format it as FAT32 see the "File system" drop down box, and choose FAT32



Open your web browser and download the display firmware file here:



https://github.com/miles-hong/primo-ager/raw/main/primoager-1.5-display-v1.02.tft

After download completed, copy and paste the file onto the formatted MicroSD card make sure only this file is saved on the MicroSD card


0.3 WIFI Connection for your Primo Ager

Please refer to WIFI Connection guide.



Step 1: Machine Firmware Upgrade 1.1 Firmware Upgrade via OTA

Go to OTA page on display



Press OTA Button and wait to begin (if see OTA failed, please see below 1.2 to continue).

When firmware has been upgraded, it will reboot automatically. However, you need to upgrade your display firmware prior the new layout appears. See Step 2- Display Firmware Upgrade.

1.2 Firmware Upgrade via USB (required USB cable & PC laptop with Windows 10 or above)

If OTA didn't perform from 1.1, please follow the steps below:

Step A) Get the latest firmware from GitHub

On your PC laptop, open web browser and download below file: https://github.com/miles-hong/primo-ager/raw/main/primoager-v1.51.bin

Save firmware file in a separated folder (v. 1.51 at time of writing this manual)




Step B) Flash Tool and USB driver

B1) Flash Tool software to be used in Step C Download and save the flash tool zip file from here:


https://www.espressif.com/sites/default/files/tools/flash download tool 3.9.2.zip

Unzip the file as:



B2) Download and install USB driver from below link:

https://www.silabs.com/documents/public/software/CP210x Windows Drivers.zip






Run "CP210xVCPInstaller_x64.exe" file

And follow the steps to install the USB to UART driver

Step C) Flash the firmware via USB connection


Remove the top cover of Primo Ager by using the hex key (4 screws in each corner). Connect USB cable between Primo Ager CPU slot (see below pic.) and your PC laptop



USB connector




Run the flash_download_tool_3.9.2.exe from B1 above and select:



ChipType: **ESP32**

WorkMode: develop

Click on **OK** to start the flash main program



1: click the 3 dots button to choose the file you just downloaded in Step A **primoager-V1.51.bin**


2: enter the text: **0x10000**

3: tick the check-box

4: drop down to choose the **COM** port. (Yours may be not COM3)

5: click **START** button to start flashing





The Flashing process may take up to a minute. FINISH sign in green will show after completion.


Now, your Primo Ager has upgraded with the latest firmware. This is the only time you need to do this, firmware version 1.50 or later will have the full OTA function by pressing on LCD display!

Step 2: Display Firmware Upgrade


2.0 Power Off your unit!


Power off the machine to carry out the following steps
























2.6 Power On

Now you have a new display firmware, check according to Appendix\New Display



Step 3: After Upgraded

After upgraded, power ON your Primo Ager, you will see your new Display program, as described in Appendix.

Do a machine reset and testing

Go to the page "Machine Setup"


Navigate to the page: "Mode/Temp/Humi"

Choose your mode and press button "SAVE"



Appendix

New Display



Showing:

Current Temperature and Humidity,

Settings:

Machine Mode and Temperature, Humidity

(when in Degree Fahrenheit mode, no decimal point for Temperature display)





Main Machine, showing all the machine status and current Temperature/Humidity

The icons on the left show the status of:


WiFi connection UV Lamp status Compressor status Defrost status

The Primo Ager icon navigates to Start Page


The icons on the right are the navigation buttons:

Home (current page)
Information Page
Setup Page
Factory Settings Page (for Factory only)


























Warning of Electric Shock

Be aware of any Electric Shock risk.

Power Off first





Warning!!!

Electric Shock

Power Off the Primo-Ager First

Copyright

All copyrights reserved by Primo-Ager

Disclaimer

Primo Ager and its technical supporting technician makes no warranties of any kind, whether expressed or implied, with respect to the information, technology or services it provides. Primo Ager will not be responsible for damages resulting from or implied by this technical guide.

Related Documents

https://github.com/miles-hong/primo-ager

Primo Ager Remote Connection user guide (for remote connection troubleshooting)

Primo Ager WiFi Connection Instruction (for WiFi connection)

Primo Ager DIY Upgrade Instruction (this document)