Figure 7: Key Pad GUI Call Flow

Menu

Call History

Status

Phone Book

Instant Messages

Direct IP Call

Preference

Config

Factory Functions

Reboot

Exit

Call History

Received Calls
Dialed Calls
Missed Calls
Back

Any of previous menu

Back
Clear All

Phone Book

New Entry
Back

New Entry

Name
Number
Account
Confirm Add
Cancel & Return

Instant Messages

Back
Clear All

Preference

Do NOT Disturb
Ring Tone
Ring Volume
Download SCR XML
Erase Custom SCR

Do NOT Disturb

Enable DND
Disable DND
Back

Ring Tone

Default Ring
Ring 1
Ring 2
Ring 3
Back

Config

Network
SIP
Audio
Upgrade
Factory Reset
Back

SIP (Primary A/C ONLY)

SIP Proxy
Outbound Proxy
SIP User ID
SIP Auth ID
SIP Password
Save
Cancel

Audio

Select PCMU
Select PCMA
Select G.723.1
Select G.729(A/B)
Select GSM
Cancel

Upgrade

TFTP Server
HTTP Server
Save and use TFTP
Save and use HTTP
Cancel

Factory Functions

Ethernet Loopback
Audio Loopback
Diagnostic Mode
Back

Keypad/LED
Diagnostics