MALICE

QUICK START GUIDE · firmware v1.4.14

Mindburner MIDI Products · hand-built in Belfast · 6-voice poly / mono synth + 16-step sequencer

1. CONNECT

Power	USB-C 5 V (phone charger), or a regulated 9-12 V DC adaptor, 500 mA+
MIDI IN	5-pin DIN from your keyboard, sequencer or DAW interface
Audio out	Stereo 3.5 mm jack to mixer, amp or headphones (start with the volume low)

Switch on: the MINDBURNER splash plays, then the last patch you used loads.

2. PLAY

Any MIDI channel (OMNI by default). Pitch bend, mod wheel, velocity and aftertouch all work.
Program Change 0-29 selects patches 1-30.

3. CONTROLS - PARAMETER PAGES

Encoder turn	Change the selected value (turn fast to move quickly)
B / C	Value up / down (hold to repeat)
A tap / Encoder push	Next parameter
D tap / A hold	Next page
D hold / B+C hold	PATCH page
A+B hold 1 s	SEQUENCER screen on / off
A+B+C hold 2 s	Restore factory sounds (B = this slot, A = all 40, C = cancel)

Pages: OSC · PW/XMOD · NOISE · FILTER · ENV · LFO · MOD · FX · VOICE · SETUP

4. PATCHES (40 slots: 31-40 are simple basics to build on)

Choose / hear	Encoder or A on the PATCH page; push the encoder to audition
Load / Save	B = LOAD, C = SAVE -> confirm with B (yes) or C (no)
Back	D tap (or B+C hold)

Edits are not kept until you SAVE them to a slot.

5. NEW IN v1.4

POLI filter	FILTER > Slope: POLI LP / POLI BP, Polivoks-style screaming filter
X-Mod / Sync	PW/XMOD page: osc 2 cross-modulates or hard-syncs osc 1
Mod matrix	MOD page: 2 slots, e.g. WHEEL -> CUTOFF or WHEEL -> DLY MIX
Wheel Vib	MOD page: AUTO / ON / OFF for the mod wheel vibrato
Cho Rate	FX page: AUTO or 0.05-8 Hz for slow 70s chorus swish

6. SEQUENCER

Steps	A or encoder push = next step; encoder = note
Note / rest	B tap; B hold or D = accent / slide
Play / stop	C or D hold (or MIDI Start / Stop)
Boxes	BPM · PAT (1-8) · LEN (1-16) · REC · CLR · CHN

Follows external MIDI Clock. Patterns are saved automatically.

7. SETUP page

Master	Overall output level (saved). Recording? Start at about 50%
MIDI Ch	OMNI or 1-16 (saved)
Tune A4	430-450 Hz master tune, default 440 Hz (saved)

8. TROUBLESHOOTING

No sound	Check MIDI channel (try OMNI), volume, and the MIDI IN cable
Unwanted vibrato	MOD page: set Wheel Vib to OFF
Recording distorts	SETUP > Master to ~50%, recorder gain low
Whine on DC power	Use USB power or a good regulated adaptor
Stuck notes	Send All Notes Off (CC 123) or change patch