NIBBLE

QUICK START GUIDE · firmware v0.9.6

Mindburner MIDI Products · hand-built in Belfast · 8-voice chiptune synth, chip drums + sequencer

1. CONNECT

Power	Regulated 9-12 V DC adaptor, 500 mA+, 2.1 mm, any polarity (quietest) or USB-C 5 V from a phone charger or power bank
MIDI IN / THRU	5-pin DIN from your keyboard, sequencer or DAW; THRU chains another synth
Audio out	Stereo line out to mixer, interface or speakers (start with the volume low)

2. PLAY

Synth: any MIDI channel (OMNI by default). Drums + speech: channel 10.
Speech notes 60-67: GO YEAH ONE TWO THREE FOUR READY GAME OVER
Program Change 0-39 selects patches 1-40.

3. CONTROLS

Encoder turn / B C	Change the selected value
A tap / Encoder push	Next parameter (push hold = previous page)
D tap / A hold	Next page
D hold / B+C hold	PATCH page
A+B hold 1 s	SEQUENCER: 8 patterns of drums + LEAD + BASS tracks
A+C hold 1 s	Demo tune with the dancing spider
C+D hold 1 s	SCOPE: live oscilloscope of every voice
A+B+C hold 2 s	Restore factory sounds (B = this slot, A = all 40, C = cancel)

Pages: OSC · WAVE ED · CHIP · ARP · ENV · MOD · FX · F.ECHO · DRUMS · VOICE · SETUP

4. PATCHES (40 slots: 31-40 are plain basics to build on)

Choose / hear	Encoder or A on the PATCH page; push the encoder to audition
Load / Save	B = LOAD, C = SAVE -> confirm with B (yes) or C (no)

Edits are not kept until you SAVE them to a slot.

5. DRAW A WAVE (WAVE ED page)

Turn the encoder to set each of the 32 steps, tap A for the next. Saved with the patch.

6. SEQUENCER (hold A+B)

B on a drum step = hit. B on LEAD/BASS = rest > note > accent > tie; turn the encoder = pitch.
Boxes: BPM PAT (1-8) CHN (chain = song) KEY BP (BASS patch) BAR REC CLR. C = play/stop.
Hold the encoder push for MIX: LEAD / BASS / DRUMS levels.

7. FAKE ECHO (F.ECHO page)

Level turns it on: each note repeats 1-3 times, quieter, on spare voices - the tracker trick.

8. SETUP page

Master	Overall level (saved). Recording? Start at about 50%
MIDI Ch / Tune A4	Synth channel OMNI or 1-16 / 430-450 Hz master tune

9. TROUBLESHOOTING

No sound	Check MIDI channel (try OMNI), Master and Volume
Gritty or echoey	The patch uses Crush / Rate / Echo (FX page) or F.ECHO
Crackle on USB	Computer ground noise: use the DC adaptor or a power bank