

PANDA Component Description: *int_memory*

Overview

The `int_memory` component implements a RAM. The address width is configurable through a generic to set the amount of ram to implement.

Note that the number of used address bits is equal to the value of the `address_width` generic.

Generics

Name	Type	Default	Description
<code>address_width</code>	integer	8	Address width of the RAM block

Registers

This component has no registers. It has $2^{\text{address_width}}$ bytes of RAM, starting at the base address, which can be read or written. The memory is not initialized, initialization must be done by software.