


16 (SS:P76B)

## NOTE:

 $\mbox{P76A}$  shall be used when the local axis of section of support is parallel to the GLOBAL axis of structural beam



## NOTE:

P76B shall be used when the local axis of section of support is perpendicular to the GLOBAL axis of structural beam

