

(•)	А	Е	F	S	(●)	А	E	F	S
HE 100A	500 ÷ 600	300	130	10	HE 160A	500 ÷ 600	300	200	12
	601 ÷ 800	500				601 ÷ 800	500		
HE 120A	500 ÷ 600	300	150	10	HE 180A	500 ÷ 600	300	200	12
	601 ÷ 800	500				601 ÷ 800	500		
HE 140A	500 ÷ 600	300	200	12		500 ÷ 600	300	200	12
	601 ÷ 800	500				601 ÷ 800	500		

FOR REFERENCES AND NOTES SEE LAST SHEET - Per riferimenti e note vedere ultimo foglio