

●)	IPE 80	IPE 100	IPE 120	HE 100A	HE 120A	HE 140A	HE 160A	HE 180A	HE 200A
••)	IPE 80			HE 100A					
A	700	800	900	1000	1200	1400	1600	1800	2000÷2200
41 ≈	450	530	600	670	800	940	1070	1200	1330
31	640	750	850	950	1130	1330	1510	1700	1880
	●) ●●) A A1 ≈ B1	A 700 A1 ≈ 450	A 700 800 A1 ≈ 450 530	PE 80 A 700 800 900 A1 ≈ 450 530 600	PE 80 A 700 800 900 1000 A1 ≈ 450 530 600 670	A 700 800 900 1000 1200 A1 ≈ 450 530 600 670 800	A 700 800 900 1000 1200 1400 A1 ≈ 450 530 600 670 800 940	A 700 800 900 1000 1200 1400 1600 A1 ≈ 450 530 600 670 800 940 1070	Pe) IPE 80 HE 100A A 700 800 900 1000 1200 1400 1600 1800 A1 ≈ 450 530 600 670 800 940 1070 1200

FOR REFERENCES AND NOTES SEE LAST SHEET - Per riferimenti e note vedere ultimo foglio