

CSL Compiler

The CSL compiler can be invoked with the command `cslc` on your terminal. See the following documentation describing the available options. See [Working With Code Samples](#) for usage examples.

```
usage: cslc [-h] [-o OUTPUT_NAME] [--params PARAMS] [--colors COLORS] [--memcpy] [--channels CHANNELS]
           [--import-path IMPORT_PATH] [--width-west-buf WIDTH_WEST_BUF] [--width-east-buf WIDTH_EAST_BUF] [--verbose]
           csl_filename
```

Frontend for `cslc-driver`. Creates a directory and then calls `cslc-driver` which will write its output files to the created directory.

positional arguments:

`csl_filename` Input CSL file

optional arguments:

`-h, --help` show this help message and exit

`-o OUTPUT_NAME` Output directory name (default: out)

`--params PARAMS` Comma-separated list of param-to-value mappings where a mapping is a `name:value` pair where name is a string and value is an unsigned integer. The parameter list is passed on to `cslc-driver` as-is.

`--colors COLORS` Comma-separated list of color-to-value mappings where a mapping is a `color:value` pair where color is a string and value is an unsigned integer. The parameter list is passed on to `cslc-driver` as-is.

`--memcpy` Add memcpy support to this program

`--channels CHANNELS` Number of memcpy I/O channels to use when memcpy support is compiled with this program.

`--import-path IMPORT_PATH` Add the given directory to the list of directories searched for <...> paths in @import_module and @set_tile_code statements.

`--width-west-buf WIDTH_WEST_BUF` width of west buffer (default is zero, i.e. no buffer to mitigate slow input)

`--width-east-buf WIDTH_EAST_BUF` width of east buffer (default is zero, i.e. no buffer to mitigate slow output)

`--verbose` Verbose output

