

Switching order SO-2026-0914-01

Isolate and restore L0001 CST-001 to CST-030

Isolation

1. Confirm CB-112 at CST-001 is open and locked out.
2. Confirm the remote breaker at CST-030 is open.
3. Open disconnect switches DS-112A and DS-112B at CST-001.
4. Open the line disconnect at CST-030.
5. Apply working grounds at both terminals. Issue clearance to the line crew.

Restoration

6. Line crew releases the clearance. Remove working grounds at both terminals.
7. Close the line disconnect at CST-030, then DS-112A and DS-112B at CST-001.
8. Reset the lockout on CB-112.
9. Energise from CST-001: close CB-112. Check voltage at CST-030.
10. Close the breaker at CST-030. Confirm flow and loading on L0001.

Approvals

Prepared by	Shift engineer (sample)
Approved by	Transmission operator (sample)
Completed	2026-09-14 16:40 CDT