The pump must be primed before the first run. Fill the housing with clean water up to the marked line, close the valve and wait until the pressure gauge reads between two and three bar.

Never run the pump dry. Running without water for more than thirty seconds damages the seal and voids the warranty for the whole unit.

Clean the filter every month. Remove the cover, rinse the mesh under running water and put it back with the arrow pointing towards the motor.