

Five-Stop Elevator - FAT Validation

TIA Portal V20 / S7-1500F / SIMATIC Safety / WinCC Unified

Format: requirement -> observed result -> retained screenshot evidence

Each test page pairs the checked behaviour with the observed result and retained HMI / PLC evidence.

Validation shown here is PLCSIM/lab evidence for the portfolio controller and configured fail-safe architecture.

- CheckValid automatic request reaches the target
- ObservedUpward travel and final arrival were captured with the expected motion commands and clean stop at target.

*DB_IO.FinalCmd.MotorUp	Bool	TRUE			
*DB_IO.FinalCmd.MotorDown	Bool	FALSE			
*DB_IO.FinalCmd.DriveEnable	Bool	TRUE			
*DB_IO.FinalCmd.BrakeRelease	Bool	TRUE			
*DB_IO.Feedback.CurrentFloor	DEC+	0			
*DB_IO.Feedback.DoorClosed	Bool	TRUE			
*DB_IO.Feedback.DoorLocked	Bool	TRUE			
*DB_IO.Feedback.DriveReady	Bool	TRUE			
*DB_IO.Feedback.SafetyChainOK	Bool	TRUE			
*DB_System.ControllerStatus.OperatingMode	DEC	1			
*DB_System.ControllerStatus.AutoState	DEC	50			
*DB_System.ControllerStatus.TargetFloor	DEC+	3			
*F_SafeMotionEnable	%Q210.0	TRUE		Fail-safe motion-enable output	
*DB_System.ControllerStatus.SystemEnabled	Bool	TRUE			
<Add new>					

EL-F01-C

Normal upward travel: target above current floor, AutoState 50, MotorUp/DriveEnable/BrakeRelease TRUE, F_SafeMotionEnable TRUE.

*DB_IO.FinalCmd.MotorUp	Bool	FALSE			
*DB_IO.FinalCmd.MotorDown	Bool	FALSE			
*DB_IO.FinalCmd.DriveEnable	Bool	FALSE			
*DB_IO.FinalCmd.BrakeRelease	Bool	FALSE			
*DB_IO.Feedback.CurrentFloor	DEC+	3			
*DB_IO.Feedback.DoorClosed	Bool	TRUE			
*DB_IO.Feedback.DoorLocked	Bool	TRUE			
*DB_IO.Feedback.DriveReady	Bool	TRUE			
*DB_IO.Feedback.SafetyChainOK	Bool	TRUE			
*DB_System.ControllerStatus.OperatingMode	DEC	1			
*DB_System.ControllerStatus.AutoState	DEC	10			
*DB_System.ControllerStatus.TargetFloor	DEC+	3			
*F_SafeMotionEnable	%Q210.0	TRUE		Fail-safe motion-enable output	
*DB_System.ControllerStatus.SystemEnabled	Bool	TRUE			
<Add new>					

EL-F01-D

Arrival at target: current floor equals target, AutoState returned to non-motion state, final commands off.

Observed Sequence snapshots show coherent target/state progression and arrival with final outputs removed.

EL-F02-C
Arrival at target with final outputs removed.

- Check

Inhibit motion during an unsafe/interlocked state
- Observed

Final motion remained inhibited during the tested interlock state and controlled operation resumed only through the recovery path.

"DB_IO".FinalCmd.MotorUp	Bool	☐	FALSE	☐		
"DB_IO".FinalCmd.MotorDown	Bool	☐	FALSE	☐		
"DB_IO".FinalCmd.DriveEnable	Bool	☐	FALSE	☐		
"DB_IO".FinalCmd.BrakeRelease	Bool	☐	FALSE	☐		
"DB_IO".Feedback.CurrentFloor	DEC+	☐	4	☐		
"DB_IO".Feedback.DoorClosed	Bool	☐	TRUE	☐		
"DB_IO".Feedback.DoorLocked	Bool	☐	TRUE	☐		
"DB_IO".Feedback.DriveReady	Bool	☐	TRUE	☐		
"DB_IO".Feedback.SafetyChainOK	Bool	☐	TRUE	☐		
"DB_System".ControllerStatus.OperatingMode	DEC	☐	1	☐		
"DB_System".ControllerStatus.AutoState	DEC	☐	10	☐		
"DB_System".ControllerStatus.TargetFloor	DEC+	☐	4	☐		
"F_SafeMotionEnable"	Bool	☒	FALSE	☐	Fail-safe motion-enable output	
"DB_System".ControllerStatus.SystemEnabled	Bool	☐	TRUE	☐		
<Add new>						

EL-F03-10
Movement inhibited with F_SafeMotionEnable false; final motion commands off.

"DB_IO".FinalCmd.MotorUp	Bool	☐	FALSE	☐		
"DB_IO".FinalCmd.MotorDown	Bool	☒	TRUE	☐		
"DB_IO".FinalCmd.DriveEnable	Bool	☒	TRUE	☐		
"DB_IO".FinalCmd.BrakeRelease	Bool	☒	TRUE	☐		
"DB_IO".Feedback.CurrentFloor	DEC+	☐	4	☐		
"DB_IO".Feedback.DoorClosed	Bool	☐	TRUE	☐		
"DB_IO".Feedback.DoorLocked	Bool	☐	TRUE	☐		
"DB_IO".Feedback.DriveReady	Bool	☐	TRUE	☐		
"DB_IO".Feedback.SafetyChainOK	Bool	☐	TRUE	☐		
"DB_System".ControllerStatus.OperatingMode	DEC	☐	1	☐		
"DB_System".ControllerStatus.AutoState	DEC	☐	60	☐		
"DB_System".ControllerStatus.TargetFloor	DEC+	☐	1	☐		
"F_SafeMotionEnable"	Bool	☒	TRUE	☐	Fail-safe motion-enable output	
"DB_System".ControllerStatus.SystemEnabled	Bool	☐	TRUE	☐		
<Add new>						

EL-F03-16
After deliberate recovery/start, downward motion resumes with safety permission true.

Check Fault, stop, reset and deliberately restart after a door-stuck condition

Observed The injected door-stuck condition produced state 900 and alarm word 16#0000_0002 with final motion off; reset and deliberate Start restored travel.

*DB_IO".FinalCmd.MotorUp	Bool	☐	FALSE			
*DB_IO".FinalCmd.MotorDown	Bool	☐	FALSE			
*DB_IO".FinalCmd.DriveEnable	Bool	☐	FALSE			
*DB_IO".FinalCmd.BrakeRelease	Bool	☐	FALSE			
*DB_IO".Feedback.CurrentFloor	DEC+/-	☐	3			
*DB_IO".Feedback.DoorClosed	Bool	☒	TRUE			
*DB_IO".Feedback.DoorLocked	Bool	☒	TRUE			
*DB_IO".Feedback.DriveReady	Bool	☒	TRUE			
*DB_IO".Feedback.SafetyChainOK	Bool	☒	TRUE			
*DB_System".ControllerStatus.OperatingMode	DEC	☐	4			
*DB_System".ControllerStatus.AutoState	DEC	☐	900			
*DB_System".ControllerStatus.TargetFloor	DEC+/-	☐	3			
*F_SafeMotionEnable"	%Q210.0	Bool	☒	TRUE		Fail-safe motion-enable output
*DB_System".ControllerStatus.SystemEnabled	Bool	☐	FALSE			
*DB_HM".Command.InjectDoorStuck	Bool	☒	TRUE			
*DB_System".ControllerStatus.FaultActive	Bool	☒	TRUE			
*DB_System".ControllerStatus.GeneralFault	Bool	☒	TRUE			
*DB_System".ControllerStatus.AlarmWord	Hex	☐	16#0000_0002			
*DB_System".ControllerStatus.RawAlarmWord	Hex	☐	16#0000_0000			
*DB_System".ControllerStatus.MaintenanceState	DEC	☐	0			
*DB_ElevatorController".stMaintenanceActive	Bool	☐	FALSE			
*DB_HM".Command JogUp	Bool	☐	FALSE			
*DB_HM".Command JogDown	Bool	☐	FALSE			
*DB_ElevatorController".stMaintCmd.MotorUp	Bool	☐	FALSE			
*DB_ElevatorController".stMaintCmd.MotorDown	Bool	☐	FALSE			
*DB_HM".Command Stop	Bool	☐	FALSE			
*DB_HM".Command Reset	Bool	☐	FALSE			
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☐	FALSE			
<Add new>						

EL-F04-20

Fault state: AutoState 900, FaultActive/GeneralFault TRUE, AlarmWord 16#0000_0002, outputs off.

*DB_IO".FinalCmd.MotorUp	Bool	☐	FALSE			
*DB_IO".FinalCmd.MotorDown	Bool	☒	TRUE			
*DB_IO".FinalCmd.DriveEnable	Bool	☒	TRUE			
*DB_IO".FinalCmd.BrakeRelease	Bool	☒	TRUE			
*DB_IO".Feedback.CurrentFloor	DEC+/-	☐	3			
*DB_IO".Feedback.DoorClosed	Bool	☒	TRUE			
*DB_IO".Feedback.DoorLocked	Bool	☒	TRUE			
*DB_IO".Feedback.DriveReady	Bool	☒	TRUE			
*DB_IO".Feedback.SafetyChainOK	Bool	☒	TRUE			
*DB_System".ControllerStatus.OperatingMode	DEC	☐	11			
*DB_System".ControllerStatus.AutoState	DEC	☐	60			
*DB_System".ControllerStatus.TargetFloor	DEC+/-	☐	2			Fail-safe motion-enable output
*F_SafeMotionEnable"	%Q210.0	Bool	☒	TRUE		
*DB_System".ControllerStatus.SystemEnabled	Bool	☒	TRUE			
*DB_HM".Command.InjectDoorStuck	Bool	☐	FALSE			
*DB_System".ControllerStatus.FaultActive	Bool	☐	FALSE			
*DB_System".ControllerStatus.GeneralFault	Bool	☐	FALSE			
*DB_System".ControllerStatus.AlarmWord	Hex	☐	16#0000_0000			
*DB_System".ControllerStatus.RawAlarmWord	Hex	☐	16#0000_0000			
*DB_System".ControllerStatus.MaintenanceState	DEC	☐	0			
*DB_ElevatorController".stMaintenanceActive	Bool	☐	FALSE			
*DB_HM".Command JogUp	Bool	☐	FALSE			
*DB_HM".Command JogDown	Bool	☐	FALSE			
*DB_ElevatorController".stMaintCmd.MotorUp	Bool	☐	FALSE			
*DB_ElevatorController".stMaintCmd.MotorDown	Bool	☐	FALSE			
*DB_HM".Command Stop	Bool	☐	FALSE			
*DB_HM".Command Reset	Bool	☐	FALSE			
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE			
<Add new>						

EL-F04-24

Deliberate restart after recovery: downward motion active again, no fault, F_SafeMotionEnable TRUE.

- Check

Jog Up/Down only through maintenance mode
- Observed

Maintenance states 810/820 produced the requested jog; releasing the command returned to 800 and removed motion.

*DB_IO".FinalCmd.MotorUp	Bool	☒	TRUE						
*DB_IO".FinalCmd.MotorDown	Bool	☐	FALSE						
*DB_IO".FinalCmd.DriveEnable	Bool	☒	TRUE						
*DB_IO".FinalCmd.BrakeRelease	Bool	☒	TRUE						
*DB_IO".Feedback.CurrentFloor	DEC+-		2						
*DB_IO".Feedback.DoorClosed	Bool	☒	TRUE						
*DB_IO".Feedback.DoorLocked	Bool	☒	TRUE						
*DB_IO".Feedback.DriveReady	Bool	☒	TRUE						
*DB_IO".Feedback.SafetyChainOK	Bool	☒	TRUE						
*DB_System".ControllerStatus.OperatingMode	DEC		3						
*DB_System".ControllerStatus.AutoState	DEC		0						
*DB_System".ControllerStatus.TargetFloor	DEC+-		2						
*F_SafeMotionEnable"	%Q210.0	Bool	☒	TRUE				Fail-safe motion-enable output	
*DB_System".ControllerStatus.SystemEnabled	Bool	☒	TRUE						
*DB_HM".Command.InjectDoorStuck	Bool	☐	FALSE						
*DB_System".ControllerStatus.FaultActive	Bool	☐	FALSE						
*DB_System".ControllerStatus.GeneralFault	Bool	☐	FALSE						
*DB_System".ControllerStatus.AlarmWord	Hex		16#0000_0000						
*DB_System".ControllerStatus.RawAlarmWord	Hex		16#0000_0000						
*DB_System".ControllerStatus.MaintenanceState	DEC		810						
*DB_ElevatorController".stMaintenanceActive	Bool	☒	TRUE						
*DB_HM".Command.JogUp	Bool	☒	TRUE						
*DB_HM".Command.JogDown	Bool	☐	FALSE						
*DB_ElevatorController".stMaintCmd.MotorUp	Bool	☒	TRUE						
*DB_ElevatorController".stMaintCmd.MotorDown	Bool	☐	FALSE						
*DB_HM".Command.Stop	Bool	☐	FALSE						
*DB_HM".Command.Reset	Bool	☐	FALSE						
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE						
<Add new>									

EL-F05-27
JogUp: MaintenanceState 810, JogUp/stMaintCmd.MotorUp TRUE, final MotorUp/DriveEnable/BrakeRelease TRUE.

*DB_IO".FinalCmd.MotorUp	Bool	☐	FALSE						
*DB_IO".FinalCmd.MotorDown	Bool	☒	TRUE						
*DB_IO".FinalCmd.DriveEnable	Bool	☒	TRUE						
*DB_IO".FinalCmd.BrakeRelease	Bool	☒	TRUE						
*DB_IO".Feedback.CurrentFloor	DEC+-		3						
*DB_IO".Feedback.DoorClosed	Bool	☒	TRUE						
*DB_IO".Feedback.DoorLocked	Bool	☒	TRUE						
*DB_IO".Feedback.DriveReady	Bool	☒	TRUE						
*DB_IO".Feedback.SafetyChainOK	Bool	☒	TRUE						
*DB_System".ControllerStatus.OperatingMode	DEC		3						
*DB_System".ControllerStatus.AutoState	DEC		0						
*DB_System".ControllerStatus.TargetFloor	DEC+-		2						
*F_SafeMotionEnable"	%Q210.0	Bool	☒	TRUE				Fail-safe motion-enable output	
*DB_System".ControllerStatus.SystemEnabled	Bool	☒	TRUE						
*DB_HM".Command.InjectDoorStuck	Bool	☐	FALSE						
*DB_System".ControllerStatus.FaultActive	Bool	☐	FALSE						
*DB_System".ControllerStatus.GeneralFault	Bool	☐	FALSE						
*DB_System".ControllerStatus.AlarmWord	Hex		16#0000_0000						
*DB_System".ControllerStatus.RawAlarmWord	Hex		16#0000_0000						
*DB_System".ControllerStatus.MaintenanceState	DEC		820						
*DB_ElevatorController".stMaintenanceActive	Bool	☒	TRUE						
*DB_HM".Command.JogUp	Bool	☐	FALSE						
*DB_HM".Command.JogDown	Bool	☒	TRUE						
*DB_ElevatorController".stMaintCmd.MotorUp	Bool	☐	FALSE						
*DB_ElevatorController".stMaintCmd.MotorDown	Bool	☒	TRUE						
*DB_HM".Command.Stop	Bool	☐	FALSE						
*DB_HM".Command.Reset	Bool	☐	FALSE						
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE						
<Add new>									

EL-F05-29
JogDown: MaintenanceState 820, JogDown/stMaintCmd.MotorDown TRUE, final MotorDown/DriveEnable/BrakeRelease TRUE.

- Check
- Stop active motion and require a new start
- Observed
- Stop removed the final commands; a deliberate restart later restored valid travel.

*DB_IO"FinalCmd.MotorUp	Bool	☒	TRUE						
*DB_IO"FinalCmd.MotorDown	Bool	☐	FALSE						
*DB_IO"FinalCmd.DriveEnable	Bool	☒	TRUE						
*DB_IO"FinalCmd.BrakeRelease	Bool	☒	TRUE						
*DB_IO"Feedback.CurrentFloor	DEC+/-	☐	2						
*DB_IO"Feedback.DoorClosed	Bool	☒	TRUE						
*DB_IO"Feedback.DoorLocked	Bool	☒	TRUE						
*DB_IO"Feedback.DriveReady	Bool	☒	TRUE						
*DB_IO"Feedback.SafetyChainOK	Bool	☒	TRUE						
*DB_System"ControllerStatus.OperatingMode	DEC	☐	1						
*DB_System"ControllerStatus.AutoState	DEC	☐	50						
*DB_System"ControllerStatus.TargetFloor	DEC+/-	☐	4						
*F_SafeMotionEnable	%Q210.0	Bool	☒	TRUE				Fail-safe motion-enable output	
*DB_System"ControllerStatus.SystemEnabled	Bool	☒	TRUE						
*DB_HM"Command.InjectDoorStuck	Bool	☒	FALSE						
*DB_System"ControllerStatus.FaultActive	Bool	☒	FALSE						
*DB_System"ControllerStatus.GeneralFault	Bool	☒	FALSE						
*DB_System"ControllerStatus.AlarmWord	Hex	☐	16#0000_0000						
*DB_System"ControllerStatus.RawAlarmWord	Hex	☐	16#0000_0000						
*DB_System"ControllerStatus.MaintenanceState	DEC	☐	0						
*DB_ElevatorController".stMaintenanceActive	Bool	☐	FALSE						
*DB_HM"Command.JogUp	Bool	☐	FALSE						
*DB_HM"Command.JogDown	Bool	☐	FALSE						
*DB_ElevatorController".stMaintCmd.MotorUp	Bool	☐	FALSE						
*DB_ElevatorController".stMaintCmd.MotorDown	Bool	☐	FALSE						
*DB_HM"Command.Stop	Bool	☐	FALSE						
*DB_HM"Command.Reset	Bool	☐	FALSE						
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE						

EL-F06-32
Moving upward before STOP: target above current floor, AutoState 50, movement outputs active.

*DB_IO"FinalCmd.MotorUp	Bool	☐	FALSE						
*DB_IO"FinalCmd.MotorDown	Bool	☐	FALSE						
*DB_IO"FinalCmd.DriveEnable	Bool	☐	FALSE						
*DB_IO"FinalCmd.BrakeRelease	Bool	☐	FALSE						
*DB_IO"Feedback.CurrentFloor	DEC+/-	☐	3						
*DB_IO"Feedback.DoorClosed	Bool	☒	TRUE						
*DB_IO"Feedback.DoorLocked	Bool	☒	TRUE						
*DB_IO"Feedback.DriveReady	Bool	☒	TRUE						
*DB_IO"Feedback.SafetyChainOK	Bool	☒	TRUE						
*DB_System"ControllerStatus.OperatingMode	DEC	☐	0						
*DB_System"ControllerStatus.AutoState	DEC	☐	0						
*DB_System"ControllerStatus.TargetFloor	DEC+/-	☐	4						
*F_SafeMotionEnable	%Q210.0	Bool	☒	TRUE				Fail-safe motion-enable output	
*DB_System"ControllerStatus.SystemEnabled	Bool	☐	FALSE						
*DB_HM"Command.InjectDoorStuck	Bool	☒	FALSE						
*DB_System"ControllerStatus.FaultActive	Bool	☐	FALSE						
*DB_System"ControllerStatus.GeneralFault	Bool	☐	FALSE						
*DB_System"ControllerStatus.AlarmWord	Hex	☐	16#0000_0000						
*DB_System"ControllerStatus.RawAlarmWord	Hex	☐	16#0000_0000						
*DB_System"ControllerStatus.MaintenanceState	DEC	☐	0						
*DB_ElevatorController".stMaintenanceActive	Bool	☐	FALSE						
*DB_HM"Command.JogUp	Bool	☐	FALSE						
*DB_HM"Command.JogDown	Bool	☐	FALSE						
*DB_ElevatorController".stMaintCmd.MotorUp	Bool	☐	FALSE						
*DB_ElevatorController".stMaintCmd.MotorDown	Bool	☐	FALSE						
*DB_HM"Command.Stop	Bool	☐	FALSE						
*DB_HM"Command.Reset	Bool	☐	FALSE						
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE						

EL-F06-33
After STOP: OperatingMode 0 / AutoState 0, SystemEnabled FALSE, final motion outputs off.

- CheckGate the real final motion path with F_SafeMotionEnable
- ObservedWith the standard controller requesting travel and F_SafeMotionEnable false, MotorUp/MotorDown/DriveEnable/BrakeRelease remained false.

*DB_IO" FinalCmd.MotorUp	Bool	☐	FALSE			
*DB_IO" FinalCmd.MotorDown	Bool	☐	FALSE			
*DB_IO" FinalCmd.DriveEnable	Bool	☐	FALSE			
*DB_IO" FinalCmd.BrakeRelease	Bool	☐	FALSE			
*DB_IO" Feedback.CurrentFloor	DEC+	☐	4			
*DB_IO" Feedback.DoorClosed	Bool	☒	TRUE			
*DB_IO" Feedback.DoorLocked	Bool	☒	TRUE			
*DB_IO" Feedback.DriveReady	Bool	☒	TRUE			
*DB_IO" Feedback.SafetyChainOk	Bool	☒	TRUE			
*DB_System" ControllerStatus.OperatingMode	DEC	☐	1			
*DB_System" ControllerStatus.AutoState	DEC	☐	10			
*DB_System" ControllerStatus.TargetFloor	DEC+	☐	4			
*F_SafeMotionEnable	%Q210.0	Bool	☒	TRUE		Fail-safe motion-enable output
*DB_System" ControllerStatus.SystemEnabled	Bool	☒	TRUE			
*DB_HM" Command.InjectDoorStuck	Bool	☒	FALSE			
*DB_System" ControllerStatus.FaultActive	Bool	☒	FALSE			
*DB_System" ControllerStatus.GeneralFault	Bool	☒	FALSE			
*DB_System" ControllerStatus.AlarmWord	Hex	☐	16#0000_0000			
*DB_System" ControllerStatus.RawAlarmWord	Hex	☐	16#0000_0000			
*DB_System" ControllerStatus.MaintenanceState	DEC	☐	0			
*DB_ElevatorController".stMaintenanceActive	Bool	☐	FALSE			
*DB_HM" Command.JogUp	Bool	☐	FALSE			
*DB_HM" Command.JogDown	Bool	☐	FALSE			
*DB_ElevatorController".stMainCmd.MotorUp	Bool	☐	FALSE			
*DB_ElevatorController".stMainCmd.MotorDown	Bool	☐	FALSE			
*DB_HM" Command.Stop	Bool	☐	FALSE			
*DB_HM" Command.Reset	Bool	☐	FALSE			
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE			

EL-F07-A
Safety-integration healthy baseline: F_SafeMotionEnable TRUE, no movement request at target.

*DB_IO" FinalCmd.MotorUp	Bool	☐	FALSE			
*DB_IO" FinalCmd.MotorDown	Bool	☐	FALSE			
*DB_IO" FinalCmd.DriveEnable	Bool	☐	FALSE			
*DB_IO" FinalCmd.BrakeRelease	Bool	☐	FALSE			
*DB_IO" Feedback.CurrentFloor	DEC+	☐	4			
*DB_IO" Feedback.DoorClosed	Bool	☒	TRUE			
*DB_IO" Feedback.DoorLocked	Bool	☒	TRUE			
*DB_IO" Feedback.DriveReady	Bool	☒	TRUE			
*DB_IO" Feedback.SafetyChainOk	Bool	☒	TRUE			
*DB_System" ControllerStatus.OperatingMode	DEC	☐	1			
*DB_System" ControllerStatus.AutoState	DEC	☐	60			
*DB_System" ControllerStatus.TargetFloor	DEC+	☐	2			
*F_SafeMotionEnable	%Q210.0	Bool	☐	FALSE		Fail-safe motion-enable output
*DB_System" ControllerStatus.SystemEnabled	Bool	☒	TRUE			
*DB_HM" Command.InjectDoorStuck	Bool	☐	FALSE			
*DB_System" ControllerStatus.FaultActive	Bool	☐	FALSE			
*DB_System" ControllerStatus.GeneralFault	Bool	☐	FALSE			
*DB_System" ControllerStatus.AlarmWord	Hex	☐	16#0000_0000			
*DB_System" ControllerStatus.RawAlarmWord	Hex	☐	16#0000_0000			
*DB_System" ControllerStatus.MaintenanceState	DEC	☐	0			
*DB_ElevatorController".stMaintenanceActive	Bool	☐	FALSE			
*DB_HM" Command.JogUp	Bool	☐	FALSE			
*DB_HM" Command.JogDown	Bool	☐	FALSE			
*DB_ElevatorController".stMainCmd.MotorUp	Bool	☐	FALSE			
*DB_ElevatorController".stMainCmd.MotorDown	Bool	☐	FALSE			
*DB_HM" Command.Stop	Bool	☐	FALSE			
*DB_HM" Command.Reset	Bool	☐	FALSE			
*DB_ElevatorController".stSafetyMovementPermitted	Bool	☒	TRUE			

EL-F07-B
Key integration proof: controller AutoState 60 / target below current floor while F_SafeMotionEnable FALSE; FinalCmd MotorUp/MotorDown/DriveEnable/BrakeRelease all FALSE.