Peripheral Device Troubleshooting Assignment

1. Common USB Keyboard or Mouse Issues and Solutions

Issue	Possible Solution
USB keyboard/mouse is not detected	Unplug the device and connect it to another USB port. Restart the laptop if necessary.
Keyboard or mouse works intermittently	Check whether the USB connector or cable is loose or damaged, and try another USB port
Mouse cursor is not moving properly	Clean the mouse sensor and try using it on a suitable flat surface; also reconnect the USB
Some keyboard keys are not working	Reconnect the keyboard and test it in another USB port. If only certain keys fail, check for d
USB device driver has a problem	Open Device Manager, locate the keyboard/mouse, update or reinstall its driver, and restar

2. Bluetooth Headphones Not Connecting to a Phone – Troubleshooting Flow

1. Check that the headphones are powered ON and have enough battery.

2. Put the headphones into Bluetooth pairing mode. Check for a flashing pairing indicator/light or a pairing sound.

3. On the phone, open Settings → Bluetooth (or Connected devices → Bluetooth) and make sure Bluetooth is ON.

4. Check the list of available devices and select the headphones' name.

5. If the headphones are listed under paired devices but will not connect, tap the device name and choose Forget/Unpair.

6. Turn Bluetooth OFF, wait a few seconds, then turn it ON again.

7. Restart the phone and put the headphones back into pairing mode.

8. Check whether the headphones are already connected to another phone, laptop, or tablet. Disconnect them there if necessary.

9. Try pairing again and check whether the phone shows a Connected status and whether audio output is routed to the headphones.

10. If it still fails, reset the headphones according to the manufacturer's instructions and repeat the pairing process.

3. External Webcam Not Detected in Zoom on Windows 10 – 6-Point Checklist

1. Check the USB connection: unplug the webcam, connect it to another USB port, and make sure its indicator light (if present) behaves normally.

2. Check Device Manager: right-click Start → Device Manager → Cameras/Imaging devices. Look for the webcam and update its driver if needed.

3. Check Windows camera privacy: Settings → Privacy → Camera. Turn on 'Allow access to the camera on this device' and allow apps to access the camera.

4. Check Zoom permissions/settings: open Zoom Settings → Video and select the external webcam from the Camera list.

5. Close other apps using the webcam, such as Teams, Skype, Camera, or another browser tab, then restart Zoom.

6. Restart Windows and, if the webcam is still missing, reinstall/update the webcam driver or test the webcam on another computer.

4. Printer Showing 'Offline' – Using Windows Troubleshooter

1. Make sure the printer is powered ON and connected to the PC by USB or to the same Wi-Fi network.

2. Open Windows Settings → Devices → Printers & scanners.

3. Select the affected printer and choose Manage. Use the available Windows troubleshooting option, or open the Windows printer troubleshooter if your Windows version provides it.

4. Follow the on-screen instructions. Windows checks common problems such as printer connection, driver/settings issues, queue problems, and whether the printer is available.

5. If Windows finds a problem, it reports the issue and may automatically apply a recommended fix. If it cannot fix the issue, it indicates what was detected and may suggest further actions.

6. After troubleshooting, print a test page to confirm whether the printer has returned to an online/working state.

Information provided by the troubleshooter: It can indicate whether Windows can communicate with the printer, identify common configuration or driver problems, report detected errors, and show whether a recommended repair was applied successfully.

Conclusion: A systematic troubleshooting process helps identify whether the problem is caused by a connection, driver, permission, device setting, or application issue.