


TODO: CHECK FOR PIN SHARING WITH LAUNCHPAD HARDWARE

BOOSTER SITE 1



TODO: BMS GIO may be rearranged as needed for layout

J9 Pins 8,9 on Launchpad



NOTES:

Use RM57 Launchpad

Remove JP6 from Launchpad for powering through node.

RM57 CPU Core

Sheet: /RM57 Core/ File: RM57 Core.sch

Title:

 Size: A4
 Date:
 Rev:

 KiCad E.D.A. kicad 4.0.6
 Id: 4/9

