


TODO: CHECK FOR PIN SHARING WITH LAUNCHPAD HARDWARE

BOOSTER SITE 1



J9 Pins 8,9 on Launchpad



NOTES:

Use RM57 Launchpad Remove JP6 from Launchpad for powering through node.

Sheet: /RM57 COre/
File: RM57 Core.sch

Title:
Size: A4 Date: Rev:
KiCad E.D.A. kicad 4.0.6 Id: 4/10

