

## AT1 COMMANDS LIST

| No.                  | Function                                | Command                                                                                                                                             | Reply                                                                                                       | Explanation                                                                                                                                                                                                                                                                                                       |
|----------------------|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>QUERY CLASS</b>   |                                         |                                                                                                                                                     |                                                                                                             |                                                                                                                                                                                                                                                                                                                   |
| 1                    | Check firmware version                  | VERSION#                                                                                                                                            | [VERSION]<br>GT300F_11_A1AM3_D23_R0_V05_WM                                                                  |                                                                                                                                                                                                                                                                                                                   |
| 2                    | Check parameters                        | PARAM#                                                                                                                                              | IMEI:868120210256738; TIMER:5; SENDS:3; SOS:;; Sensorset:10,3,5,1; TimeZone:E,8,0;                          |                                                                                                                                                                                                                                                                                                                   |
| 3                    | Query device network setting            | GPRSSET#                                                                                                                                            | GPRS:ON; Currently use APN:;; Server:1.gpsdev.tracksolid.com,21100,0; URL:http://maps.google.com/maps?q=;   |                                                                                                                                                                                                                                                                                                                   |
| 4                    | Check status                            | STATUS#                                                                                                                                             | Battery:4.06V,NORMAL; GPRS:Link Up GSM Signal Level:Strong; GPS:OFF; Defense:OFF;                           |                                                                                                                                                                                                                                                                                                                   |
| 5                    | Check position status                   | WHERE#                                                                                                                                              | Last position! Lat:N22.551825, Lon:E113.940834, Course:252.38, Speed:0.00Km/h, DateTime:2016-05-11 18:00:57 |                                                                                                                                                                                                                                                                                                                   |
| 6                    | Check URL                               | URL#                                                                                                                                                | 05-11 18:00http://maps.google.com/maps?q=N22.551825,E113.940834                                             |                                                                                                                                                                                                                                                                                                                   |
| 7                    | Check position                          | POSITION                                                                                                                                            | e.g.<br>01-08<br>17:36http://maps.google.com/maps?q=N22.577156,E113.916748                                  |                                                                                                                                                                                                                                                                                                                   |
| <b>SETTING CLASS</b> |                                         |                                                                                                                                                     |                                                                                                             |                                                                                                                                                                                                                                                                                                                   |
| 1                    | Set APN                                 | APN, apnname#<br>OR<br>APN, apnname,user,pwd#<br>APN#                                                                                               |                                                                                                             | Close automatic APN and set by yourself.<br><br>Check the current APN parameters.                                                                                                                                                                                                                                 |
| 2                    | Set automatic APN                       | ASETAPN, X#<br>ASETAPN#                                                                                                                             |                                                                                                             | X=ON/OFF;<br>ON: open automatic APN;<br>OFF: close automatic APN.<br><br>Check automatic APN status                                                                                                                                                                                                               |
| 3                    | Set automatic GMT                       | ASETGMT,X#<br>ASETGMT#                                                                                                                              |                                                                                                             | X=ON/OFF;<br>ON: open automatic GMT;<br>OFF: close automatic GMT.<br><br>Check automatic GMT status                                                                                                                                                                                                               |
| 3                    | Set server parameters                   | SERVER,mode,domainName/IP, port,protocol#<br>SERVER#                                                                                                |                                                                                                             | eg: SERVER,1,www.ydpat.com,8011,0#<br>SERVER,0,211.154.135.113,8011,0#<br>mode = 1 means set with domain name<br>mode = 0 means set with ip address<br>protocol = 0 means connect server with TCP protocol<br>protocol = 1 means connect server with UDP protocol<br><br>Check the current sever parameters       |
| 4                    | Set GMT parameter                       | GMT,A,B,C#<br>GMT#                                                                                                                                  |                                                                                                             | A: E or W; "E" means eastern time zone, "W" means western time zone; default: E<br>B: 0~12; time zone default: 8<br>C: 0/15/30/45; half time zone; default: 0<br><br>Check the current time zone parameters                                                                                                       |
| 5                    | Restore to factory                      | FACTORY#                                                                                                                                            |                                                                                                             | Restore to factory setting                                                                                                                                                                                                                                                                                        |
| 6                    | Edit URL                                | EURL,network links#<br>EURL#                                                                                                                        |                                                                                                             | set the network links for latitude and longitude, default: http://maps.google.com/maps?q=<br><br>Check the current URL                                                                                                                                                                                            |
| 7                    | set language                            | LANG,A#<br>LANG#                                                                                                                                    |                                                                                                             | A=0/1; 0 means english; 1 means chinese<br><br>check the language setting                                                                                                                                                                                                                                         |
| 8                    | GPRS switch                             | GPRSON,X#<br>GPRSON#                                                                                                                                |                                                                                                             | X=0 or 1; "1" means GPRS ON, "0" means GPRS OFF, default:1<br><br>Check the current GPRS status                                                                                                                                                                                                                   |
| 9                    | Reboot                                  | RESET#                                                                                                                                              |                                                                                                             | The device would reboot in 20S after receiving the command.                                                                                                                                                                                                                                                       |
| 10                   | GPRS blocking alarm                     | GPRSALM,X#<br>GPRSALM#                                                                                                                              |                                                                                                             | X=ON/OFF, default: OFF<br><br>Check the GPRS alarm status                                                                                                                                                                                                                                                         |
| 11                   | SOS setting                             | SOS,A,phone number 1,phone number 2,phone number 3#<br>SOS,D,sequence number 1, sequence number 2,sequence number 3#<br>SOS,D,phone number#<br>SOS# |                                                                                                             | Add SOS phone number.<br><br>Delete the phone number according to the sequence number.<br><br>Delete the matching SOS phone number.<br><br>Check the SOS phone number.                                                                                                                                            |
| 12                   | Set which SOS number will receive Alarm | ALMREP,A,B,C#<br>ALMREP#                                                                                                                            |                                                                                                             | A=0/1; 0=Allow SOS Number #1 to receive alarms, 1=Allow SOS Number #1 to receive alarms;<br>B=0/1; 0=Allow SOS Number #2 to receive alarms, 1=Allow SOS Number #2 to receive alarms;<br>C=0/1; 0=Allow SOS Number #3 to receive alarms, 1=Allow SOS Number #3 to receive alarms;<br><br>check the current setting |

|    |                                       |                   |  |                                                                                                                                                                                                                                                                                                                    |
|----|---------------------------------------|-------------------|--|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    |                                       | HBT,T#            |  | T ranges 1~300 (minutes), heartbeat package upload interval ; default is 3;                                                                                                                                                                                                                                        |
| 13 | Heartbeat interval setting            | HBT#              |  | Check the current parameters of T.                                                                                                                                                                                                                                                                                 |
| 14 |                                       | ANGLEREP,X,A,B#   |  | X=ON/OFF, default : ON<br>A=5~180 degrees, diversion angle degree, default :20 degrees ;<br>B=2~5 seconds, detecting time, default :2 seconds,                                                                                                                                                                     |
|    | Set the angle upload                  | ANGLEREP,OFF#     |  | Close the angle upload.                                                                                                                                                                                                                                                                                            |
|    |                                       | ANGLEREP#         |  | Check the angle upload status and its parameters.                                                                                                                                                                                                                                                                  |
| 15 |                                       | BATCH,A,N#        |  | A= A=ON/OFF, data sending batch function on or off, default:OFF<br>N=1~50, N means the number of messages in the batch, default : 10;                                                                                                                                                                              |
|    | Set the GPS data sending batch        | BATCH#            |  | Check the number of messages in a batch.                                                                                                                                                                                                                                                                           |
| 16 |                                       | SENSOR,A,,B,C#    |  | A=10-300 seconds,detecting time. Default: 10 seconds<br>B=10-300 seconds, alert delay. Default:10 seconds<br>C=1-3000 minutes, vibration alert interval. Default: 5 minutes<br>SENSOR# Check the parameter of the status                                                                                           |
| 17 |                                       | SENDS,A#          |  | A=0-300(minute), time duration for GPS to work once vibration detected, 0 means GPS always on work, default: 3(minute)                                                                                                                                                                                             |
|    | Set the GPS controlled time by sensor | SENDS#            |  | Check the parameters of the time.                                                                                                                                                                                                                                                                                  |
| 18 | Arm/disarm manually                   | 111               |  | Arm                                                                                                                                                                                                                                                                                                                |
|    |                                       | 000               |  | disarm                                                                                                                                                                                                                                                                                                             |
| 19 | Set the vibration alarm               | SENALM,X,M#       |  | X=ON/OFF, default: ON;<br>M=0~3, way of alarming, 0 :GPRS only, 1: SMS+GPRS, 2 : GPRS+SMS+phone call, 3 :GPRS+phone call. default:1                                                                                                                                                                                |
|    |                                       | SENALM#           |  | Check the parameters of the alarm                                                                                                                                                                                                                                                                                  |
| 20 | Clear the backup data                 | CLEAR#            |  |                                                                                                                                                                                                                                                                                                                    |
| 21 | Set the static data filtering         | SF,A,B#           |  | A=ON/OFF; static drift filtering switch ; default: ON<br>B=10-1000(m) ; maximal filtering distance ; default: 100(m) ;                                                                                                                                                                                             |
|    |                                       | SF#               |  | Check the parameters.                                                                                                                                                                                                                                                                                              |
| 22 | Set the low battery alarm             | BATALM, A, M#     |  | A=ON/OFF, default : ON;<br>M=0/1, way of alarming, 0: GPRS only, 1: SMS+GPRS, 2 : GPRS+SMS+phone call, 3 :GPRS+phone call. default : 1 ;                                                                                                                                                                           |
|    |                                       | BATALM,OFF#       |  | Close the low battery alarm.                                                                                                                                                                                                                                                                                       |
|    |                                       | BATALM#           |  | Check the parameters of the alarm.                                                                                                                                                                                                                                                                                 |
| 23 | Set the dialing times                 | CALL,N#           |  | N=1~3, default :3, times to dial all numbers;                                                                                                                                                                                                                                                                      |
|    |                                       | CALL#             |  | Check the parameters of the dialing.                                                                                                                                                                                                                                                                               |
| 24 | Set the overspeed alarm               | SPEED,A,B,C,M#    |  | A=ON/OFF, open or close over speed alarm, default : OFF<br>B=5~600 (second), time interval, default :20 (second)<br>C=1~255(km/h), speed limit, default :100(km/h);<br>M=0~3, way of alarm, 0 : GPRS only, 1: SMS+GPRS, 2: GPRS+SMS+phone call, 3 :GPRS+phone call. default : 1                                    |
|    |                                       | SPEED#            |  | Check the parameters of over speed.                                                                                                                                                                                                                                                                                |
| 25 | Set sensitivity of SENSOR             | LEVEL,A#          |  | A=1-5: sensitivity range; default:2 The greater the level, the less the sensitivity<br>LEVEL# check the current sensitivity of sensor                                                                                                                                                                              |
| 26 | Set the instruction password          | PWDSW,A#          |  | A= ON, enable the instruction password.                                                                                                                                                                                                                                                                            |
|    |                                       | PWDSW,password,B# |  | Numbers and letters mix inputs supported for instruction password, at least 1 character, no more than 19 characters, default : 666666; B=OFF, disable the instruction password.                                                                                                                                    |
| 27 | Revise the instruction password       | PASSWORD,A,B#     |  | A=old password, numbers and letters mix inputs supported, at least 1 character, no more than 19 characters, default : 666666; B=new password, numbers and letters mix inputs supported, at least 1 character, no more than 19 characters.                                                                          |
| 28 | Set the SMS forwarding                | FW,A,B#           |  | A=phone number, phone number to send;<br>B=SMS content, content to forward.<br>Only SOS can use this command.                                                                                                                                                                                                      |
| 29 | GPS enter blind-zone alarm            | BLINDALM,A,B,C,M# |  | A=ON/OFF; default:OFF<br>B=5~600(second); time; default:60(second) alert delay time after GPS failed to locate<br>C=5~600(second); time; default:20(second) alert delay time after GPS start to locate again<br>M=0~3; alarm method: 0=GPRS only; 1=SMS+GPRS; 2=GPRS+SMS+phone call; 3=GPRS+phone call ; default:1 |
|    |                                       | BLINDALM#         |  | check current statue.                                                                                                                                                                                                                                                                                              |
| 30 | work mode                             | MODE,N,T#         |  | N=1/2, 1 : Positioning in a regular time interval; 2 : tracking mode, positioning while detects any movement, default: 2<br>N=1, T means GPS working time interval (0/5~7200 minutes), 0 means no location upload, default:30<br>N=2, T means upload interval in fixed time(10~1800 seconds) default:10            |
|    |                                       | MODE,N,T1,T2#     |  | N=3: Deep sleep mode, GPS works in a certain time;<br>T1 means starting time(format: HH:MM)<br>T2 means the time interval( value range 1, 2, 3, 4, 6, 8, 12, 24) unit :hour; default: 24                                                                                                                           |
|    |                                       | MODE#             |  | Query current work mode                                                                                                                                                                                                                                                                                            |
| 31 | Tamper alarm                          | REMALM,A,M#       |  | REMALM,A,M#<br>A=ON/OFF ; default: ON<br>M=0~3; way of alarming, 0 GPRS, 1 SMS+GPRS; M=2 GPRS+SMS+phone call; M=3 GPRS+phone call. default: 1;                                                                                                                                                                     |
|    |                                       | REMALM,OFF#       |  | Turn off the tamper alarm                                                                                                                                                                                                                                                                                          |

|    |                                          |                           |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----|------------------------------------------|---------------------------|--|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    |                                          | REMA#                     |  | Query the parameters that have been set                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 32 | Exit tamper alarm                        | CANCEL#                   |  | The terminal will exit the alarm tracking mode and back to original working mode after receiving the command.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 33 | Set voice alarm parameters               | SODALM,A,M,N,P,Q#         |  | A=ON/OFF; default:OFF<br>M is the function type after alarm triggered.<br>M=0 GPRS+automatic recording, M=1 Only GPRS, M=2 Only phone call monitoring, M=3 GPRS+phone call monitoring; default:3<br>N indicates the time of the voice activated alarm, and the range is 1-10 seconds; default:3<br>P is the time interval of voice-activated alarms, ranging from 1 to 60 minutes. The interval between automatic recording and monitoring starts as soon as the voice control triggered, rather than from the call end. default:2<br>Q is automatic recording time; range is 10-600,unit: second; default: 60 |
|    | Query set voice alarm                    | SODALM#                   |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 34 | Set the fence alarm                      | GFENCE,N,B,O,D,E,F,X,M#   |  | For Circular Geo-Fence setting<br>N=1-5; geo-fence serial number;<br>B=ON/OFF, open or close fence alarm, default: close;<br>D=the latitude of the circle center;<br>E=the longitude of the circle center;<br>F=1~9999, the fence radius, unit: 100 meters;<br>X=IN/OUT; IN: alarming when get in the fence, OUT: alarming when get out the fence, blank means both alarming when get in or get out the fence, default: blank.<br>M=0/1/2/3; way of alarming, 0: GPRS only, 1: SMS+GPRS, 2: GPRS+SMS+phone; 3: GPRS+phone default: 1                                                                           |
|    |                                          | GFENCE,N,B,1,D,E,F,G,X,M# |  | For Rectangular Geo-Fence setting<br>N=1-5;geo-fence serial number;<br>B=ON/OFF, open or close fence alarm, default: OFF;<br>D=the latitude of the position 1; range: -90 ~90(degree);<br>E=the longitude of the position 1; range: -180 ~180(degree);<br>F=the latitude of the position 2; range: -90 ~90(degree);<br>G=the longitude of the position 2; range: -180 ~180(degree);<br>the latitude supports "N/S" or "+/-" coming before it's value;<br>the longitude supports "E/W" or "+/-" coming before it's value;                                                                                       |
|    |                                          | GFENCE#                   |  | Check the parameters of the fence.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|    |                                          | GFENCE,N#                 |  | Query the parameters of geo-fence N                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 35 | Monitoring setting                       | MONITOR#                  |  | Request phone call monitoring                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|    |                                          | REMSET#                   |  | Query the parameters of remset                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 36 | Tracking Mode after Tamper Alarm setting | REMSET,A,B#               |  | A=1/2; 1=device switch to mode 1( Positioning in a regular time interval) after a tamper alert; 2=device switch to mode 2 (tracking mode) after a tamper alert; default: 2<br>B= B range: 3-120min, default:20                                                                                                                                                                                                                                                                                                                                                                                                 |
| 37 | WiFi setting                             | WF#                       |  | Check the current WiFi settings                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|    |                                          | WF,A,T1,T2#               |  | A=ON/OFF, default:OFF;<br>T1=Scan hot spots time; 1~60 seconds, default 10 seconds;<br>T2=WiFi packet upload interval; T2 range: 10 to 18000 seconds, default 600 seconds.                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|    |                                          | WIFION#                   |  | Open the WiFi at a time                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 38 | LBS setting                              | LBSON#                    |  | Check the current LBS status                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|    |                                          | LBSON,A,T1,T2#            |  | A=ON/OFF, default:OFF;<br>T1=LBS packet upload interval; 10~3600 seconds, default 60 seconds;<br>T2=LBS activated when GPS has not positioning for T2. T2 range: 10-3600seconds, default: 60seconds                                                                                                                                                                                                                                                                                                                                                                                                            |
| 39 | Device boot up notification setting      | BOOTALM,A,M#              |  | BOOTALM,A,M#<br>A=ON/OFF#<br>M=0/1; alarm method,0=GPRS only, 1=SMS+GPRS<br>BOOTALM,OFF# turn off boot alarm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|    |                                          | BOOTALM#                  |  | Check the current setting                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 40 | Limit Device poweroff setting            | PWRLIMIT,ON/OFF#          |  | PWRLIMIT,ON/OFF#<br>ON:allow user manually shutdown device<br>OFF:not allow user manually shutdown device                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|    |                                          | PWRLIMIT#                 |  | Check the current setting                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 41 | Dial Specific Number                     | DIAL,N,C#                 |  | DIAL,N,C#<br>N=Specific Number, set the number you want device to dial<br>C=Re-dial count,default 1,range 1-3                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 42 | Recording                                | LY,T#                     |  | record sound around. T=10~600 seconds. the default is 60.<br>LY# Active the recording function                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 42 | Trigger device to Record Sound           | CXLY,A,B#                 |  | CXLY,A,B#<br>A=ON/OFF;turn ON/OFF sound recording feature<br>B=record duration, default 30(s), range 10-300(s)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 43 | Ask for the location immediately         | LIDW#                     |  | The device will send current position on GPRS                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|    |                                          |                           |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|    |                                          |                           |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |