

Troubleshooting Guide

Common Issues

1. "Gateway Not Found" during Scan

- **Cause:** Firewall blocking UDP broadcast or mismatched subnet.
- **Solution:**
 - Ensure your computer is on the same IP subnet (e.g., 192.168.1.x) as the gateway.
 - Temporarily disable Windows Firewall to test.
 - Allow inbound UDP traffic on port 5353 (mDNS).

2. "EADDRINUSE" Error in Logs

- **Cause:** Another application is using a required port.
- **Solution:**
 - **Port 162 (SNMP):** Stop the Windows "SNMP Trap" service (services.msc).
 - **Port 7001 (Web):** Change the application port in Settings and restart.

3. "Start Polling" does nothing (Gateway Timeout)

- **Cause:** The gateway IP is incorrect, or the gateway is offline.
- **Solution:**
 - Ping the gateway IP from a command prompt.
 - Verify the gateway is powered on and has a solid green link LED.
 - Ensure "MODBUS TCP" is enabled in the Gateway Settings.

Ethernet Gateway Connection Issues (iMonnit)

If your Ethernet Gateway 4 is not connecting to iMonnit Online (Default Server status "Off" or "Server Error"), follow these diagnostic steps:

1. Check Power & Self-Test:

- Power cycle the gateway.



Monnit MODBUS TCP Utility

- Observe the LEDs. They should perform a "waterfall" sequence (scrolling light). If they display a solid pattern instead, the self-test failed (contact Monnit support).

2. Check Network Connection (Bottom LED):

- **Solid Green:** Gateway has an IP address and is communicating on the local Ethernet.
- **Red:** Gateway failed to retrieve an IP via DHCP. Check your router/switch.

3. Check Server Connection (Middle LED):

- **Green:** Successfully connected to iMonnit.
- **Red:** Failed to connect.
 - Ensure **Outbound TCP Port 3000** is open on your firewall.
 - Ensure your network DNS can resolve sensorsgateway.com.

Operating on a Private Network (Offline Mode)

To use the gateway exclusively with this utility (without iMonnit), you must configure it for **Private Mode**.

Prerequisites:

- The gateway must be **Unlocked** (purchased unlock code applied).
- The gateway firmware should be up to date.

Configuration Steps:

1. Open the **Gateway Settings** tab in this utility.
2. Select your gateway.
3. Go to the **Default Server** sub-tab.
4. Set the "Default Server" toggle to **Disable**.
5. Click **Save Changes**.
 - *Note:* This will stop the gateway from trying to contact iMonnit. The "Server" LED (Middle) may turn off or blink red/green depending on firmware, but the sensor network (Top LED) should remain active.



Monnit MODBUS TCP Utility

Important Note: If you disable the Default Server interface on a LOCKED gateway, the sensor network will disable itself, and you will receive no data. You MUST unlock the gateway first.