Thank you very much for purchasing Panasonic products. Please read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference.

Slim Body Area Sensor NA2-N Series

- If this product is used as a sensing device for personnel protection, serious body injury or death could result. Never use this product as a sensing device with any press machine, shearing machine, roll grinding machine, forming machine, vulcanizer, or robot etc. for protection of a hand or a part of the body.
- This product does not include a self-checking circuit for safety functions necessary to allow its use as a safety device. Thus, a system failure or malfunction can result in either an energized or a de-energized output condition.
- When this product is used as a sensing device in the following applications and if a problem relating to 'law' or 'product liability' occurs, Panasonic Electric Works SUNX shall not be liable for the failure and for the damage or less. Use of this product installed to a machinery or a device as a sensing device to detect a hand or a part of the operator's body entering a dangerous area
 - and stop the machinery or the device. 2) Installation of this product to a protection device for preventing to enter a dangerous area and use of this as a sensing device which detectes a hand or
 - a part of the operator's body and open/close the door or window.
 - 3) Use of this product as a sensing device for personnel protection (including interlock).
- For sensing devices to be used as safety devices for press machines or for personnel protection, use products which meet standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country
- In case of using as a safety device for press machines, use a product approved by the Ministry of Labor in Japan.


1 SPECIFICATIONS


WARNING

Number of beam channels		8	12	16	20	24	28		
`		Model	NPN output	NA2-N8	NA2-N12	NA2-N16	NA2-N20	NA2-N24	NA2-N28
Iter	n	No.	PNP output	NA2-N8-PN	NA2-N12-PN	NA2-N16-PN	NA2-N20-PN	NA2-N24-PN	NA2-N28-PN
Sensing height				140mm	220mm	300mm	380mm	460mm	540mm
Sei	nsin	g range		5m					
Bea	am p	oitch				201	nm		
Sei	nsin	g object		ϕ 30mm or more opaque object					
		voltage		12 to 24V DC±10% Ripple P-P 10% or less					
Power consumption	Emitter		icator ON	0.7W or less	0.8W or less	0.9W or less	1.0W or less	1.1W or less	1.2W or less
	Ш	Job indi	cator OFF	0.6W or less	0.7W or less	0.8W or less	0.9W or less	1.0W or less	1.1W or less
ver 00	Receiver		icator ON	0.7W or less	0.8W or less	0.9W or less	1.0W or less	1.1W or less	1.2W or less
Pov	Rec	Job indi	cator OFF	0.6W or less	0.7W or less	0.8W or less	0.9W or less	1.0W or less	1.1W or less
Output				 Maximum Applied volume Residual 2V or less 	collector trains sink current: bltage: 30V D (between out voltage: s (at 100mA since (at 16mA si	100mA C or less put and 0V)	Maximum Applied vo Residual v 2V or less		t: 100mA or less utput and +V)
Output operation			ration	ON when all beam channels are received (OFF when one or more beam channels are interrupted)					
Short-circuit protection			protection	Incorporated					
Response time				10ms or less (12ms or less when the interference prevention function is used)					
	Emitter		Emitting indicator: Green LED×2 (light up when the power is ON; one LED lights up for Frequency A setting, both LEDs light up for Frequency B setting) Job indicator: Red LED (lights up, blinks or lights off when the job indicator input is applied, selected by operation mode switch)						
Indicators	Receiver		Operation indicator: Red LED (lights up when one or more beam channels are interrupted) Stable incident beam indicator: Green LED (lights up when all beam channels are stably received) Job indicator: Red LED (lights up, blinks or lights off when the job indicator input is applied, selected by operation mode switch) *When an excess current flows through the output, the stable incident beam indicator and the operation indicator on the receiver blink simultaneously due to the operation of the short-circuit protection circuit.						
Ambient temperature			rature	-10 to +55°C (No dew condensation or icing allowed), Storage: -10 to +60°C					
Ambient humidity		35 to 85% RH, Storage: 35 to 85% RH							
Emitting element			nt	Infrared LED (modulated)					
Material				Enclosure: Heat-resistant ABS, Front cover: Polyacetal, Indicator cover: Acrylic					
Cable			<u> </u>	0.2mm ² 4-core oil-resistant cabtyre cable, 3m long					
Weight (total of the emitter and the receiver)			the receiver)	350g approx.	400g approx.	450g approx.	500g approx.	570g approx.	650g approx.

2 MOUNTING

- Use M4 screws with washers and M4 nuts. The tightening torque should be 0.5N · m or less. During mounting, do not apply any bending or twisting force to the sensor. (Please arrange the screws and nuts separately.)
- Sensor mounting brackets (MS-NA2-1, MS-NA1-1) are also available.






MS-NA1-1 assembly drawing NA2-N (-PN) Sensor mounting bracket Anti-rotation hool M4 screw with washers

3 CAUTIONS

- The CE conformity of the product is declared based on additional EMC contermeasures, which are explained in the manual and shall be realised by the installer Refer to ' 7 USE CONDITIONS TO COMPLY WITH CE MARKING' regarding intended products for CE marking.
- This product has been developed / produced for industrial use only.
- Make sure that the power supply is off while wiring.
- Take care that wrong wiring may damage the sensor
- Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- Extension up to total 25m is possible, for both emitter and receiver, with 0.2mm², or more, cable. However, in order to reduce noise, make the wiring as short as possible. Do not use during the initial transient time (500ms) after the power supply is switched on.
- Avoid dust, dirt, and steam.
- Take care that the sensor does not come in contact with water, oil, grease, or organic solvents, such as, thinner, etc.
- Do not use in an environment containing inflammable or explosive gas.
- Make sure to use an isolation transformer for the DC power supply. If an auto-transformer (single winding transformer) is used, this product or the power supply may get damaged.
- In case a surge is generated in the used power supply, connect a surge absorber to the supply and absorb the surge.
- Take care that the sensor is not directly exposed to fluorescent light from a rapid-starter lamp or a high frequency lighting device, as it may affect the sensing performance.
- The emitter and the receiver must face each other with their cable ends on the same side. If they are set upside down, the sensor will not work correctly.
- This sensor is suitable for indoor use only

4 I/O CIRCUIT DIAGRAMS


■ NA2-N□ / NPN output type



Internal circuit -→ Users' circuit Internal circuit -

Notes: 1) The input (pink) is the job indicator input when No. 4 of the operation mode switch on the emitter is set to the 'OFF' side, and it is the test input (emission halt input) when the switch is set to the 'ON' side.


- 2) In order to use the job indicator as a large operation indicator, connect the input (pink) of the emitter to the output (black) of the receiver.
- 3) When the test input (emission halt input) is set, the job indicator does not light up or blink.






Rugghölzli 2 CH - 5453 Busslingen Tel. +41 (0)56 222 38 18 Fax +41 (0)56 222 10 12 mailbox@sentronic.com www.sentronic.com

■ NA2-N□-PN / PNP output type




Notes: 1) The input (pink) is the job indicator input when No. 4 of the operation mode switch on the emitter is set to the 'OFF' side, and it is the test input (emission halt input) when the switch is set to the 'ON' side.

- 2) In order to use the job indicator as a large operation indicator, connect the input (pink) of the emitter to the output (black) of the receiver.
- 3) When the test input (emission halt input) is set, the job indicator does not light up or blink.



5 PART DESCRIPTION



Operation mode switch

No	Description	'OFF' side	'ON' side	
1	Emission frequency selection	Frequency A	Frequency B	
2	Job indicator operation selection	Lights up when job indicator input is Low	Lights off when job indicator input is Low	
3	Job indicator operation selection	Lights up	Blinks	
4	Operation indicator / test input (emission halt input) selection	Job indicator input	Test input (Emission halt input)	

6 JOB INDICATOR OPERATION SELECTION

The operation of the job indicator can be selected with the job indicator mode switch.

The operation of the jet maiotace can be delected that the jet maiotace made					
0 : -	Job indicator operation				
Operation mode switch	NPN output type	PNP output type	NPN output type	PNP output type	
SWILCIT	Job indicator input: Low	Job indicator input: High	Job indicator input: High	Job indicator input: Low	
1 2 3	Lights up		Lights off		
1 2 3	Lights off		Lights up		
1 2 3	Lights up		Blinks		
1 2 3	Lights off			Blinks	

Job indicator input signal condition

Output	Signal	Signal condition	
NDN autout tros	Low	0 to 2V	
NPN output type	High	5 to 30V, or open (Note)	
DND autout tune	Low	0 to 2V, or open (Note)	
PNP output type	High	8V to +V	

Note: Insulate the wire if it is kept open.

7 USE CONDITIONS TO COMPLY WITH CE MARKING


Intended products for CE marking NA2-N8(-PN), NA2-N12(-PN), NA2-N16(-PN), NA2-N20(-PN) NA2-N24(-PN), NA2-N28(-PN) NA2-N8-C5, NA2-N12-C5, NA2-N16-C5, NA2-N20-C5

NA2-N24-C5, NA2-N28-C5

Note: Contact our office regarding other than above models.

 Right work must be done in case of using this product as a CE marking conforming product.

> Prepare 2 pcs. of the following recommended ferrite core (or and equivalent product.) Recommended product>
> ESD-SR-110 [NEC TOKIN Co., LTD.]



8 IN CASE OF USING JOB INDICATOR AS LARGE OPERATION INDICATOR


 The job indicators can be used as large operation indicators by setting No. 4 of the operation mode switch to the 'OFF' side and connecting the input (pink) of the emitter to the output (black) of the receiver.

	1 (/		
Job indicator mode switch	Light state	Dark state	
1 2 3 4	Lights up	Lights off	
1 2 3 4	Lights off	Lights up	
1 2 3 4	Lights up	Blinks	
1 2 3 4	Lights off	Blinks	

Note: In order to use the job indicators as large operation indicators, make sure to set No. 4 of the operation mode switch to the 'OFF' side. If it is set to the 'ON' side, the job indicator does not light up or blink.

9 TEST INPUT (EMISSION HALT INPUT) FUNCTION

The emission is stopped when No. 4 of the operation mode switch is set to the 'ON' side and the input (pink) of the emitter is made High (PNP output type: Low). Since the output can be turned ON/OFF without the sensing object, this function is useful for start-up inspection. If the output follows the application/withdrawal of the test input (emission halt input), the sensor operation is normal, else it is abnormal.



Notes: 1) When the test input (emission halt input) function is set, the job indicator (red) does not light up or blink.

2) When emission is stopped during the test-run function, the emitter's emitting indicator (green) does not light up.


10 INTERFERENCE PREVENTION FUNCTION

● By setting different emission frequencies, two units of NA2-N can be mounted close together, as shown in the figure below. The emission frequency can be checked by the number of LEDs lighting up in the emitting indicator on the emitter.

	Operation mode switch	Emitting indicator (Emitter)	
Sensor (A)	A 2 3 4	One LED lights up	Sensor ®
Sensor ®	Frequency B B	Two LEDs	Senso

11 BEAM ALIGNMENT

- 1) Place the emitter and the receiver face to face along a straight line.
- 2 After the cables have been correctly connected, switch the power ON.
- ③ Move the emitter in the up, down, left and right directions, in order to determine the range of the beam received condition with the help of the operation indicator on the receiver. Then, set the emitter at the center of this range.



Sensor

Receiver

- (4) Similarly, adjust for up, down, left and right angular movement of the emitter.
- ⑤ Further, perform the angular adjustment for the receiver also.
- 6 Check that the stable incident beam indicator (green) lights up
- 7 Interrupt each beam channel with the actual sensing object, and confirm that the sensor operates correctly.

Note: The stable incident beam indicator (green) lights up when all the light beams are stably received.