

6- Serial Monitor - PowerPoint (Product Activation Failed)

File Home Insert Design Transitions Animations Slide Show Review View Developer Acrobat Tell me what you want to do... Sign in Share

Cut Copy Paste Format Painter New Slide Section Layout Reset Font Paragraph Drawing Shape Fill Shape Outline Shape Effects Find Replace Select Create a PDF Adobe Acrobat

Objectives

- Define the Serial Monitor
- Use the serial monitor
- Control a LED using the Arduino Serial Monitor
- Print comments on the serial monitor

dot-LABORATORY

Activate Windows Go to Settings to activate Windows.

meet.google.com is sharing your screen. Stop sharing Hide

Slide 2 of 32 Arabic (Lebanon) 116% 3:15 PM

Serial Monitor

A serial monitor is a pop-up Windows & it is a part of the Arduino IDE software.

- Its job is to allow you to both send messages from your computer to an Arduino board (over USB) and also to receive messages from the Arduino.
- **Arduino → PC:** Receives data from Arduino and display data on screen. This is usually used for debugging and monitoring
- **PC → Arduino:** Sends data (command) from PC to Arduino



dot

Activate Windows
Go to Settings to activate Windows.

meet.google.com is sharing your screen. Stop sharing Hide

Slide 4 of 32 C3 Arabic Lebanon

Search the web and Windows




116% 3:17 PM 7/1/2026 ENG

Serial Monitor


A serial monitor is a pop-up Windows & it is a part of the Arduino IDE software.

- Its job is to allow you to both send messages from your computer to an Arduino board (over USB) and also to receive messages from the Arduino.
- **Arduino → PC:** Receives data from Arduino and display data on screen. This is usually used for debugging and monitoring
- **PC → Arduino:** Sends data (command) from PC to Arduino



Serial Monitor Interface

1. **Output console:** display data received from Arduino
2. **Autoscroll checkbox:** option to select between automatically scroll and not scroll.
3. **Show timestamp checkbox:** option to show timestamp prior to data displayed on Serial Monitor.
4. **Clear output button:** clear all text on the output console.
5. **Baud rate selection:** select communication speed (baud rate) between Arduino and PC.



dot.

Activate Windows

Go to Settings to activate Windows.

meet.google.com is sharing your screen.

Stop sharing

Hide

Notes Comments

15%

PM


2023

Serial Communication or Baud Rates

- A baud is a measure of how many times the hardware can send **0s** and **1s** in a second.
- The baud rate must be set properly for the board to convert incoming and outgoing information to useful data.
- The Arduino board can communicate at various baud ("baud rates").

Example:

If your receiver is expecting to communicate at a baud rate of 2400, but your transmitter is transmitting at a different rate (for example 9600), the data you get will not make sense.



6- Serial Monitor - Powerpoint (Product Activation failed)


File Home Insert Design Transitions Animations Slide Show Review View Developer Acrobat Tell me what you want to do... Sign in Share

Cut Copy Paste Format Painter New Slide Layout Reset Section Clipboard Slides Font Paragraph Drawing Arranging Styles Shape Fill Shape Outline Shape Effects Find Replace Select Create a PDF Adobe Acrobat

Serial Communication or Baud Rates

9600 is a good baud rate to start with.

Other standard baud rates available on most Arduino modules include: 300, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 57600, or 115200 and you are free to specify other baud rates.



dot

Activate Windows Go to Settings to activate Windows.

mect.google.com is sharing your screen. Stop sharing Hide

Notes Comments 34 33 32 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1

Slide 9 of 32 Arabic (Lebanon)

sketch_jul21a | Arduino IDE 2.3.10

File Edit Sketch Tools Help

✓ → ⚙ Arduino UNO ▾

sketch_jul21a.ino

```
1 void setup() {  
2   // put your setup code here, to run once:  
3   Serial.begin(9600);  
4 }  
5  
6 void loop() {  
7   // put your main code here, to run repeatedly:  
8   Serial.print("Arduino Course by DOT Lebanon");  
9   delay(1000);  
10 }  
11
```

Output Serial Monitor X

Message (Enter to send message to 'Arduino UNO' on 'COM6')

DOT LebanonArduino Course by DOT LebanonArduino Course by DOT LebanonArduino Course by DOT LebanonArduino Course by DOT Lebanon

Necessary functions

`Serial.begin();`

This function will start the serial monitor. The serial monitor requires a baud rate. The standard for the baud refresh rate is 9600.

Example:

```
void setup() {  
  Serial.begin(9600);  
}
```

`Serial.print();`

`Serial.print();` will print the data written on the monitor Windows.


Example:

```
int i = 7;  
void loop() {  
  Serial.print("number i = ");  
  Serial.print(i);  
}  
// This will print: number i = 7
```



```
1 void setup() {  
2   // put your setup code here, to run once:  
3   Serial.begin(9600);  
4 }  
5  
6 void loop() {  
7   // put your main code here, to  
8   Serial.print("Arduino Course by ")  
9 }  
10
```

01/11 print(char) -> size_t



sketch_jul21a.ino

```
1 void setup() {  
2   // put your setup code here, to run once:  
3   Serial.begin(9600);  
4 }  
5  
6 void loop() {  
7   // put your main code here, to run repeatedly:  
8   Serial.println("Arduino Course by DOT Lebanon");  
9   delay(1000);  
10 }  
11
```

Output Serial Monitor X

Message (Enter to send message to 'Arduino UNO' on 'COM6')

```
15:40:56.245 -> Arduino Course by DOT Lebanon  
15:40:56.245 -> Arduino Course by DOT Lebanon  
15:40:56.245 -> Arduino Course by DOT Lebanon  
15:40:56.245 -> Arduino Course by DOT Lebanon  
15:40:57.864 -> Arduino Course by DOT Lebanon  
15:40:58.836 -> Arduino Course by DOT Lebanon  
15:40:59.869 -> Arduino Course by DOT Lebanon  
15:41:00.839 -> Arduino Course by DOT Lebanon  
15:41:01.839 -> Arduino Course by DOT Lebanon  
15:41:02.842 -> Arduino Course by DOT Lebanon  
15:41:03.846 -> Arduino Course by DOT Lebanon
```



Mohamad is presenting

meet.google.com is sharing



Stop s

```
3 Serial.begin(9600);
4 }
5
6 void loop() {
7   // put your main code here, to run repeatedly:
8   for(int i=0;i<11;i++){
9     Serial.print("The value of i is:");
10    Serial.println(i);
11    delay(1000);
12  }
13  Serial.println("-----");
14 }
15
```

Output Serial Monitor X

Message (Error or warning) message to the Arduino IDE or COM1

The value of i is:0

The value of i is:1

The value of i is:2

The value of i is:3

The value of i is:4



Mohamad is presenting



sketch_jul21a | Arduino IDE 2.3.10

File Edit Sketch Tools Help

Arduino UNO

sketch_jul21a.ino

```
1 void setup() {  
2   // put your setup code here, to run once:  
3   Serial.begin(9600);  
4 }  
5  
6 void loop() {  
7   // put your main code here, to run repeatedly:  
8   Serial.println("Arduino Course by DOT Lebanon");  
9   delay(1000);  
}
```

Output Serial Monitor X

Message (Enter to send message to 'Arduino UNO' on 'COM6')

```
15:42:56.864 -> Arduino Course by DOT Lebanon  
15:42:57.882 -> Arduino Course by DOT Lebanon  
15:42:58.882 -> Arduino Course by DOT Lebanon  
15:42:59.886 -> Arduino Course by DOT Lebanon  
15:43:00.887 -> Arduino Course by DOT Lebanon  
15:43:01.890 -> Arduino Course by DOT Lebanon  
15:43:02.891 -> Arduino Course by DOT Lebanon  
15:43:03.895 -> Arduino Course by DOT Lebanon  
15:43:04.895 -> Arduino Course by DOT Lebanon  
15:43:05.869 -> Arduino Course by DOT Lebanon  
15:43:06.867 -> Arduino Course by DOT Lebanon  
15:43:07.871 -> Arduino Course by DOT Lebanon  
15:43:08.876 -> Arduino Course by DOT Lebanon  
15:43:09.876 -> Arduino Course by DOT Lebanon  
15:43:10.876 -> Arduino Course by DOT Lebanon  
15:43:11.881 -> Arduino Course by DOT Lebanon  
15:43:12.879 -> Arduino Course by DOT Lebanon  
15:43:13.880 -> Arduino Course by DOT Lebanon  
15:43:14.882 -> Arduino Course by DOT Lebanon  
15:43:15.886 -> Arduino Course by DOT Lebanon  
15:43:16.887 -> Arduino Course by DOT Lebanon
```

```
1 int i;
2 const int j=7;
3     I
4 void setup() {
5     // put your setup code here, to run once:
6     Serial.begin(9600);
7 }
8
9 void loop() {
10    // put your main code here, to run repeatedly:
11    for(i=0;i<=10;i++){
12        int k=j*i;
13        Serial.print(j);
14        Serial.print("x");
15        Serial.print(i);
16        Serial.print("=");
17        Serial.println(k);
18        delay(100);
19    }
20    exit(0);
21 }
```

Activate Windows

Go to Settings to activate Windows.


Sketch uses 2042 bytes (6%) of program storage space. Maximum is 32768 bytes.

6- Serial Monitor - Powerpoint (Product Activation failed)

File Home Insert Design Transitions Animations Slide Show Review View Developer Acrobat Tell me what you want to do... Sign in Share

Cut Copy Paste Format Painter New Slide Layout Reset Section Clipboard Slides Font Paragraph Drawing Editing Adobe Acrobat

Board connection




dot: fritzing AL

meet.google.com is sharing your screen. Stop sharing Hide

Notes Comments

Slide 22 of 32 Arabic (Lebanon) ENG 4 PM 7/20/2026



```
Arduino UNO
sketch_jul21e.ino

6 // put your setup code here, to run once:
7 pinMode(led,OUTPUT);
8 pinMode(button,INPUT);
9 Serial.begin(9600);
10 }
11
12 void loop() {
13 // put your main code here, to run repeatedly:
14 ButtonState=digitalRead(button);
15
16 if(ButtonState==HIGH){
17     digitalWrite(led,HIGH);
18     Serial.println("The button is PRESSED");
19     delay(500);
20 }
21 else{
22     digitalWrite(led,LOW);
23     Serial.println("The buttons is NOT PRESSED");
24     delay(500);
25 }
```

Activate Windows

Go to Settings to activate Windows.

Output Serial Monitor X

meetandale.com is sharing your screen.

Stop sharing

Hide

```
1 int button=7;
2 int ButtonState;
3
4 void setup() {
5   // put your setup code here, to run once:
6   pinMode(button,INPUT);
7   Serial.begin(9600);
8 }
9
10 void loop() {
11   // put your main code here, to run repeatedly:
12   ButtonState=digitalRead(button);
13   Serial.print("The button is :");
14   Serial.println((ButtonState==HIGH)?"PRESSED":"NOT PRESSED");
15   delay(500);
16 }
17
```