1. Eksekusi Perintah . 1+2+3+4+5+6

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	300
AC	
IR	1940

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	301
AC	00000001
IR	1940

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	301
AC	00000001
IR	5-941

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

Data	
940	00000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

CPU Register	
PC	302
AC	00000011
IR	5-941

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	302
AC	00000011
IR	5-942

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

202
303
00000110
5-942

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	303
AC	00000110
IR	5-943

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

CPU Register	
PC	304
AC	00001010
IR	5-943

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	304
AC	00001010
IR	5-944

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	305
AC	00001111
IR	5-944

Data	
940	0000001
941	0000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	305
AC	00001111
IR	5-945

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

CPU Register	
PC	306
AC	00010101
IR	5-945

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	306
AC	00010101
IR	5-946

Data	
00000001	
0000010	
00000011	
00000100	
00000101	
00000110	
00000111	

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

CPU Register	
PC	307
AC	00011100
IR	5-946

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

CPU Register	
PC	307
AC	00011100
IR	2-946

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00000111

Memory	
300	1-940
301	5-941
302	5-942
303	5-943
304	5-944
305	5-945
306	5-946
307	2-946

Data	
940	0000001
941	00000010
942	00000011
943	00000100
944	00000101
945	00000110
946	00011100

CPU Register	
PC	307
AC	00011100
IR	2-946

Dilakukan penyimpanan data dari AC ke Memory pada lokasi 946