World Wide
SHADES

# Somfy Situo RTS II

## Programming Guide

Situo 1 RTS II & Situo 5 RTS II | Ref. 5150179B

World Wide Shades | worldwideshades.com | (844) 674-2716 | hello@worldwideshades.com
26 Broadway, Suite 934, New York, NY 10004

Complete guide for programming, pairing, and operating your Somfy Situo RTS II remote controls. Designed for use with all RTS-compatible motorized window coverings.

| | |
|---|---|
| Compatible With | All Somfy RTS motors and receivers |
| Battery | CR2032 3V (included) |
| Warranty | 5 Years (Somfy) |
| Radio | RTS (Radio Technology Somfy) - Omni-directional |

# Table of Contents

1. Remote Control Overview
Identifying your Situo RTS II

2. Button Layout and Functions
Buttons, indicators, and controls

3. Getting Started
First-time setup and pairing

4. Programming Your Motor
Step-by-step limit setting

5. Setting a Favorite Position
The my button feature

6. Adding or Removing a Remote
Multi-remote management

7. User Mode Operations
Adjusting limits after initial setup

8. Troubleshooting
Common issues and solutions

9. Battery Replacement
Maintaining your remote

10. Safety Information
Important warnings

# 1. Remote Control Overview

The Somfy Situo RTS II is a sleek, handheld remote control designed to operate Somfy RTS-compatible motorized window coverings including roller shades, solar shades, blinds, and draperies. It comes in two variants:

## Situo 1 RTS II

Single-channel remote control. Controls one individual motorized window covering or one group of coverings.

Ideal for single rooms or individual shade control.

## Situo 5 RTS II

Five-channel remote control. Controls up to five individual motorized window coverings or five groups of coverings.

Ideal for multiple rooms or coordinated shade control.

Situo 1 RTS II
(Front)

Situo RTS II
(Back - showing
PROG button)

Situo 5 RTS II
(5-Channel)

# 2. Button Layout and Functions

| Button / Feature | Location | Function |
|---|---|---|
| UP Button | Top of remote | Raises / Opens / Turns On the shade. Long press for tilt or intensity increase. |
| my / STOP Button | Center of remote | Stops shade in motion. When stationary, sends shade to saved favorite position. |
| DOWN Button | Bottom of remote | Lowers / Closes / Turns Off the shade. Long press for tilt or intensity decrease. |
| PROG Button | Back of remote (recessed) | Used to pair/unpair the remote with a motor. Requires a paperclip or small tool to press. |
| Group Selector (Situo 5 only) | Side of remote | Selects which channel (1-5) to control. Press to cycle through channels; LED indicates selection. |
| LED Indicator(s) | Front of remote | Lights up when a button is pressed to confirm signal is being sent. On Situo 5, also shows selected channel. |
| Wall Mount Recess | Back of remote | Allows mounting the remote on a wall bracket for convenient access. |

## Channel Selection (Situo 5 RTS II Only)

Before performing any operation with the Situo 5 RTS II, you must first select the correct channel:

1. Short press the Group Selector button to see which channel is currently selected (LED illuminates).
2. Press repeatedly to cycle through channels 1 through 5.
3. Channels 1-4 each light a single LED. When all LEDs are lit, channel 5 (group) is selected.
4. Channel 5 can be used to control all paired shades simultaneously.

# 3. Getting Started: First-Time Pairing

IMPORTANT: Before you begin, ensure that power is connected only to the motor being programmed. If multiple motors are on the same circuit, disconnect power to all other motors. The motor will exit programming mode after 2 minutes of inactivity.

## Initial Motor Pairing

For a brand-new motor with no previously paired remote, refer to the motor's own installation instructions to put it into factory/discovery mode. Then proceed with the programming steps below.

If pairing to a motor that already has a remote programmed, see Section 6: Adding or Removing a Remote.

## What is a 'Jog'?

Throughout this guide, the term jog refers to a brief up-and-down movement of your motorized shade. This is the motor's way of confirming it received your command successfully. Watch for it after each programming step.

# 4. Programming Your Motor: Setting Limits

Follow these steps in order to set the upper and lower travel limits for your motorized shade. Complete all steps before moving on.

## 1 Step 1: Initiate Programming Mode

On the Situo 5, first select the desired channel. Then, on either remote, press and hold both the UP and DOWN buttons simultaneously until the shade jogs. The shade is now in programming mode.

> Note: The motor will exit programming mode after 2 minutes of inactivity. If this happens, repeat Step 1.

## 2 Step 2: Check Direction of Travel

Press the DOWN button. The shade should move downward (closing). If the shade moves in the wrong direction, you must reverse it now.

## 3 Step 3: Reverse Direction (If Needed)

If the shade moved in the wrong direction in Step 2, press and hold the my/STOP button until the shade jogs. This reverses the motor direction. Verify by pressing DOWN again - the shade should now move downward.

> Note: Direction can ONLY be changed during programming mode. Once programming is complete, you cannot reverse the direction without resetting the motor.

## 4 Step 4: Set the Upper Limit

Use the UP button to move the shade to the desired fully-open (upper) position. Press and release to fine-tune. Once the shade is at the correct upper position, press and hold both my/STOP and DOWN simultaneously until the shade begins to move downward, then release the buttons.

> Note: If the shade stops when you release the buttons, return it to the upper limit position and repeat.

## 5 Step 5: Set the Lower Limit

The shade is now moving downward. Press my/STOP to stop the shade when it reaches your desired lower limit. Use UP or DOWN to fine-tune the position. Then, press and hold both my/STOP and UP simultaneously until the shade begins to move, then release. The shade will return to the

upper limit.

## 6 Step 6: Confirm Limit Settings

Press and hold the my/STOP button until the shade jogs. This confirms and saves both the upper and lower limit positions to the motor's memory.

## 7 Step 7: Finalize and Exit Programming

Using a paperclip or small pointed tool, briefly press the PROG button on the back of the remote until the shade jogs. The shade is now in user mode and ready to use. Double-check the limit settings by pressing UP and DOWN to verify both positions.

# 5. Setting a Favorite Position (my)

The Somfy exclusive my feature lets you save a preferred intermediate position for your shade - for example, half-open for natural light while maintaining privacy.

## To Set a Favorite Position:

1. Move the shade to your desired position using the UP or DOWN buttons.
2. Press my/STOP to stop the shade at the exact position you want.
3. Press and hold the my/STOP button for approximately 5 seconds until the shade jogs.
4. The favorite position is now saved. Pressing my/STOP when the shade is stationary will automatically move it to this saved position.

## To Delete a Favorite Position:

Move the shade to the saved favorite position. Then press and hold the my/STOP button for approximately 5 seconds until the shade jogs. The favorite position is now deleted.

# 6. Adding or Removing a Remote

You can pair multiple remotes to the same motor, or remove a remote that is no longer needed. This process requires access to a remote that is already paired with the motor.

## To Add a New Remote:

1. On the remote that is already paired with the motor, select the appropriate channel (Situo 5 only).
2. Using a paperclip, press and hold the PROG button on the back of the already-paired remote for approximately 2 seconds until the shade jogs. The motor is now in listening mode.
3. On the new remote you want to add, select the desired channel (Situo 5 only).

4. Briefly press the PROG button on the back of the new remote. The shade will jog to confirm the new remote has been paired.

## To Remove a Remote:

Follow the exact same process above. The PROG button acts as a toggle: if the remote is already paired, briefly pressing PROG will unpair it. The shade will jog to confirm.

> Note: To replace the last remote that has been lost or broken, contact a professional Somfy installer. A special reset procedure is required.

# 7. User Mode Operations: Adjusting Limits

After initial programming is complete, you can adjust the upper and lower limits without going through the full programming process.

## To Change the Lower Limit:

1. Send the shade to its current lower limit by pressing DOWN.
2. Press and hold both UP and DOWN simultaneously until the shade jogs.
3. Use UP and DOWN to adjust to the new desired lower limit.
4. Press and hold my/STOP until the shade jogs. The new lower limit is saved.

## To Change the Upper Limit:

1. Send the shade to its current upper limit by pressing UP.
2. Press and hold both UP and DOWN simultaneously until the shade jogs.
3. Use UP and DOWN to adjust to the new desired upper limit.
4. Press and hold my/STOP until the shade jogs. The new upper limit is saved.

> Tip: If the shade is actively moving when you try to adjust limits, press my/STOP twice to stop it before beginning.

# 8. Troubleshooting

| Issue | Possible Cause | Solution |
|---|---|---|
| Shade does not respond to remote | Dead battery or remote not paired | Replace CR2032 battery. If still unresponsive, re-pair the remote (Section 6). |

| | | |
|---|---|---|
| LED does not light when pressing buttons | Battery is depleted | Replace the battery immediately (Section 9). |
| Shade moves in wrong direction | Motor direction not set correctly | A full motor reset and reprogramming is required. Contact your installer or see factory reset procedure. |
| Motor exits programming before you finish | 2-minute inactivity timeout | Start programming again from Step 1. Work through steps more quickly. |
| Remote does not pair with motor | Motor not in listening mode | Ensure the existing remote's PROG button was held until the shade jogs before pressing PROG on new remote. |
| Shade jogs but won't set limits | Button combination not held long enough | Press and hold the button combination until the shade starts to move. Do not release early. |

## Factory Reset Procedure

If you need to completely reset the motor and erase all programming:

1. Using a paperclip, press and hold the PROG button on the motor for approximately 12 seconds.
2. Wait for the shade to jog 3 separate times. This confirms all settings have been erased.
3. The motor is now reset to factory defaults. All paired remotes and limit settings will be erased. You must reprogram from scratch.

WARNING: Factory reset erases ALL settings including all paired remotes. Use only as a last resort.

# 9. Battery Replacement

The Situo RTS II uses a single CR2032 3V lithium battery. When the LED no longer lights up during button presses, it is time to replace the battery.

| Specification | Detail |
|---|---|
| Battery Type | CR2032, 3V Lithium Coin Cell |
| Quantity | 1 |
| Expected Life | Approximately 2 years with normal use |

## Replacement Steps:

1. Unscrew the rear cover of the remote control.
2. Gently push the used battery out of its housing using a plastic (non-metallic) tool.
3. Insert a new CR2032 battery with the positive (+) side facing up (visible). Ensure correct polarity.
4. Push the battery fully into its housing until it clicks.
5. Screw the rear cover back into place securely.
6. Test the remote by pressing a button and verifying the LED lights up.

WARNING: Risk of explosion if the battery is replaced by an incorrect type. Do not short-circuit the battery terminals. Dispose of used batteries responsibly via your local recycling facility.

# 10. Safety Information

BATTERY SAFETY - INGESTION HAZARD: This product contains a coin cell battery. If swallowed, a battery can cause severe internal chemical burns in as little as 2 hours, which can lead to death. Keep new and used batteries out of reach of children. If a battery is swallowed or inserted into any part of the body, seek immediate medical attention.

- Do not install or use this product outdoors.

- Do not expose the remote to moisture, extreme heat, or flammable materials.
- Do not knock or drop the product.
- This product must not be installed at a height greater than 2 meters (6.5 feet).
- Do not install near metal frames or on metal surfaces, as this can reduce radio range.
- Non-rechargeable batteries must not be recharged.
- If the battery compartment no longer closes securely, stop using the product and keep out of reach of children.
- If used with a motor, also consult the instructions provided with the motor.
- Do not permit children to operate this product.
- This Somfy product should be installed by a professional installer who must comply with all applicable local standards and legislation.

## Quick Reference Card

| Action | Button Combination |
|---|---|
| Enter Programming Mode | Press and hold UP + DOWN simultaneously |
| Reverse Motor Direction | Press and hold my/STOP (in programming mode only) |
| Set Upper Limit | Press and hold my/STOP + DOWN simultaneously |
| Set Lower Limit | Press and hold my/STOP + UP simultaneously |
| Confirm Limits | Press and hold my/STOP until shade jogs |
| Exit Programming | Briefly press PROG button (back of remote) |
| Save Favorite Position | Press and hold my/STOP for 5 seconds |
| Go to Favorite Position | Briefly press my/STOP (shade must be stationary) |
| Delete Favorite | At favorite position, hold my/STOP for 5 seconds |
| Put Motor in Listen Mode | Press and hold PROG on paired remote for 2 seconds |
| Pair / Unpair Remote | Briefly press PROG on new remote (motor in listen mode) |

World Wide
SHADES

# World Wide Shades

Where Innovation Meets Craftsmanship

worldwideshades.com | (844) 674-2716 | hello@worldwideshades.com

26 Broadway, Suite 934 | New York, NY 10004 | Mon-Fri 9AM - 6PM EST

Premium, handcrafted window treatments made in the USA. From design inspiration to final install, we are with you every step of the way.

## Sources

1. Somfy Situo 1 & 5 RTS II Official Manual (Ref. 5150179B), http://www.john.bm/Gallery/Riddells/RiddellsHomeInfo/Riddells-Somfy-CurtainRemoteControl.pdf
2. Somfy RTS Quick Programming Guide, https://hartmannforbes.com/sites/default/files/20077-AU-Somfy-programming-guide.pdf
3. Somfy Systems - Situo 5 RTS Pure II Product Page, https://www.somfysystems.com/en-us/products/1870575/situo-5-rts-pure-ii
4. Somfy Systems - RTS Motor Programming FAQ, https://www.somfysystems.com/en-us/support/faq?question=how-do-i-program-a-remote-control-to-operate-my-motorized-shades-blinds-and-draperies
5. Somfy Professional - RTS Programming Instructions, https://www.somfypro.com/support/faq?question=somfy-rts-motor-programming-instructions-how-to-set-limits

Somfy, RTS, and Radio Technology Somfy are registered trademarks of Somfy SAS. World Wide Shades is an authorized reseller of Somfy-powered products. This guide is provided for informational purposes.