Short Press
Long Press

IGNITRON CheatSheet

https://github.com/stangreg/Ignitron

BOOT

Hold UP + DOWN at boot: reset AMP blocklist

Bank Up
HOLD WITH DOWN

Bank Down
HOLD WITH UP

AMP MODE		KEYBOARD MODE	

KEYBOARD MODE

Send “6”
Send “F”

Send “5”
Send “E”

Send “1” Send “A”	Send “2” Send “B”	Send “3” Send “C”	Send “4” Send “D”

This mode will turn the Ignitron into a Bluetooth LE keyboard. All buttons will act like keyboard presses

AMP MODE

Bank Up

Bank Down
Unload/Delete

Sel/Store P1	Sel/Store P2 REBOOT	Sel/Store P3	Sel/Store P4

In AMP mode, Ignitron acts like a Spark AMP and can communicate with the Spark app running on a mobile. New presets can be stored on Ignitron and existing presets can be deleted.

APP MODE - AMP BLOCKLIST

CONNECTED	UP + DOWN (2 sec): block amp
AT LOGO	UP + DOWN (2 sec): open / close
BROWSE	UP: previous / DOWN: next
UNBLOCK	P4: confirm / P4 again: delete
BOOT	HOLD UP + DOWN: reset / clear all

APP MODE Manual/FX Mode

Noise gate
PRESET MODE

Compressor

Drive	Modulation REBOOT	Delay	Reverb

In Manual/FX mode, you can toggle single effects

APP MODE Preset Mode

Bank Up
HOLD WITH DOWN

Bank Down
HOLD WITH UP

Preset1/Drive	Preset2/Drive REBOOT	Preset3/Drive	Preset4/Drive LOOPER MODE

APP Mode is the default Ignitron mode.
You can switch presets (1-4) and banks (1-n)

In Looper mode, Ignitron is connected to your mobile/PC as a bluetooth keyboard. If supported by the respective app on the mobile/PC, the buttons can be freely configured to any function offered by the respective App.

APP MODE Looper Mode

Send “6”
Next Preset

Send “5”
Prev. Preset

Send “1”	Send “2” REBOOT	Send “3”	Send “4” PRESET MODE

V1.1 Ivan Tarozzi 2024
CC BY SA