#### SERVICE HINTS

### H1, H2 HEADLIGHT BEAM LEVEL CONTROL ACTUATOR LH, RH

3-GROUND : Approx. 12 volts with light control SW at HEAD position or dimmer SW at FLASH position

1-GROUND : Always continuity

# : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
H1	97 (LHD)	H13	99 (LHD)	J9	99 (LHD)
'''	105 (RHD)	1113	107 (RHD)		107 (RHD)
H2	97 (LHD)	J1	105 (RHD)		
112	105 (RHD)	J5	107 (RHD)		

## ) : RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	'	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)	
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	
26	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)	
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)	

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code See Page Joining Wire Harness and Wire Harness (Connector Location)		Joining Wire Harness and Wire Harness (Connector Location)
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
1/1/2	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)

# : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
	122 (RHD)	
ID	114 (LHD)	Cowl Side Panel LH
	124 (RHD)	Cowi Side Fallei Ln
IF	124 (RHD)	Cowl Side Panel RH