① : **Engine Room No.1 R/B**	**Engine Compartment Left**
② : **Engine Room No.2 R/B**	**(See Page 76)**

[RHD]

*1 : 10A H-LP L LWR (*3)
  15A H-LP LH (*4)
*2 : 10A H-LP R LWR (*3)
  15A H-LP RH (*4)
*3 : Europe
*4 : Australia

Engine Room No.1 R/B

60A ABS
(for High Current)

120A ALT
(for High Current)

30A H-LP CLN
(for Medium Current)

30A RDI FAN
(for Medium Current)

30A CDS FAN
(for Medium Current)

Engine Room No.2 R/B

ABS SOL Relay

ABS MTR Relay

HORN Relay

EFI Relay

EFI
TURN-HAZ
RADIO NO.1
TEL
HORN
AM2
ETCS
ALT-S

CIRCUIT
OPENING Relay

ECU-B1

H-LP LVL

40A MAIN
(for Medium Current)

STARTER Relay

HEAD LP
Relay

IS 200 (FR SPORT) (EWD368F)