TAILLIGHT

SYSTEM OUTLINE

When the light control SW is turned to TAIL or HEAD position, the current flows to TERMINAL 3 of the light failure sensor through the TAIL fuse.

When the ignition SW is turned on, the current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear light warning light to TERMINAL 4 of the light failure sensor.

TAILLIGHT DISCONNECTION WARNING

With the ignition SW on and the light control SW turned to TAIL or HEAD position, if the taillight circuit is open, the light failure sensor detects the failure by the change in current flowing from TERMINAL 3 of the light failure sensor to TERMINAL 9 and the warning circuit of the light failure sensor is activated.

As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on, which remains on until the light control SW is turned off.

SERVICE HINTS

TAIL RELAY

5-3: Closed with the light control SW at **TAIL** or **HEAD** position

L3 LIGHT FAILURE SENSOR

4, 8-GROUND: Approx. 12 volts with ignition SW at ON or ST position

3, 9-GROUND: Approx. 12 volts with light control SW at TAIL or HEAD position

11-GROUND: Always continuity

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
C10	А	98 (LHD)	J5	99 (LHD)	L1	108 (RHD)
		106 (RHD)	33	107 (RHD)	L2	100 (LHD)
C11	В	98 (LHD)	J9	107 (RHD)		108 (RHD)
		106 (RHD)	J14	100 (LHD)	L3	100 (LHD)
	А	98 (LHD)	314	108 (RHD)		108 (RHD)
C14		106 (RHD)	J15	100 (LHD)	R10	101 (LHD)
	В	106 (RHD)	G (RHD) 108 (RHD)		1 810	109 (RHD)
D1		98 (LHD)	J16	100 (LHD)	R11	101 (LHD)
F1		96 (LHD)	310	108 (RHD)	KII	109 (RHD)
		104 (RHD)	J17	100 (LHD)	T4	107 (RHD)
F2		96 (LHD)	317	108 (RHD)		
		104 (RHD)	L1	100 (LHD)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
1 '	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1C		
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
10	02 (2115)	Engine recomment who and sitted class of Learnier and
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)	
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)	
BD1	118 (LHD)		
	128 (RHD)	Floor No.2 Wire and Luggage Room Wire (Right Side of the Luggage Door)	
BD2	118 (LHD)		
	128 (RHD)		

: GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
	122 (RHD)	Lettrender Apron
ID	114 (LHD)	Cowl Side Panel LH
"	124 (RHD)	
IF	124 (RHD)	Cowl Side Panel RH
IG	114 (LHD)	
ВК	118 (LHD)	Left Quarter Panel LH
	128 (RHD)	Lott Quartor Failor Err