SERVICE HINTS

FR FOG RELAY

5–3 : Closed with the light control SW at **TAIL** or **HEAD** position and the fog light SW at **ON** position

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
C10	Α	98 (LHD)	D1	98 (LHD)	J5	99 (LHD)
C11	В	98 (LHD)	F3	96 (LHD)	J9	99 (LHD)
C14		98 (LHD)	F4	96 (LHD)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)	
2F		Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	
2G	84 (LHD)		
2H	04 (LITD)		
21			

: GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH