COMBINATION METER

SERVICE HINTS

P2 PARKING BRAKE SW

1-GROUND: Closed with parking brake lever depressed

F15 FUEL SENDER

2–3 : Approx. **2.0** Ω at fuel full Approx. **48.7** Ω at fuel empty

C10 (A), C11 (B) COMBINATION METER

(A)17-GROUND : Approx. 12 volts with ignition SW at ON or ST position

(A)18–GROUND : Always continuity (A)19–GROUND : Always continuity (A)15–GROUND : Always approx. **12** volts (A)16–GROUND : Always approx. **12** volts

: PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
A14	А	98 (LHD)	D4		106 (RHD)	J7	99 (LHD)
		106 (RHD)	E2	Α	96 (LHD)] 37	107 (RHD)
A15	В	98 (LHD)] [2	^	104 (RHD)	J8	99 (LHD)
		106 (RHD)	- E3	В	96 (LHD)		107 (RHD)
В	1	96 (LHD)			104 (RHD)	J9	99 (LHD)
	1	104 (RHD)			100 (LHD)		107 (RHD)
В6	А	98 (LHD)	F15		108 (RHD)	J10	107 (RHD)
Во		106 (RHD)	F16		100 (LHD)	J11	99 (LHD)
В7	В	98 (LHD)			108 (RHD)		107 (RHD)
"		106 (RHD)	J2	А	97 (LHD)	P2	99 (LHD)
C10	А	98 (LHD)			105 (RHD)		107 (RHD)
		106 (RHD)	- J3	В	97 (LHD)	R9	99 (LHD)
C11	В	98 (LHD)			105 (RHD)		107 (RHD)
		106 (RHD)	J5		99 (LHD)	S1	97 (LHD)
D1		98 (LHD)]		107 (RHD)	31	105 (RHD)
D2		106 (RHD)	J6		99 (LHD)	T5	107 (RHD)
D4		98 (LHD)			107 (RHD)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)	
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)	
'	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)	
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)	
2	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
_ '`	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
11	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2A	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
20	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
211	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA2	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
	122 (RHD)	Linging wille and Engine Room Main wille (Inside of the EGO Box)
IA2	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)
	128 (RHD)	

: GROUND POINTS

Code	See Page	Ground Points Location	
EC	122 (RHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
"	124 (RHD)		
IH	114 (LHD)	Front Floor Panel Center LH	
"	124 (RHD)	Front Floor Panel Center RH	
BJ	128 (RHD)	Front Floor Panel LH	
BL	118 (LHD)	Front Floor Panel RH	