SERVICE HINTS

DEICER RELAY

3--5 : Closed with ignition SW at ON position and defogger SW [A/C control assembly] on

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
A14	А	98 (LHD)	- C10		98 (LHD)	E3	В	104 (RHD)
		106 (RHD)			106 (RHD)	F9		96 (LHD)
A15	В	98 (LHD)	D2		106 (RHD)			104 (RHD)
		106 (RHD)	- E2	А	96 (LHD)	Т	5	107 (RHD)
В6	Α	98 (LHD)			104 (RHD)			
		106 (RHD)	E3	В	96 (LHD)			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)	
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	
1K	02 (LI ID)	Lengine Noom Main whe and Driver Side 3/D (Lent Nick Failer)	

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	

: GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IF	124 (RHD)	Cowl Side Panel RH