MANUAL TRANSMISSION

SST (Special Service Tools)

PP23N-01

09309-35010	Transmission Rear Bearing Replacer	Output shaft bearing No. 1 Clutch hub 6th gear
09309-36010	Transmission Rear Bearing Replacer	Counter gear
09309–37010	Transmission Bearing Replacer	Clutch hub No. 3
09308-00010	Oil Seal Puller	Extension housing oil seal
(09316-00011)	Replacer Pipe	Clutch hub No. 2
(09316-00021)	Replacer "A"	Output shaft bearing rr.
09325-20010	Transmission Oil Plug	Extension housing rear oil seal
09330-50010	Propeller Shaft Center Bearing Replacer	Counter gear front bearing
09350-20015	TOYOTA Automatic Transmission Tool Set	
(09350-06120)	No.2 Measure Terminal	6th gear thrust clearance
09527–20011	Rear Axle Shaft Bearing Remover	Input shaft bearing
09631-12090	Seal Ring Tool	Clutch hub No. 1

	09632-36010	Steering Vane Pump Bearing Replacer	Clutch hub No. 4
	09817–16011	Back-up Light Switch Tool	Back-up light switch
	09950-00020	Bearing Remover	Clutch hub No. 4
	09950-30011	Puller A Set	
	(09951-03010)	Upper Plate	Clutch hub No. 4
	(09953-03010)	Center Bolt	Clutch hub No. 4
	09950-40011	Puller B Set	Clutch hub No. 4
8	(09957-04010)	Attachment	Clutch hub No. 4
Sessesses (09950-60010	Replacer Set	
9	(09951-00230)	Replacer 23	Counter gear front bearing Counter gear
	(09951-00420)	Replacer 42	Front bearing retainer oil seal
6	(09951-00560)	Replacer 56	Input shaft bearing
0000	09950-60020	Replacer Set No.2	

PREPARATION - MANUAL TRANSMISSION

(a)	(09951-00750)	Replacer 75	Extension housing dust deflector
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	Extension housing dust deflector