DI257-06


Transmission Shift Switch Circuit

CIRCUIT DESCRIPTION

When shifting the shift lever in M range, using the transmission shift switch, it is possible to shift in 2-5 ranges.

Pressing "Up switch" once shifts up 1 range, "Down switch" once shifts down 1 range respectively.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check[the[E-shift[main[switch[See[page[DI-240]].

NG□

Replace the E-shift main witch (See page AT-24).

OK

2 | Check operation of transmission shift switch.

PREPARATION:

- (a) Turn the ignition switch ON.
- (b) Shift he shift ever into he Mange.

CHECK:

Check[]the[]do[]trip[]display[]panel[]when[]the[]transmission[]shift switch[]s[]pressed.

OK:

Switch[condition	Odo[<u>f</u> rip[display[panel
"Up"[switch[press	Shift[up
"Down"[switch[press	Shift <u></u> down


OK[]

 $\label{lem:check_and_replace_the_Engine_and_ECT_ECU (See_page_N-34).} \label{lem:check_and_replace} \end{center}$

NG

3□

Check[voltage[between[each[of[terminals[\$FTU,[\$FTD[and[E1[of[Engine[and[ECT ECU.



PREPARATION:

- (a) Turn ignition switch ON.
- (b) Remove the Engine and ECT ECU with connectors still connected.

CHECK:

 $\label{lem:check_voltage_between_each_leminals_of_SFTU_or_SFTD_and E1_of_Engine_and_ECT_ECU.} \\$

<u>OK:</u>

Switch@ondition	Tester[connection	Specified@ondition
"Up"[switch[held[pressing	SFTU -Œ1	7 -[]4[V
"Up"[switch[released		Below[] .5[]V
"Down"[switch[held pressing	SFTD -Œ1	7 -[]4[] V
"Down"[switch[released	_	Below[].5[]V




$$\label{lem:condition} \begin{split} & \textbf{Proceed_to_next_circuit_inspection_shown_in} \\ & \textbf{problem_symptoms_table_See_page_Dl-190}). \end{split}$$

NG

4∏

Check[transmission[shift[switch.



PREPARATION:

- (a) Remove the steering wheel pad.

CHECK:

Check[continuity[between[each[]erminal[of[]transmission[]shift]] switch connector.

OK:

Switch@ondition	Tester[connection	Specified[]value
"Up"[switch[pressed		No <u>[</u> continuity
"Up"[switch[released	3 –[5	Continuity
"Down"[switch[pressed	3 –[6	No[continuity
"Down"[switch[released		Continuity



Replace[the[steering[wheel[(See[page[\$R-7)]]

OK

Repair or replace harness or connector (See page N-34).