DI3CL-04

DTC P1566/54 Input Signal Circuit abnormal

CIRCUIT DESCRIPTION

DTC[No.	Detection[]tem	Trouble[A rea
P1566/[54	Stop[light[switch]]nput[signal@ircuit[abnormal.]	•Engine@and@ECT@ECU

INSPECTION PROCEDURE

 $\label{lem:check_and_replace} Check[and] \begin{tabular}{ll} Engine[and] ECT[ECU (See] \begin{tabular}{ll} page[] N-32 \end{tabular}). \end{tabular}$