#### SERVICE HINTS

#### FR FOG RELAY

5-3: Closed with the light control SW at **TAIL** or **HEAD** position and the fog light SW at **ON** position

### : PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
C10	Α	106 (RHD)	C14	В	106 (RHD)	J5	107 (RHD)
C11	В	106 (RHD)	F3		104 (RHD)	J9	107 (RHD)
C14	Α	106 (RHD)	F4		104 (RHD)	T4	107 (RHD)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)		
1F	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)		
1H	66 (KHD)			
2A	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)		
2F	90 (1(11D)	Institution ratio wife and rassenger side 3/5 (Lett Nok ratio)		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)		
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)		
2L	30 (IXI ID)	This truthett and write and trasseriger side 3/D (Left Non Faller)		

## : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
IH	124 (RHD)	Front Floor Panel Center RH