32 IS 300 / 200 (LHD) Power Source Radio and Player (9 Speaker) * 1 : w/ LEXUS Navigation System * 2 : w/o LEXUS Navigation System 2 R14 Rear Speaker LH R15 Rear Speaker RH S26 Squawker RH 10A RADIO NO. 2 I15 Ignition SW Navigation ECU . <29-2> J15 Junction J₁₃ Junction L-Y 40A AM1 3 IB3 9 IB3 10 IH3 11 IH3 (°±1) HB S 9(A), S10(B) Stereo Component Amplifier 16(A) 14(A) BU+B NAVI-MUTE GND(S) GND(E) TX+ TX-GND(E) 8(B) 9(B) 17(B) 18(B) 14**B** 1 (B) 10 (B) 6(A) 15(A) 4(A) 2**A** 8(A) 20A RADIO NO. 1 120A ALT 1 IH3 7 IH3 8 IH3 IH3 (*2) P Navigation ECU 1 IC2 1 11 MUTE L+ R+ L-S-GND TX+ TX-WF+ WF-GND AMP+ ANT+B AMP+ MTR R 6 Radio and Player F14 Front Door Tw Speaker RH Battery 13 IH1 3 IH3 A29 Antenna Amplifier L-Y F12 Front Door F11 Front Door Speaker LH Front Floor Panel Front Floor N

OVERALL

ELE

CTRICAL WIRING

DIAGRAM