LIGHT REMINDER (LHD)

SYSTEM OUTLINE

This system is provided to remind the driver to turn off the taillights and headlights.

LIGHT REMINDER OPERATION

In case the driver's side door is opened while the light control SW is at TAIL or HEAD with the ignition SW turned to off from on, through the communication control of the body ECU etc., the light reminder buzzer in the combination meter comes on.

SERVICE HINTS

C14 COMBINATION SW

14-GROUND: Continuity with light control SW at TAIL or HEAD position

D7 DOOR COURTESY SW FRONT LH

1-GROUND: Closed with door open

B7 (B) BODY ECU

6-GROUND: Continuity with driver door open

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
A14	Α	98 (LHD)	C′	14	98 (LHD)	E3	В	96 (LHD)
A15	В	98 (LHD)	D1		98 (LHD)	J5		99 (LHD)
В6	Α	98 (LHD)	D4		98 (LHD)	J8		99 (LHD)
B7	В	98 (LHD)	D7		100 (LHD)	J	9	99 (LHD)
C10		98 (LHD)	E2	Α	96 (LHD)			

: RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
Γ	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A		
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F	1	
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1L	02 (L11D)	Institution ratio wife and briver side 3/b (Lett Nick Faller)
10	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E		
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H]	
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
BL	118 (LHD)	Front Floor Panel RH