## **REASSEMBLY**

ST053-01

Reassembly[is[in[the[reverse[order[of[disassembly[See[page[ST-4)]]

HINT:

Use high-temperature grease to lubricate the bearings and gears when assembling the starter.