26 IS 300 / 200 (LHD) Power Source Power Seat Seat Heater 2 * 1 : w/ Power Seat * 2 : w/o Power Seat L-R I15 Ignition SW W SEAT HTR 1 BF1 BE1 Power Seat Control SW Power Seat Control SW (Driver' s Seat) (Front Passenger' s Seat) → Rear → Rear 12 IH3 P23 IB3 Power Seat Motor Power Seat Motor 2 (1D S 6 Seat Heater SW (Driver' s Seat) (Driver' s Seat (Front Passenger' s IG IG Seat Reclining Control) Reclining Control) Front → Front → Down 10(2G) -[(M)]-P17 Power Seat Motor P22 Power Seat Motor (Front Passenger' s Seat (Driver' s Seat Rear Vertical Control) Rear Vertical Control) Y-G 10 IB3 4 IH3 **⊸** Up **⊸** Up Down → Down W-G -**(**(M**)**)-(*1) (*1) Power Seat Motor Power Seat Motor (Front Passenger' s Seat (Driver' s Seat Front Vertical Control) W-R Front Vertical Control) BE1 BF1 Up Rear Rear R-G R-L P24 Power Seat Motor (Front Passenger' s Seat P19 Power Seat Motor (Driver' s Seat Slide Control) Slide Control) → Frnot → Frnot (*1) (*1) W-B (*2) ₹ 2 BF1 Ŧ Battery W−B **≫**BE1 W-B W-R IG Cowl Side Panel RH Front Floor BL Panel LH Floor Panel RH

OVERALL

Ш

EC

TRICAL

WIRING

DIAGRAM