

# XYZ RNC

## Configuration and Commissioning Guide

Synthetic demonstration document - not real Nokia documentation.

## Modifying XYZ parameters

This section describes how to interrogate and modify XYZ parameter values on the RNC. Parameter changes take effect after the next configuration commit.

## Configuring Signaling Connections

Signaling connections are configured per adjacent network element. The connection state is reported by the XYZ Service Indicator.

## Activating XYZ Service Indicator

Activate the service indicator before commissioning. The indicator reports availability to the network management layer.

## Overview

See [Modifying XYZ parameters](#) to find information on how to interrogate and modify XYZ parameter values.

For more information, see [Configuring Signaling Connections in XYZ RNC Network](#).

For instructions, refer to [Activating XYZ Service Indicator](#) in the XYZ documentation.

Figure: WCDMA RAN upgrade path shows the top-down approach of the upgrade path for the radio network.

The software versions supporting the different releases of the XYZ elements are depicted in [Table: XYZ Compatibility](#).

See/Refer to XYZ technical support note.

## Commissioning

See [to find information on how to interrogate and modify XYZ parameter values.](#)

For more information, see [in XYZ RNC Network.](#)

Once commissioning is complete, verify the configuration against the compatibility table before handover.