

Software Update Guide

Keeping the accessory's software current isn't just about new features. It fixes weird bugs, improves stability, and keeps everything working smoothly. Here's how to handle updates without overthinking it.

1. Check for updates regularly

Most accessories rely on a companion app or a system settings page. Open it once in a while and look for an update prompt. If nothing shows up, tap into the settings section and check manually. Updates don't always announce themselves.

2. Make sure the battery isn't low

Run updates only if the accessory has enough charge. If the battery dips too low halfway through the process, you risk corrupting the firmware. Plug it into power if you're unsure.

3. Use a stable connection

If the update downloads over Bluetooth, Wi-Fi, or mobile data, give it a clean environment. Stay close to your phone or router so the signal doesn't cut out. For wired updates, avoid touching the cable during the process; you don't want a loose connection interrupting the transfer.

4. Let the update finish fully

Once you start the update, leave the device alone. Don't power it off, don't press buttons, and don't disconnect it. The accessory might restart or flash indicators—just let it do its thing.

5. After the update, reboot if needed

Some accessories apply changes only after a restart. If everything feels laggy or unresponsive right after the update, a quick power cycle usually settles things.

6. Reconnect or re-pair if the link breaks

Sometimes the accessory unpairs during an update. If it doesn't reconnect automatically, do it manually. Forget the device from your phone or system and pair it again. This clears old connection data that might conflict with the new firmware.

7. Check for improvements or changes

Once everything's back on, test the main functions to make sure nothing feels off. If you notice issues, check the app or support page. Sometimes there's a small patch update released right after a major one.

8. If the update fails

Don't panic. Restart the accessory and try again. If it fails repeatedly, switch cables, move closer to your router, or reinstall the companion app. When none of that works, the accessory may need a forced recovery update or service attention.