

131402010165A005 Return spring pin.....	17-15	13231554 Chassis Harness Guide Support Assembly.....	2-71
131402010165A006 Brake shoe	17-15	13246981 Plate Spring Side Washer.....	17-3
131402010165A007 Roller	17-15	13252585 Support of Rear Towing Hook	9-7
131402010165A Front first axle assembly.....	17-5	13252586 Towing Hook Pin.....	7-3
131402010238A003 Push row-steep roller bearing.....	17-17	13257054 GCC Tag.....	4-3
131402010238A004 Steering knuckle arm	17-19	13257613 Logo and Name Plate Assembly	1-3
131402010238A005 Pin	17-15	13261688 Pipe String Beam Backing Plate	9-5
131402020002B008 Wheel Nut.....	11-9, 12-13, 17-15	13265068 Front Panel Right Reinforced Plate Assembly.....	2-119
13141680 Fixed Bracket for Warm Air Pipe	6-3	13275025 Front Wheel Dashboard Left Central Support Assembly	20-3
131500000014A Bolt.....	13-5	13389242 Battery Layering	15-7
131500000015A no name.....	13-5	13399617 Fixed Bracket Assembly of Distribution Box	2-71
131500000043A Lock Pin.....	13-5	13425240 Front Panel Mode Assembly	2-81
131500000058A Balance Bearing Cap	13-5	13425267 Manual Lever of Left Rearview Mirror	2-85
131500000059A balance shaft bushing	13-5	13425270 Right Rear View Mirror Assembly.....	2-81
131500000060A balance bearing drum.....	13-5	13425272 Manual Lever of Right Rearview Mirror	2-87
131500000061A no name.....	13-5	13426602 Hand Adjusted External Rearview Mirror Assembly.....	2-73
131500000062A SCREW	13-5	13489284 Pin Shaft.....	14-19
131500000063A Coupling Plate	13-5	13489285 Pin Shaft.....	14-19
131500000064A Balance Shaft.....	13-5	13490435 Square Cross Beam.....	24-11
131500000065A Balance Shaft Bracket.....	13-5	13507321 Transition Plate	14-21
131500000071A Thrust Plate	13-5	13507322 Air Storage Cylinder Bracket Assembly.....	14-17
131500000072A Bolt, Hexagon.....	11-3, 11-9, 11-13, 12-3, 12-13, 12-17	13528465 Steel Tube Nut Assembly	14-11, 26-17
131699000028B012 Bushing	17-7, 17-11	13528469 Nylon Tube Nut Assembly	14-7
131699000038A010 leaf spring gasket.....	13-7	13538898 Air Storage Cylinder.....	14-17
131699000084A001 The 1th Rear Front Plate.....	17-7, 17-11	13546545 Non-bearing General Support.....	6-3, 14-11, 24-3, 26-17, 30-3
131699000084A002 The 2th Rear Front Plate.....	17-7, 17-11	13547181 Fixed Board of Relay Valve.....	14-7, 14-23
131699000084A003 The 3th Rear Front Plate.....	17-7, 17-11	13547196 Internal Air Storage Cylinder Installing.....	14-13
131699000084A004 The 4th Rear Front Plate.....	17-7, 17-11	13551827 Balance Suspension Pad	9-7
131699000084A005 The 5th Rear Front Plate.....	17-7, 17-11	13586486 Arched beam.....	9-11
131699000084A006 The 6th Rear Front Plate.....	17-7, 17-11	13603062 Chassis Power Distribution Case Support Assembly.....	15-13
131699000084A007 The 7th Rear Front Plate.....	17-7, 17-11	13605465 Power Device.....	15-7
131699000084A008 The 8th Rear Front Plate.....	17-7, 17-11	13609955 Upper Thrusting Rod Bracket	13-3
131699000084A009 The 9th Rear Front Plate.....	17-7, 17-11	13611206 Seal Assembly.....	2-13
131699000084A010 front spring gasket.....	17-7, 17-11	13630375 Junction Box Plate Assembly.....	2-71
131699000084A011 Rear Plate Spring Center Bolt.....	17-7, 17-11	13631416 Right Front Superstructure Handrail	2-119
131699000084A Front Armor Plate Spring Assembly.....	17-5, 17-9	13637885 Arched beam assembly.....	9-7
131699000086A001 The 1th rear leaf plate.....	13-7	13694345 Left Connecting Plate.....	25-3
131699000086A002 The 2th rear leaf plate.....	13-7	13694346 Right Connecting Plate	25-3
131699000086A003 The 3th rear leaf plate.....	13-7	13694348 Draw Hook Seat Bottom Board	32-7
131699000086A004 The 4th rear leaf plate.....	13-7	13694349 Draw Bar Hook Seat Rigid Board	32-7
131699000086A005 The 5th rear leaf plate.....	13-7	13694350 Draw Bar Hook Seat Rigid Board	32-7
131699000086A006 The 6th rear leaf plate.....	13-7	13694351 Draw Hook Seat Rigid Board	32-7
131699000086A007 Rear Plate Spring Center Bolt.....	13-7	13694352 Towing Hook Board.....	32-7
131699000086A Rear Leaf Spring Assembly	13-3	13694353 Draw Bar Hook Seat	32-5
131699000091A Shock Absorber Assembly.....	17-21, 17-23	13708874 Outer Plate of Battery Frame	15-11
13175795 Oil Cylinder Pin Shaft.....	19-3	13708875 Locker Support.....	15-11
		13708877 Battery Frame	15-9
		13708878 Inner Plate Assembly of Battery Frame	15-11

13709121 Air Reservoir Assembly	14-15	141502000017 Fresh Air Filter Screen	2-61
13710232 Backup Plate of Battery Frame	15-9	141502000076 Desiccant	2-61
13724531 Pull Ring Assembly	15-9	141502000077 Fresh Air Filter	2-61
13732758 Electrical Installed Middle Bracket.....	2-131	141502000338A A Pipeline of Expansion Valve	
13741435 Assembly of Battery Frame	15-7	Import and Export.....	5-3
13748442 Cab Electrical Assembly.....	15-3	141601990069A Left Direction-indicator Lamp ...	2-69
13753961 Reinforcement Plate A of the Arched		141601990070A Right Direction-indicator	
Beam	9-11, 9-13, 9-17	Lamp.....	2-69
13753962 Reinforcement Plate B of the Arched B		141604000060A Light	2-63
eam.....	9-11, 9-13, 9-17	141998000097B Combination Instrument	
13777564 Muffler Bracket	16-13	Assembly.....	3-3
13797225 Fixed Device of Air Reservoir.....	14-15	14213251 Harness	2-71
13810154 Reinforced plate of the Tow-hook	9-9	14213252 Harness	2-71
13816361 Relay Valve Assembly.....	14-23	14223738 Transmission System.....	27-3
13840970 Draw Bar Hook Seat Rigid Board	32-7	14233847 Relay Valve Assembly.....	14-5
13850875 Front Panel Right Reinforced Plate		14244903 Selector Rocker.....	27-3
Assembly	2-79	14257134 Bracket	27-7
13898814 Guide Plate Assembly.....	2-77	14257135 Mounting Leg	27-7
13898818 Door Lower Decorating Plate		14257136 Dust Cover Bracket Assembly	27-3
Assembly.....	2-75	14259075 Left Front Wheel Rear Dashboard with	
13898833 Front Pannel Mode Assembly.....	2-117	Anti-splash Assembly	20-3
13898842 Front Panel Assembly.....	2-77	14259076 Right Front Wheel Rear Dashboard with	
13937559 Support.....	14-29	Anti-splash Assembly	20-3
13984311 Link Body Electromagnetic Valve		14268699 Arched beam.....	9-17
Bracket.....	15-15	142999000045A Central distribution case	2-71
13987177 Air Filter Strap	21-3	142999000182A Junction Box.....	2-71
139999000176A Inlet Rubber Pad	2-93	14337842 Interim Plate	27-3
139999000177A Inlet	2-93	14340445 Front Combined Lamp	2-63
139999000237A Shim	13-5	14359834 Exhaust Pipe.....	16-5
139999000238A Safety Valve	13-5	14359835 Exhaust Pipe.....	16-5
139999000257A Hexagon Flange Nut	13-5	14359848 Exhaust Pipe Fixing Bracket.....	16-5
14008121 Inter-axle Differential Warning Board....	4-3	14359851 Bracket for exhaust pipe.....	16-5
14014995 Guard Top Board	2-23	14362526 Gland	16-3
14015124 Glasses Assembly.....	2-75	14373051 Three-grade Right Pedal Assembly.....	2-3
14015141 Lower Side Decorating Plate		14383597 Dashboard	24-11
Assembly.....	2-75	14389650 Muffler	16-13
14019459 Panel Assembly.....	2-13	14469941 Lower reinforced board (1)	9-15
14027239 Stop Block	32-7	14493698 Rubber Hose of Inlet Oil Pump.....	26-17
14034369 Thrusting Rod Bearer Backup Plate ...	13-3	14498803 Rear Axle Drive Shaft Assembly	31-3
14035338 The Hanger Assembly.....	31-3	14498805 Middle transmission shaft assembly ...	31-3
14036335 Exhaust Clamp.....	16-5	14506701 Air Exhaust Pipe Hoop	16-5
140502000048A pressure sensor	15-3	14513469 Left Door Backplate Switch Assembly	
140502000208A Pressure Sensor	15-15		2-49
140502000236B Pressure Sensor.....	15-3	14513483 Right Door Backplate Switch Assembly	
140504000155A Fuel Sensor.....	30-9		2-49
14052824 Blanking Cover Assembly.....	2-47	14513554 Door Backplate Switch Assembly	2-47
14089965 Cover Lock Mounting Support		14513560 Switch Assembly	2-45
Plate	2-151	14529057 Pipeline Bracket	5-3
140999020011A Mobile Terminal.....	3-3	14538626 Water Tank Guardrail Bottom	
14106148 Ball Joint Assembly.....	26-11, 26-13, 26-15	Board	24-11
14146066 Spring Suspension Assembly	2-131	14545345 Spare tire assembly	10-3
141501000147A008 Condenser.....	5-3	146399000018A Voice Alarm	3-3
141501000151A001 The support of condenser	5-3	151208000111A Quick Coupler Adapter.....	27-3
141501000151A004 Pipeline-condenser to		151304060006A Elastic Clip	24-3
evaporator	5-3	151304060026A Steel Band Elastic Clamp	24-3
141501000152A001 Compressor.....	5-3	151304990047A Worm Rod Thimble Helical	
141501000230A001 The Pipe of Evaporator to		Spring	24-3
Compressor.....	5-3	151304990048A Worm rod thimble of helical Spring	
141501000230A002 Compressor to Condenser			24-3
Line.....	5-3	152505000095A Hose Assembly, High	
141501000230A Air Conditioning Assembly	1-3	Temperature	14-11

152599000060A	Automatic	Discharging	Valve	14-15, 14-17	168899000846A	Exhaust Nozzle	22-11
160102040013A327	Clamping band			22-39	168899000850A	Accumulator Relay	22-11
160102160020A486	Spacing sleeve			22-39	168899000851A	Bypass Oil Filter Element	22-11
160299000044A	Expansion	Water	Tank		168899000852A	Bypass Oil Filter Element	22-11
Assembly				24-13	168899000853A	Safety Relay	22-11
160602010088A	Air Filter			21-3	168899000863A	Oil Cooling Valve	22-5
160602010092A001	Master Filter and safety filter			21-7	168899000864A	Main Bearing Cover	22-5
Component				21-7	Assembly		22-5
160602010092A002	Rear cover sub-assembly			21-7	168899000865A	Oil Std Ring	22-5
160602020042A	Air Filter Primary Filter			21-9	168899000869A	Flywheel Housing Support	22-9
Element				21-9	168899000870A	Flywheel Housing Support	22-9
160602030029A	Air Filter Safety Filter Element			21-9	168899000871A	Oil Pressure Alarm Switch	22-9
160801040041A	Radiator			24-5	168899000875A	Starter Assembly	22-9
160801050020A	Intercooler			24-5	168899000879A	Engine Wiring Harness	22-9
160899000399A	Insect Net			24-5	Components		22-9
168899000578A	Fuel Pipe Cover Parts			22-9	168899000880A	Engine Wire	22-9
168899000590A	Spacer			22-9	168899000881A	Engine Grounding Wire	22-9
168899000629A	Gasket			22-7	168899000886A	Inlet Valve Rocker Arm	22-7
168899000630A	Plug			22-7	168899000891A	Intake Manifold Washer	22-9
168899000645A	Soft Washer			22-9	168899000892A	Exhaust Manifold Heat Shield	22-9
168899000649A	Soft Washer			22-9	168899000893A	Oil Cooling Filter	22-9
168899000669A	Collar			22-11	Components		22-9
168899000681A	Boost Pressure Sensor			22-9	168899000894A	Machine Oil Filter Element	22-9
168899000683A	Speed Sensor			22-9	168899000898A	Nozzle Holder Clamp	22-9
168899000686A	Soft Washer			22-9	168899000901A	Injector Return Pipe Welded	22-9
168899000687A	Water Temperature Sensor			22-9	Parts		22-9
168899000804A	Idle Speed Control			22-11	168899000907A	V Belt	22-9
Mechanism				22-11	168899000908A	ECU Components	22-11
168899000809A	Fuel Valve Seat			22-5	168899000909A	ECU	22-11
168899000810A	Intake Valve Seat			22-5	168899000990A	Cylinder Head Assembly	22-5
168899000811A	Exhaust Valve Seat			22-5	168899000991A	Cylinder Head Parts	22-5
168899000812A	Valve Guide Intake Repair Std			22-5	168899000992A	CYL Head	22-5
Bushing				22-5	168899000993A	Cylinder Block Assembly	22-5
168899000813A	Cylinder Head Lower Housing			22-5	168899000995A	Cylinder Block Assembly	22-5
168899000814A	Housing Bolt Spacer			22-5	Parts		22-5
Component				22-5	168899000996A	Cylinder Block	22-5
168899000818A	Cyl Liner			22-5	168899000997A	Crankshaft Thrust Blade	22-5
168899000819A	Rearing Set			22-5	168899000998A	Piston Ring Set	22-5
168899000823A	Piston Ring Components			22-5	168899000999A	Piston and Piston Ring	22-5
168899000824A	First Air Ring			22-5	Assembly		22-5
168899000825A	Second Air Ring			22-5	168899001000A	Piston	22-5
168899000826A	Third Air Ring			22-5	168899001001A	Crankshaft	22-5
168899000827A	Rod Assembly			22-5	168899001002A	Camshaft	22-7
168899000830A	Flywheel			22-7	168899001003A	Ball Bearing	22-7
168899000831A	Flywheel Ring Gear			22-7	168899001004A	Ball Bearing	22-7
168899000832A	Flywheel Bolt			22-7	168899001005A	Intake Manifold	22-7
168899000833A	PTO Flywheel Housing Assembly			22-7	168899001006A	Intake Manifold Washer	22-9
Parts				22-7	168899001007A	Water Pump Assembly	22-9
168899000834A	PTO Flywheel Housing			22-7	168899001009A	Water Pump Assembly	22-9
168899000835A	Oil Seal			22-7	21001328	Washer	22-3
168899000836A	Oil Seal			22-7	21005163	Plug	14-13
168899000837A	Pan Oil			22-7	21005186	Bolt	2-155
168899000838A	Oil Absorption Plate			22-7	21018263	Bolt	9-7
168899000839A	Oil Strn Screen			22-7	23002286	Screw	2-159
168899000840A	Intake Std Valve			22-7	24000513	Washer	2-155
168899000841A	Intake Exh Valve			22-7	24000639	Washer	2-155
168899000842A	Crosshead Assembly			22-7	60000509	Carton	7-3
168899000843A	Valve Spring Assembly			22-7	60001414	Fire Extinguisher	2-3
168899000844A	Valve Spg Retainer Lock			22-7	60006346	Thread Pin Shaft	30-5
168899000845A	Inlet Valve Rocker Arm			22-7	60006348	Inner Hexagon Screw	30-5
					60006636	Bolt	23-3

60007328 Clutch Pressure Disc Assembly	22-3	60075135 Spacer, Reverse Gear, 2nd Shaft.....	22-15
60007733 Steel Strap	24-3	60075136 Key	22-15
60009857 Socket Spanner.....	7-3	60075146 GEAR SPACER MAIN SHAFT AUXILIARY BOX.....	22-31
60011711 Water Pump Pulley.....	22-9	60075147 Gasket.....	22-35
60012789 Wiring Harness.....	15-7	60075149 Bushing, Spacer.....	22-17
60012804 Wiring Harness.....	15-7	60075151 Sleeve, Pressure & Lubrication Tube	22-25
60013165 Oil Pan Gastet.....	22-7	60075162 bolt assembly	22-35
60013321 Battery Negative Terminal Group	15-7	60075164 Gasket, Seal	22-37
60013322 Battery Positive Terminal Group.....	15-7	60075174 Flange, Adapter	22-35
60014660 Clamp Welding Plate	26-17	60075176 Gasket.....	22-25
60014918 The Flywheel Components.....	22-7	60075179 Nut	22-31
60016876 Relay Valve	14-7, 14-25, 14-27	60075188 Screw, Stop.....	22-25
60016881 Gas Filling Joint.....	14-13	60075192 Middle Shaft.....	22-17
60022604 Draw Belt	30-5	60075193 4-key, Intermediate Shaft.....	22-17
60022606 Draw Belt Pin	30-5	60075194 Bearing Baffle Plate, Intermediate Shaft	22-17
60022607 Strainer.....	30-5	60075199 Bearing Base	22-29
60022610 Fuel Tank.....	30-5	60075200 Ring, Retainer, Elastic.....	22-19
60022612 Supporting Bracket	30-5	60075201 Washer, Main Shaft Gear	22-15
60022613 Tank Bracket Strip	30-5	60075208 Ring, Snap.....	22-17
60022614 Oil Tank Cover.....	30-5	60075209 Ring, Snap.....	22-31
60022616 Cushion Belt of Draw Belt.....	30-5	60075210 Ring Snap	22-19
60025666 Limit Block	13-3	60075211 Ring, Snap	22-33
60031006 Connecting Rod Bearing Bush Assembly.....	22-5	60075212 Ring, Snap.....	22-15, 22-29
60034670 Distribution Box Assembly, Chassis ..	15-13	60075213 Ring, Snap.....	22-29
60041490 Oil Baffle Assembly.....	12-3	60075214 Ring, Snap.....	22-17
60041522 Right Half Axis.....	11-9, 12-13	60075215 Shaft, Middle, Ring, Snap.....	22-17
60041523 Left Half Axis.....	11-9, 12-13	60075224 Air Cleaner Regulator Assembly	22-27
60041586 Round Nut	11-11, 12-15	60075232 REDUCING GEAR SPACER AUXILIARY BOX.....	22-31
60041587 Round Nut	11-11, 12-15	60075233 Gasket.....	22-35
60043730 Fixing Sheet.....	2-71	60075234 WASHER MAIN SHAFT AUXILIARY BOX.....	22-31
60056379 Nut	2-41	60075235 Gasket.....	22-35
60060096 Generator Belt Set	22-9	60075238 Gasket Clutch Housing	22-13
60064779 CYLINDRICAL ROLLER BEARINGS 717813.....	22-35	60075240 Gasket, Head, Cylinder	22-37
60064780 Spindle Box, Vice	22-31	60075242 Bearing Cap, 1st Shaft, Gasket Bearing	22-13
60069652 Washer.....	22-9	60075245 Retainer.....	22-29
60069654 Engine Fan Belt Set.....	22-9	60075248 Washer	22-21
60070549 Turbocharger Assembly	22-11	60075249 Pin.....	22-23
60071633 Acid Accumulator	15-7	60075252 Washer, Thrust.....	22-21
60072722 V Belt.....	22-9	60075253 Washer.....	22-21
60075067 Plug.....	22-27	60075256 Ring, Snap.....	22-19, 22-33
60075071 Gasket.....	22-25	60078169 Nut 8-3, 14-7, 14-11, 14-21, 14-23, 14-25, 14-29, 15-3, 15-5, 15-7, 15-13, 15-15, 16-5, 19-3, 20-3, 21-5, 24-3, 24-13, 26-17, 26-19, 27-3, 28-3, 30-3	
60075073 High/Low Gear Synchronizer Assembly.....	22-31	60085527 Waterproof Ring	15-13
60075078 Adapter, Range Shift.....	22-25	60090803 The Clamp Nut	17-7, 17-11
60075082 Reverse Idler Gear	22-21	60099447 Rear Fog Lamp	15-5
60075083 Reverse Gear Shaft	22-15	60100617 Power Steering Oil Pump.....	26-17
60075084 Reverse Gear Shaft.....	22-15	60101847 Strip, Seal	2-55
60075085 Gear Low Range Shaft.....	22-15	60103813 Type 1 hex nuts	11-3, 12-3, 12-9
60075090 Gear Assembly.....	22-31	60103947 Hexagon Bolt	12-9
60075102 Key, Woodruff.....	22-17	60103962 Hexagon Bolts	12-3
60075105 Plate, Side	22-25	60103968 Bolt, Hexagon	12-3
60075109 Gasket.....	22-25	60104021 All Metal Lock Nut	11-15, 12-19
60075110 Cover.....	22-25	60104190 Quick Connector.....	14-23
60075111 Spacer Bushing, Spring.....	22-25	60104191 Quick Coupling Connector.....	14-13
60075117 Reverse Gear Clasp.....	22-15		
60075118 Intermediate Shaft	22-21		
60075120 Low Gear Sleeve.....	22-15		
60075128 Nut, Dowel	22-25		
60075133 Spline Spacer Shaft.....	22-15		

60104192 Quick Connector.....	14-5, 14-13, 14-23	60118362 Foot valve	2-183
60104193 Quick Connector.....	14-13	60118365 Clutch Master Pump Reservoir Oil Kettle	2-181
60104194 Quick Coupler	14-13	60118854 Right Door Glass Lifter Assembly	2-135
60104195 Quick Connector.....	14-5, 14-13, 14-23	60118855 Right Door Upper Hinge	2-129
60104308 Lifting Bent plate.....	22-23	60118856 Right Next Door Hinge Assembly	2-129
60104309 Iron Wire.....	22-29, 22-37	60118857 Left Door Glass Lifter Assembly	2-135
60104310 Bearing.....	22-19	60118858 Left Door Upper Hinge	2-129
60104311 single row angular contact ball bearing.....	22-17	60118859 Left Door Lower Hinge	2-129
60104312 BEARING. ROLLER. SHORT CYLINDRICAL.....	22-33	60118860 Door Limiter Assembly of Right Door.....	2-171, 2-173
60104313 Bearing, Roller, Cylinder.....	22-33	60118861 Door Limiter Assembly of Left Door ..	2-169, 2-173
60104314 Needle Bearing	22-21	60119268 Ignition Lock ASSY	2-141
60104316 Bearing.....	22-17	60119920 Side Reflection Device	2-63
60104334 Gasket Control	22-23	60119921 Front Fog Lamp	2-65
60104336 Spacer, Gear.....	22-19	60119922 Light	2-27
60104341 Washer.....	22-25	60120093 Right Ear Superstructure Handrail.....	2-119
60104356 Lengthen Middle Shaft Cover Gasket	22-35	60120467 Left Pillar Outer Decorating Plate Cover	2-119
60104366 Gasket.....	22-23	60120957 Washer.....	2-159
60104369 Stud	22-23	60122626 Cylindrical Pin, Elastic.....	22-17
60104370 Stud	22-13	60122635 Bolt, Hexagon	17-13
60104372 Spring, Compression	22-25	60122641 Bolt, Hexagon	22-25
60104374 COMPRESSED SPRING.....	22-23	60122644 Plug.....	22-37
60104381 Cylindrical Pin	22-25	60122648 Screw	22-21
60104712 Wiring Harness.....	15-3	60122651 Stud	22-13
60105071 24V Cigar Lighter.....	2-55	60122659 Bearing.....	22-29
60105341 Butterfly Valve	16-9	60125276 Seal, Oil.....	22-25
60105343 Valve Body.....	16-9	60125991 Nut	17-7, 17-11
60105345 Cylinder Assembly.....	16-9	60125992 Nut.....	13-7
60105620 gasket.....	11-15, 12-3, 12-11, 12-19	60129182 Oil Plug.....	22-23
60105694 Bolt, Hexagon	11-15	60129201 Bolt with Lock Washer.....	22-23
60107036 Washer.....	11-15, 12-19	60129203 Hexagon Socket Cap Screw	22-25
60107037 Washer.....	22-13	60129208 O-Ring Seal	22-13
60107132 Ring, Retainer, Elastic.....	12-13	60136827 Spring Washer	13-5
60109937 Quick Coupler	14-23	60139091 Washer.....	22-13
60110159 Brake Chamber	17-13	60139106 Washer.....	12-15, 17-17
60110160 Brake Chamber	17-13	60139107 Washer.....	11-7
60110175 Brake Drum.....	17-15	60139521 Screw	11-7
60110188 Sensor.....	17-17	60139533 Nut, Hexagon Head	12-3
60110328 Upper Sheet of Pipeline Support	5-3	60139595 Bolt.....	12-3, 22-25
60110344 Horn	2-57	60139686 Bolt.....	14-23, 19-3
60110347 Antenna.....	2-55	60141516 Wiper Motor and Mounting Plate Assembly.....	2-177
60114860 Dual-position Three-way Solenoid Pneumatic Valve	15-3	60144669 Hook Lock Buckle.....	2-149
60115756 Quick Coupler	14-13	60144670 Steel Lock Cable	2-149
60116487 Rubber Pipe Assembly.....	26-17	60144672 Right Cover Lock.....	2-149
60117669 Cover in the Front Lock Assembly	2-147	60144674 Hood Lock	2-149
60117670 Door Lock	2-159	60144676 Screw Cap.....	2-161, 2-163
60117671 Door Lock	2-159	60144677 Hood Lock Buckle Bracket Assembly.....	2-149
60118233 Front Right Wiper Brush ASSY	2-175	60144678 Lock Pin Seat.....	2-149
60118234 Wiper Brush Assembly.....	2-175	60144680 Inner-opening Handle of Right Door.....	2-163
60118237 Front Wiper Motor with Joint Rod Assembly.....	2-175	60144681 Inner-opening Handle Guard of Right Door.....	2-163
60118238 Scrubber Assembly.....	2-165	60144682 Right Door Lock Pull Rod	2-163
60118239 Front Right Wiper Arm ASSY	2-175	60144684 Right Door External Open Pull Rod ..	2-163
60118240 Front Left Wiper Arm ASSY	2-175	60144685 Right Door External Handle	2-163
60118242 Regulate Switch, Light Highness	2-55	60144688 Inner-opening Handle of Left Door	2-161
60118244 Door Lamp Switch.....	2-145		
60118250 Combined Switch.....	2-53		
60118361 Clutch Main Pump.....	2-183		

60144689 Inner-opening Handle Guard of Left Door.....	2-161	60147379 Grease Nozzle ...	11-13, 11-15, 12-17, 12-19, 17-13
60144690 Left Door Lock Pull Rod	2-161	60147380 Density Gasket.....	11-9, 12-13
60144692 Left Door External Open Pull Rod	2-161	60147385 Flange Assembly.....	11-3, 12-5
60144693 Left Door External Handle Assembly.....	2-161	60147386 Lower Stinger Bracket.....	12-11
60144694 Rubber Sleeve	2-149	60147387 Lower Stinger Bracket.....	12-11
60144696 Locker	2-161, 2-163	60147388 Lower Stinger Bracket.....	11-7
60144812 Oil Gear Unit	22-7	60147389 Lower Stinger Bracket.....	11-7
60144880 Nut.....	2-107, 2-111	60147392 Pin.....	11-15, 12-19
60144883 Nut....	2-155, 14-5, 14-13, 14-23, 14-25, 16-3, 19-3, 20-3, 23-3, 24-9, 25-3, 26-17	60147396 Cylindrical Pin	11-11, 12-15
60144888 Nut.....	2-69, 2-71, 2-107, 2-111, 2-135, 3-3, 15-15, 25-3	60147397 Thrust Washer.....	11-11, 12-15
60144889 Nut....	2-169, 2-171, 2-173, 2-181, 29-7, 29-9	60147398 Brake Bottom	11-13, 12-17
60144892 Bolt.....	2-107, 2-111	60147400 Brake friction plate	11-13, 12-17
60144895 Bolt.....	16-5, 21-3, 26-17	60147403 Right Brake Camshaft.....	11-13, 12-17
60144899 Bolt.....	24-3	60147404 Brake camshaft (left).....	11-13, 12-17
60144904 Bolt	15-15	60147406 Ring, Retainer, Elastic.....	11-13, 11-15, 12-17, 12-19
60144906 Bolt... 2-57, 2-135, 2-139, 2-147, 2-179, 2-181		60147407 Axle packing ring	12-7
60144907 Bolt.....	3-3, 15-15	60147410 Ring, Seal	11-3
60144908 Bolt	2-33, 29-7, 29-9	60147411 Ring, Seal	11-9, 12-13
60144912 Bolt.....	2-71, 2-181, 3-3	60147412 Ring, Seal	11-11, 12-15
60144913 Bolt	2-107, 2-111, 2-119, 2-123, 2-147, 2-175, 16-5	60147413 Main Reducer Oil Seal	11-3, 12-5
60144915 Bolt.... 14-11, 14-21, 15-5, 15-13, 26-17, 27-3, 30-3		60147861 Bolt, Hexagon Head.....	11-3, 12-9
60144917 Bolt	2-21, 2-33, 2-39, 2-91, 2-169, 2-171, 2-173, 2-181, 2-185	60155285 Pump Assy-oil Strr	22-7
60144921 Bolt.....	2-123, 29-7, 29-9	60155287 LINER_CYL_S/S.....	22-5
60144926 Nut	29-7, 29-9	60155288 Cylinder Liner.....	22-5
60146757 Overspeed Gear, 2nd Shaft	22-15	60155289 LINER_CYL_S/S.....	22-5
60146758 2nd Gear, 2nd Shaft.....	22-15	60155291 Inlet Valve Rocker Arm.....	22-7
60146759 1st Gear, 2nd Shaft.....	22-15	60155294 Inlet Valve Rocker Arm.....	22-7
60146760 Auxiliary Case Drive Gear	22-29	60164813 Gasket.....	22-13
60146761 1st Shaft Gear	22-15, 22-19	60164853 Fork, Shift	22-13
60146762 Overdrive Gear, Intermediate Shaft.....	22-17	60170931 Cap Clutch.....	22-13
60146763 Gear, Intermediate Shaft	22-17	60175479 Quick Connector.....	14-13
60146764 Intermediate Shaft Second Gear.....	22-17	60181010 Mid-high Roof Cab Steering Column.....	2-185
60146765 Intermediate Shaft First Gear.....	22-17	60183678 Speed Control Module	2-61
60146774 Fork Shaft	22-23	60183682 Internal and External Mode Motor	2-61
60147326 Flange Assembly.....	12-7	60183683 Mode Motor.....	2-61
60147327 Locking Plate	11-3, 12-9	60183684 Water Valve Motor	2-61
60147328 Steel Ball	11-11, 12-15	60183685 Temperature Sensor	2-61
60147333 Front Axle Shaft Gear	12-5	60183686 Heater Valve	2-61
60147340 Differential Locking Ring	12-5	60183687 Wiring Harness.....	2-61
60147352 Bushing	11-13, 11-15, 12-17, 12-19	60186746 Piston Pin	22-5
60147355 Washer	11-11, 12-19	60188041 Wind Scooper ComponentS	22-9
60147358 Regulating Washer	11-3	60189262 Inner hex tapered screw.....	22-27
60147359 Regulating Washer	11-15, 12-19	60190934 Radio.....	3-3
60147361 Regulating Washer	12-5	60196532 Left Door Lock Body	2-161
60147362 Regulating Washer	11-15	60196533 Right Door Lock Body	2-163
60147363 Cap, End.....	12-3	60197003 Clamp Sleeve.....	28-3
60147364 Cap, End.....	11-11, 12-15	60197334 Pipeline Support.....	5-3
60147365 Cap, End.....	11-11, 12-15	60198935 Evaporator	2-59
60147366 Cap, Dust.....	11-3, 12-5	60199812 Hollow Rivet.....	17-15
60147367 Additional Washer	11-13, 12-17	60199822 Bolt, Hexagon Head.....	11-15, 12-19
60147369 Shaft.....	12-7	60199827 Lock Nut	17-15
60147373 Return Spring.....	11-13, 12-17	60200335 Nut	13-3
60147375 Bolt, Hexagon Head.....	11-7, 12-11	60202124 Ashtray	2-3
60147378 Rivet.....	11-13, 12-17	60202895 Hose Clamp	30-3
		60203144 Clamp.....	2-71
		60205575 Pipe Clamp	5-3
		60205576 Pipe Clamp Bush.....	5-3
		60205698 Bolt.....	17-21, 17-23

60207152 Bolt.....	2-5, 14-13, 32-3	60243434 Fitting, Adapter.....	14-7, 14-27
60207366 Spanner.....	7-3	60243435 ABS Magnetic Valve.....	8-3
60207386 Gasket Sub Assy.....	22-11	60247886 Gear 1 & 2 Fork Shift.....	22-23
60207387 Exhaust Nozzle Washer.....	22-11	60247888 Guide Block.....	22-23
60207392 Filter Assy Fuel.....	22-9	60247898 Low Reverse Shift Fork Shaft.....	22-23
60207397 Tubing Intake Unit.....	22-9	60248016 Engine.....	22-3
60207400 Tubing Intake Unit.....	22-9	60251533 Assembly Parts for Cylinder Head Lower Housing.....	22-5
60210230 Bolt.....	30-3	60251534 Air cylinder cover washer.....	22-5
60210231 Bolt.....	2-5	60251535 the Welded Part of the Dipstick Pipe... ..	22-7
60210233 Nut.....	13-3	60251538 Crankshaft Thrust Plate.....	22-5
60211864 Left Combined Taillight.....	15-5	60251539 Crankshaft Pulley Assembly Parts.....	22-7
60211865 Right Combined Taillight.....	15-5	60251540 Camshaft Assembly Parts.....	22-7
60212900 Lifting Controller.....	19-3	60253346 Bulb.....	2-67
60212901 Left and Right Hydraulic Lock Oil Line Connected to the Oil Pipe.....	19-3	60253349 Upper Steering Shaft of Steering Column.....	2-187
60212902 Connecting Oil Pipe of Hydraulic Lock.....	19-3	60253350 Lower Steering Shaft of Steering Column.....	2-187
60212903 Connecting Oil Pipe of Hydraulic Cylinder.....	19-3	60253351 Anti-dust Cover.....	2-187
60212904 Connecting Oil Pipe of Hydraulic Cylinder.....	19-3	60253352 Nut.....	2-187
60212907 Hydraulic Lock.....	19-3	60253353 Washer.....	2-187
60212957 Limit Block.....	17-5, 17-9	60255460 Connecting Rod and Fixed Support... ..	2-177
60213185 Electric Opening Plunger Pump.....	19-3	60255461 Washer Motor.....	2-167
60213186 Opening Plunger Pump.....	19-3	60255462 Washer Cover and Gasket.....	2-167
60214066 Air Conditioner Control Panel.....	2-59, 2-61	60255463 Wash Pot.....	2-167
60218295 Self Locking Nut.....	11-7, 12-11	60255464 Washer Waterpro of Plug.....	2-167
60226300 Cap Screw.....	17-13	60255465 Water Pipe of Washer.....	2-167
60226370 Ring, Retainer, Elastic.....	17-17	60255466 Three-way Joint.....	2-167
60226374 Hexagon Flange Plug.....	12-11	60255502 Dashboard Fixed Seat.....	20-3
60226377 Plug.....	11-7, 12-11	60256058 Hexagon Bolt & Spring Washer Assembly.....	22-13
60226381 Stud.....	11-7, 12-11	60256074 Bolt, Hexagon.....	22-37
60226828 Stud.....	11-7, 12-11	60256085 Combination Part, Bolts and Spring Washer.....	22-23
60226830 Nut, Hexagon Head.....	11-7, 12-3, 12-11	60256093 Hexagon Bolt & Spring Washer Assembly.....	22-27
60226847 Bolt, Hexagon.....	11-13, 17-13	60256102 Upper Cover.....	22-23
60226850 Bearing, Cylindrical Roller.....	11-3, 12-9	60256755 Cylindrical Pin.....	11-5, 12-3
60226857 Stud.....	12-3	60259046 Fork, Shift.....	22-37
60226858 Stud.....	12-3	60259053 Hexagon Nut.....	22-23
60226859 Stud.....	12-3	60259430 Nut.....	23-3
60226880 Lock Nut.....	12-5	60259431 Bolt.....	13-3
60226883 Ring, Retainer, Elastic.....	12-5	60259432 Bolt.....	13-3
60226906 Split Pin.....	11-3, 12-5	60260865 Lower Seat of Air Valve Spring.....	22-7
60226917 Set Screw.....	12-3	60260866 Upper Seat of Air Valve Spring.....	22-7
60227101 fan.....	2-61	60260867 Outer Valve Spring.....	22-7
60227745 Two League Box.....	2-51	60260868 Inner Valve Spring.....	22-7
60227901 Fixed Bolt.....	11-3, 12-9	60260869 Valve Rocker Arm Components.....	22-7
60227911 Bolt.....	11-13, 12-11, 12-15	60260870 Inlet Valve Rocker Arm Shaft Component.....	22-7
60227917 Ring, Retainer, Elastic.....	11-11, 12-15	60260876 Crankshaft Assembly Parts.....	22-5
60227922 Bolt, Hexagon.....	11-11, 12-15	60262611 Electronic Throttle.....	22-11
60227951 Cylindrical Pin Elastic.....	11-13, 12-17	60265717 Bolt.....	2-189, 14-29, 15-3, 19-3, 20-3, 21-5, 24-3, 24-13, 26-17, 26-19
60227968 Bracket.....	11-15, 12-19	60265718 Bolt.....	14-11, 15-13, 20-3, 27-3, 28-3
60227986 Bolt, Hexagon.....	11-3	60265719 Bolt.....	14-11, 14-29, 22-3, 26-17
60227990 Bearing, Cylindrical Roller.....	11-3	60265720 Bolt.....	14-23, 19-3, 27-3
60227991 Bearing, Cylindrical Roller.....	11-3	60265721 Bolt.....	27-3
60228512 ABS Controller.....	8-3	60265722 Bolt.....	19-3
60229369 Hanger of exhaust tube (1).....	16-11	60265723 Bolt.....	15-15
60241448 Bolt.....	19-3, 25-3, 26-17	60265726 Bolt.....	8-3, 14-7
60242587 Bolt.....	13-3		
60242588 Bolt.....	13-3		
60242589 Bolt.....	13-3		
60242591 Nut.....	13-3		

60265732 Bolt.....	15-3, 16-3, 16-13, 24-13
60265733 Bolt.....	16-3, 30-3
60265734 Bolt.....	16-3, 16-5, 16-13
60265735 Bolt.....	16-3, 16-5, 21-5
60265736 Bolt.....	15-7, 16-5
60265737 Bolt.....	16-13
60265748 Bolt.....	2-5, 9-7, 13-3, 16-3, 17-3, 17-23, 18-3, 19-3, 20-3, 23-3
60265749 Bolt.....	14-13
60265750 Bolt.....	13-3, 16-3
60271572 Piston Pin Clasp	22-5
60273215 Oil Seal Axis Balanced Suspension....	13-5
60273563 Heater Core	2-61
60273565 Mode Motor.....	2-61
60273566 Internal and External Circulating Motor	2-61
60273567 Water Valve Motor	2-61
60273568 BLOWER.....	2-61
60273569 Evaporator Core	2-61
60273570 Speed Control Module	2-61
60273571 Thermistor	2-61
60273800 Bolt.....	14-5, 14-23, 14-25, 17-3, 17-21, 20-3, 23-3, 24-9, 26-17
60274682 Manual Brake Valve ASSY	2-181
60274813 Braking switch.....	2-183
60279287 Cotter Pin.....	11-15, 12-19, 17-15
60282425 Fuel Temperature Sensor.....	22-9
60284005 Evaporator core.....	2-61
60284006 Heater Core	2-61
60284007 Expansion Valve.....	2-61
60284008 Expansion Valve.....	2-61
60287245 Balanced Suspension Assembly.....	13-3
60287261 Air Compression Pump Assembly	22-9
60287266 Element et Fuel Filter.....	22-9
60287273 Nut, Hexagon Head	17-17, 22-13
60287281 Spring Washer	11-3, 11-9, 11-13, 12-3, 12-9, 12-13, 12-17
60287282 Spring Washer	22-25
60287284 Spring Washer	12-3, 22-25
60287326 Bolt Hexagon	17-7, 17-11
60287329 Hexagon Bolt & Spring Washer Assembly.....	22-35
60287333 Plain Washer.....	22-23
60287361 Fitting, Adapter.....	22-39
60287375 Ring, Retainer, Elastic.....	12-3, 17-15
60290914 Front Panel Assembly	2-79
60292205 Bolt.....	13-3
60314437 Bush.....	12-3
60314438 O-ring Seal.....	12-3
60314439 Differential Lock Rocker Arm Assembly.....	12-3
60314444 Bushing, Spacer.....	12-3
60314445 Bracket Assembly.....	12-3
60314446 Cylindrical Pin	11-7, 12-3, 12-11
60314447 Plug.....	12-3
60314452 Bolt, Hexagon Head.....	11-5, 12-3
60314453 Base, Bearing	12-3
60314456 Nut	11-3, 12-5
60314457 Bearing.....	12-5
60314458 Moveable Fork Shift Block	11-3, 12-5, 12-9
60314459 Fork, Shift	12-5
60314460 Inter Shaft Differential Housing Gasket	12-5
60314461 Differential Locking Pin	12-5
60314465 Axle Shaft Gear Washer (Front).....	12-5
60314466 Axle Shaft Gear Washer (Front).....	12-5
60314467 Axle Shaft Gear Washer (Front).....	12-5
60314470 Planet Gear.....	11-3, 12-5, 12-9
60314471 Washer	11-3, 12-5, 12-9
60314472 Axle Shaft Gear	12-5
60314473 Axle Shaft Gear Washer	12-5, 12-9
60314474 Axle Shaft Gear Washer (Rear) ..	12-5, 12-9
60314475 Axle Shaft Gear Washer (Rear) ..	12-5, 12-9
60314476 Axle Shaft Gear Washer (Rear) ..	12-5, 12-9
60314477 Axle Shaft Gear Washer (Rear) ..	12-5, 12-9
60314479 Bolt, Hexagon	11-5, 12-5, 12-9
60314480 Bearing.....	12-5
60314481 Hollow Shaft.....	12-5
60314484 Drive Column Gear	12-5
60314485 Nut	12-5
60314486 Bolt, Hexagon Head.....	12-5
60314487 Bearing Pressure Plate	12-5
60314488 Regulating Washer	12-5
60314489 Regulating Washer	12-5
60314490 Regulating Washer	12-7
60314491 Bearing Unit Assembly	12-7
60314492 Stud	12-7
60314495 Column Gear Driven	12-7
60314496 Rolling Bearing.....	12-7
60314497 Steel Wire Ring	12-7
60314498 Grease Baffle	12-7
60314502 Four Point Contact Ball	12-7
60314506 Fork, Shift	11-3, 12-9
60314507 Bent Plate	11-3, 12-9
60314508 Sliding Engage Bushing	11-3, 12-9
60314509 Round Nut	11-3, 12-9
60314510 Lock Washers	11-3, 12-9
60314511 Fixed Meshing Sleeve.....	11-3, 12-9
60314512 Regulating Nut, Differential Bearing ...	11-3, 12-9
60314516 Adjusting Washer	11-3
60314518 Adjusting Washer	11-3
60314520 Half Axis Gear	11-3, 12-9
60314528 Plate Spring Bracket	11-7, 12-11
60314529 Pin.....	11-7, 12-11
60314532 Arched Fixing Catch.....	11-7, 12-11
60314533 Arched Fixing Catch.....	11-7, 12-11
60314536 Chamber Bracket Assembly	11-7, 12-11
60314537 Bolt, Hexagon	11-7, 12-11
60314538 Bolt, Hexagon	11-7
60314539 O-ring	11-7, 12-11
60314543 Rear wheel hub zsembly	11-9, 12-13
60314544 Ring, Retainer, Elastic.....	11-9
60314545 Inner Gear Ring.....	11-9, 12-13
60314548 Oil Baffle Cover	11-9, 12-13
60314551 Needle Rolling Bearing	11-11, 12-15
60314552 Gear, Carrier	11-11, 12-15
60314553 Planet Gear Shaft.....	11-11, 12-15
60314554 Washer, Seal	11-11, 12-15
60314555 Bolt, Hexagon	11-11, 12-15, 17-13
60314556 Sun Gear	11-11, 12-15

60314557 Washer	11-11, 12-15	60335138 Washer	17-17
60314560 Packing plug	11-13, 12-17	60335139 Roller Bearing	17-17
60314563 O style packing ring	11-13, 12-17	60335140 Shaft Seal	17-17
60314564 Spring, Return	11-13, 12-17	60335143 Sealing Plug	17-19
60314569 Bolt	11-11, 12-17, 17-15	60335145 Hexagon Head Bolts of Fine Teeth	17-17
60314570 Return Spring Pin	11-13, 12-17	60335146 Knuckle Pin	17-17
60314577 Adjusting Washer	11-15	60335147 Spacer Adjusting	17-19
60314578 Adjusting Washer	11-15	60335148 Adjusting washer	17-19
60314579 Adjusting Washer	12-19	60335149 Adjusting washer	17-19
60314586 Bolt, Hexagon	12-19	60335150 Adjusting washer	17-19
60314587 Bracket	11-15, 12-19	60335151 Adjusting washer	17-19
60314588 Bracket	11-15, 12-19	60335152 Adjusting washer	17-19
60314590 Ring	11-3	60335153 Adjusting washer	17-19
60314595 Regulating Washer	11-3	60335154 Adjusting washer	17-19
60314596 Regulating Washer	11-3	60335155 Adjusting washer	17-19
60314603 Regulating Washer	11-3	60335156 Adjusting washer	17-19
60314604 Regulating Washer	11-3	60335157 Adjusting washer	17-19
60314606 Base, Bearing	11-3	60335158 Adjusting washer	17-19
60314631 Straight Adapter	11-7, 12-11	60335159 Adjusting washer	17-19
60314634 Rolling Bearing	11-9, 12-13	60335160 Adjusting washer	17-19
60314635 Rolling Bearing	11-9, 12-13	60335161 Adjusting washer	17-19
60317486 Piston Nozzle Unit	22-5	60335162 Adjusting washer	17-19
60332847 Connecting Rod Bush	22-5	60335163 Adjusting washer	17-19
60333774 Quick Connector	28-3	60335164 Shaft Seal	17-17
60335017 Triangle Alarm Board	7-3	60335165 The Top Bushing	17-17
60335075 Brake Camshaft	17-13	60335174 Brake Drum	11-13, 12-17
60335076 Brake Camshaft	17-13	60335175 Pin	11-13, 12-17
60335078 Shroud	17-13	60335176 Hexagon Bolt	12-17
60335079 Bolt, Hexagon Head	17-13	60335179 Left Diaphragm Spring Brake Chamber	11-15, 12-19
60335082 U Clamp Pin	17-13	60335180 Right Diaphragm Spring Brake Chamber	11-15, 12-19
60335083 Spacer Bushing	17-17	60339491 Silicone Oil Fan Clutch Assembly	22-9
60335085 Instruction Sheet	17-13	60343634 Bearing Pin	22-23
60335086 Shim	17-13	60343635 Shift Block	22-23
60335087 Shim	17-13	60343646 Air Control Valve	22-25
60335088 Shim	17-13	60347433 Quick Connector	2-3
60335089 Washer	17-15	60351631 transmission and power take-off	22-3
60335090 Ring Retainer Elastic	17-15	60354727 Suction Oil Pipe of Motor Pump	19-3
60335094 Knuckle	17-13	60354728 Pressure Oil Pipe of Motor Pump	19-3
60335098 Sealing Plug	17-13	60358718 Oil Water Separator	30-3
60335100 Bolt Hexagon Head	17-13	60358722 Filter Element	30-7
60335101 Pad Plate	17-13	61003891 Nut	2-189, 15-3, 15-7, 16-3, 16-5, 16-13, 20-3, 21-3, 21-5, 24-5, 24-13, 26-17, 30-3
60335106 Tapered Roller Bearing	17-13	61005716 Clutch Release Bearing	22-3
60335107 Oil Baffle Cover	17-13	61006355 Front Suspension Assembly	2-155
60335109 Front Hub	17-15	61006356 Front Suspension Upper Left Bracket	2-157
60335110 Oil Baffle Cover	17-15	61006357 Front Suspension Upper Right Bracket	2-157
60335111 Tapered Roller Bearing	17-15	61006358 Shock Absorber Plate	2-157
60335112 Thrust Washer	17-15	61006359 Limit Rod	2-157
60335113 Hub Cap	17-15	61006360 Limit Block	2-157
60335114 Screw, Inner Hexagon	17-15	61006361 Stabilizer Rod Assembly	2-157
60335120 Sleeve Bushing	17-15	61006362 Rubber Shaft Sleeve	2-157
60335121 Washer	17-15	61006363 Rubber Washer	2-157
60335122 Seal	17-15	61006364 Pin	2-157
60335123 Sleeve Bushing	17-15, 17-17	61006365 Pin Nut	2-157
60335126 Upon brake friction plate	17-15	61006366 Upper Support	2-157
60335128 Steering Cross Rod	17-15	61006367 Buffer Seat	2-157
60335129 Nut, Hexagon Head	17-15	61006368 Polyurethane Gasket	2-157
60335130 Pin	17-15		
60335131 Hexagon Head Bolts of Fine Teeth	17-15		
60335134 Snap Ring	17-17		
60335135 Sealing Plate	17-17		
60335137 O-ring	17-17		

61006369 Shock Absorber.....	2-157	A210111000024 Bolt	20-3, 24-5, 24-7
61006370 Shock Absorber.....	2-157	A210111000026 Bolt	22-3
61006371 Hydraulic Lock Support Assembly.....	2-155	A210111000027 Bolt	16-11
61006538 Radiator Support	2-7	A210111000063 Bolt	26-5
61006539 Rear Suspension Spiral Spring Shock Absorber	2-7	A210111000080 Bolt	2-59, 2-137
61006540 Rear Suspension Swing Boom	2-7	A210111000089 Bolt	2-119
61006541 Cross Beam of Rear Suspension	2-7	A210111000091 Bolt	6-3
61006542 Front Suspension Lower Support	2-5	A210111000119 Bolt.....	29-5
61006543 Turnover Cylinder	19-3	A210111000204 Bolt	2-155
61006673 Rear Suspension Assembly.....	2-5	A210111000270 Bolt	16-3
61008313 Spider Assembly	11-3, 12-5, 12-9	A210111000297 Bolt	2-189, 22-3
61008316 Housing	12-3	A210111000447 Bolt	27-9
61008317 Main Reducer Assembly	11-3	A210114000006 Bolt	23-3
61008319 Active Bevel Gear	12-7, 12-9	A210114000010 Bolt	9-7
61008320 Washer	11-11, 12-15	A210114000120 Bolt	31-3
61008621 Bolt, Wheel	17-15	A210127000003 Bolt.....	17-21, 17-23
61009385 Synchronization Assembly	22-15	A210204000133 Screw	2-81
61009409 Bolt.....	11-9, 12-13	A210204000135 Screw	2-27
61009637 Elbow Union Connector	28-3	A210204000139 Screw	2-81, 2-83
61009655 Bearing	22-13	A210204000179 Screw	14-19
61009657 Cage Assembly Bearing.....	22-19	A210204000184 Screw	2-79
61009918 Transmission Control Assembly.....	27-3	A210204000341 Screw	2-39, 2-43
61009945 Flexible Shaft	27-3	A210210000002 Screw	2-65, 15-13
61009946 Flexible Shaft	27-3	A210210000006 Screw	2-159, 15-13
61012554 Rainproof Cover	26-19	A210210000007 Screw	2-141
61013913 Hook and Loop Safety Vest	7-3	A210210000008 Screw	2-15, 2-19, 2-25, 2-29, 2-31, 2-71, 2-99, 2-115, 2-135
61013923 Rubber Wheel Stop	7-3	A210210000010 Screw	2-19, 2-159
61014415 Front Bumper Middle Faceplate.....	2-89	A210210000017 Screw ...	2-33, 2-59, 2-71, 2-95, 2-121, 2-127, 2-153
61014465 Air Distribution Mechanism Assembly.....	2-59	A210210000027 Screw	2-153, 2-165
61014875 Regulating Washer	11-11, 12-15	A210211000015 Screw.....	2-159
61019283 Clutch Booster.....	22-3	A210264000004 Tapping Screw.....	2-17, 15-3
61020937 Seal.....	17-13	A210299000040 Tapping Screw.....	2-33
61020938 Quill roller	17-13	A210306000011 Nut.....	28-3
61020939 Cylinder Bracket.....	17-13	A210306000012 Nut.....	14-9
61020940 Cylinder Bracket.....	17-13	A210307000012 Nut.....	2-71, 2-119, 2-143, 6-3, 15-7
61020942 Knuckle	17-13	A210307000017 Nut.....	2-93, 16-3, 16-5, 16-11, 16-13
61020947 Front Axle	17-15	A210307000031 Nut.....	16-3
61020949 Steering Trapezoid Arm	17-15	A210307000036 Nut.....	24-7
61020950 Steering Trapezoid Arm	17-15	A210307000040 Nut.....	27-9
61020951 Bolt, Hexagon	17-17	A210309000014 Nut.....	27-9
61020953 Plug.....	17-17	A210313000034 Nut.....	17-21, 17-23, 19-3
61023513 Pressure Measuring Connector	14-5, 14-23	A210319000014 Nut.....	26-5
61024601 Seal.....	17-17	A210319000016 Nut.....	9-7, 13-3
61025678 Screw, Cylinder Hexagon	11-11, 12-15	A210319000017 Nut.....	17-3
61025681 Washer.....	11-15	A210319000019 Nut.....	9-7
61025733 Plug.....	11-7	A210319000021 Nut.....	31-3
61028556 Bolt.....	9-5	A210332000001 Screw Plug.....	14-13
61028566 Nut.....	2-5, 30-3, 32-3	A210334000015 Nut.....	14-11, 19-3
61028568 Nut	10-3	A210338000000 Nut.....	14-5
61028574 Nut	17-5, 17-9	A210338000002 Nut.....	14-11
61028577 Nut	2-5, 30-3	A210338000003 Nut.....	28-3
61032214 Fork, Shift	22-13	A210347000000 Nut.....	14-13
A210110000012 Bolt	17-3	A210352000001 Nut.....	16-3
A210110000205 Bolt	26-5	A210355000001 Nut.....	17-21, 17-23
A210110000323 Bolt	16-3	A210401000001 Washer	2-155, 22-3
A210110000341 Bolt	9-7	A210401000002 Washer	23-3
A210110000384 Bolt	2-155	A210401000003 Washer	23-3
A210110000432 Bolt	15-3	A210401000004 Washer	23-3
		A210401000015 Washer	2-65

A210401000016 Washer	2-137, 2-159, 2-165, 29-7, 29-9
A210401000017 Washer	2-71, 2-119, 2-141, 14-7, 29-7, 29-9
A210404000003 Washer	2-189, 16-3, 20-3, 25-3
A210404000004 Washer	2-5, 23-3, 25-3
A210404000005 Washer ...	6-3, 21-3, 24-13, 29-7, 29-9
A210404000006 Washer	27-9
A210404000008 Washer	2-5
A210404000009 Washer ..	2-15, 2-19, 2-25, 2-59, 2-71, 2-115, 2-137, 2-153, 2-165, 2-181, 15-13, 29-7, 29-9
A210404000012 Washer	31-3
A210405000002 Washer	31-3
A210405000003 Washer	17-21, 17-23, 19-3
A210405000004 Washer	2-17
A210405000005 Washer	2-65
A210405000006 Washer ..	2-19, 2-27, 2-29, 2-59, 2-81, 2-83, 2-95, 2-99, 2-121, 2-127, 2-159
A210405000007 Washer	2-71, 2-79, 2-119, 6-3, 7-5, 14-7
A210405000008 Washer	19-3
A210405000011 Washer	2-93, 2-155
A210414000006 Ring, Retainer	17-21, 17-23
A210431000003 Washer	14-11
A210431000005 Washer	14-11, 19-3
A210431000006 Washer	14-5
A210431000008 Washer	28-3
A210459000005 Washer	2-159
A210491000011 Pin	7-5
A210491000017 Pin	17-21, 17-23
A210491000020 Pin	19-3
A210501000013 Pin	26-7
A210506000021 Rivet	9-7
A210506000026 Rivet	9-7
A210506000027 Rivet	9-7
A210506000028 Rivet	9-7
A210506000040 Rivet	9-3
A210508000032 Pin	7-5
A210710000004 Tube Sleeve	14-9
A210712000005 End Straight Pipe Connector...	26-17
A210747300000 Joint Body	14-11
A210747300001 Joint Body	26-17
A210747300002 Joint Body	28-3
A210770000392 Pipe Joint	14-7
A210770000394 Fitting, Connector	14-23
A210804000001 Oil Cup	17-21, 17-23
A210804000002 Oil Cup	26-7
A220400000516 Exhaust Brake Valve	16-3
A220400000574 Oil Pressure Valve Components	22-5
A221000000202 Oil Cup	17-3
A221500000286 Ball Bearing	22-7
A222100000393 Filter Core	26-21
A229900001360 Washer	15-9
A229900002294 Rivet Blind	4-3, 29-3
A229900002962 Clamp	6-3
A229900002965 Hose Clamp	26-17, 26-19
A229900003011 End Right Angle Adjustable Pipe Connector	26-17
A229900003050 Pipe Connector	14-11
A229900003077 Battery Case Cover Assembly	15-9
A229900003129 Brake Hose	14-5
A229900003310 Hose Clamp	21-3
A229900003353 Seal Washer	15-3
A229900003354 Pipe Joint	14-23
A229900003463 Fitting, Adapter	14-11
A229900003816 Bush	14-9
A229900003846 Clip	26-17
A229900003851 Clamp	14-29, 15-15, 24-3
A229900003898 T-type Clamp	21-3, 21-5
A229900004205 Double Tube Clamps Lower Support	19-3
A229900004211 Ear with Bush Assembly	17-3
A229900004242 Radiator Suspension Cushion	16-3, 27-9
A229900004372 Pipe Joint	14-11
A229900004374 Three Way Adaptor Body	14-5
A229900004597 Clamp	26-17
A229900004634 Tube Clip	5-3
A229900004635 Pipe Clamp Bush	5-3
A229900004636 Tube Clip	14-11, 24-3, 27-3, 30-3
A229900004637 Pipe Clamp Sleeve	14-11, 24-3, 27-3, 30-3
A229900004645 Compressor Bracket	5-3
A229900004646 Supporting Arm	5-3
A229900004647 The Tighten Slider	5-3
A229900004665 Pipe Nip	5-3
A229900004672 Pipe Clip	2-181
A229900004673 Pipe Clamp	6-3, 27-3, 28-3
A229900005108 Brake Hose	14-23
A229900005492 Steering Power Cylinder Assembly	26-5
A229900005611 Elbow Union Connector	28-3
A229900005979 Upper Thrusting Rod Assembly	13-3
A229900005980 Lower Thrusting Rod Assembly	13-3
A229900006818 Clamp	26-17
A229900007018 Thermostat	22-9
A229900007038 Crankshaft Shock Absorber Assembly	22-7
A230200000170 Clip	2-55, 2-71
A240500000091 Electric Two Tone Air Horn	15-15
A240500000097 Electric Horn Assembly	15-15
A241200000648 Proximity Switch	15-3
A260401010096 Tyre Sleeve	7-3
A260401010097 Hexagon Sleeve for Central Rear Axle	7-3
A260401040004 Adjustable Spanner	7-3
A313180502003 Screw	2-53
A810102061108 Engine Front Suspension Cushion	23-3
A810102061109 Engine Rear Suspension Cushion	23-3
A810102072177 Engine Outlet Pipe Flange	21-5
A810201058734 Power Supply Harness	15-7
A820101026089 Elastic Beam	27-9
A820101026790 Brattice Adaptor Support	14-23
A820101026989 Soft Pad of Radiator Pressure Plate	16-3

A820101338759 Supporting Plate	27-11	JSS005299650 Assembly, body framework.....	2-129
A820101338819 Secondary Tank Outflow Rubber Hose Bracket	26-17	JSS005299654 body in white	2-11
A820101342949 Pipeline Support	5-3	JSS005302067 Sleeping Berth.....	2-13
A820101342951 Pipeline Support	5-3	JSS005302101 Rear Guard Board	2-23
A820101343021 Hose Support	14-11	JSS005320809 Panel.....	2-107
A820202005054 Flange	21-13	JSS005322023 Panel.....	2-111
A820205002231 Pipe Joint	14-11	JSS005370792 Water Shield	2-19
A820205002285 Hinged Joint	26-17	JSS005492149 Cover	2-89, 2-115
A820206013015 Inline Steel Pipe of Air Filter Hose	21-3	JSS005507362 Internal ASM	2-13
A820206021328 Air inlet tube elbow of engine ..	21-13	JSS005531923 Assy, right, 3-grade pedal	2-105
A820301021255 Pin Axis.....	17-3	JSS005531946 Assy, mid-high, roof, left, 3-grade, pedal.....	2-105
A820301990120 Lock Pin.....	7-3	JSS005531964 Assy, 3-grade pedal	2-75
A820403000883 Lower Connecting Fork	17-21, 17-23	JSS005532002 Outer decoration, assy	2-11
A820403000884 Lower Mounting Bearer	17-21, 17-23	JSS005556525 Screw plug	2-31
A820503002028 Lengthening Rod Crank Fork	7-5	JSS005561879 Left Headlamp Mask Body.....	2-89
A820606010981 Air Removing Pipe of Radiator	24-3	JSS005562297 Right Headlamp Mask Body	2-89
A820606010982 Air Exhaust Pipe of Engine	24-3	JSS005565894 Assembly, bumper	2-77
A820606020623 Outlet Pipe of Auxiliary Water Tank	24-3	JSS005568689 Assembly, accessories, brake	2-131
A820606030809 Cross Coil	28-3, 30-3	JSS005568726 Assembly, accessory	2-11
A820606030928 Intercooler Hose	21-5	JSS005571577 Bracket, fixed	2-179
A820607000222 Air Intake Flange Sealing Paper Pad	21-5	JSS005571813 Assembly, pedal	2-133
B210780000100 Bulkhead Fitting.....	14-5, 14-23	JSS005583263 Side Turning Lamp	2-63
B210780000155 Hinged Joint	26-17	JSS005589336 Framework of Collision Bumper with Frog Lamp Bracket.....	2-89
B221000000096 Alternator	22-9	JSS005648151 CONCEL	2-13
B229900001059 Clamp, T-type	21-3	JSS005648152 GROUND MAT	2-13
B229900002723 Accelerator Pedal	22-11	JSS005681906 Sleeping Box.....	2-21
B230103004461 Rubber Hose	26-17	JSS005681912 Sleeping Box.....	2-21
GJB004700779 Inner Fender Batten.....	29-3	JSS005710798 Seat Support.....	2-41
GJB005357201 Vehicle Tools.....	1-3	JSS005710916 Seat Support.....	2-41
GJB005769936 Chassis Nameplate	4-3	JSS005710952 Seat Support Assembly.....	2-39
HQ3725005SQ01 24V Power Supply Port	2-55	JSS005718280 Operator seat.....	2-13
JSS004817138 Dust Cover.....	2-37	JSS005718327 Auxiliary Driver Seat	2-13
JSS004845122 Metal Clip.....	2-107	JSS005736348 Temperature sensor bracket.....	2-129
JSS004845740 Front Wall Wiring Harness.....	2-71	JSS005819846 electric assembly.....	2-45
JSS004845743 ceiling harness	2-71	JSS005827839 Seat Air Pipe Protective Sleeve.....	2-39
JSS004845747 Floor hamess	2-71	JSS005876497 Glass Limit Block.....	2-97
JSS004846301 Floor, front.....	2-129	JSS006074189 Assy, protective plate, left pedal.....	2-111
JSS004846362 Reinforced Plate, front floor	2-129	JSS006654374 power intake plugging cover	2-55
JSS005031219 Plate, cover.....	2-129	JSS006754074 light	2-45
JSS005031223 Plate, cover.....	2-129	JSS006802552 Instrument harness.....	2-71
JSS005199162 Protective Cover of Steering Column Assembly.....	2-23	JSS006803494 harness assembly.....	2-45
JSS005199467 Left Upper Decorating Plate Front Panel Assembly	2-107	JSS006803630 electrical system.....	2-11
JSS005199479 Front Panel Left Upper Reinforced Plate	2-111	JSS006890326 Inner-decoration assembly	2-11
JSS005199529 Front Panel Hinge Assembly	2-111	JSS006997224 Thermal Insulation Pad	2-125
JSS005199531 Right Upper Decorating Plate Front Panel	2-107	JSS007015291 Glass Strip	2-17
JSS005202884 Front Cover Right Support.....	2-121	JSS007197600 Sleeping berth pad.....	2-21
JSS005202891 Front Cover Left Support.....	2-121	JSS007583165 Assy Left Door Inner Trim	2-27
JSS005234240 Rear Interior	2-31	JSS007583377 Assy Right Door Inner Trim.....	2-27
JSS005296873 Rubber Pad.....	2-93	QDP004582153 Battery Plate Separator.....	15-7
JSS005297052 Air intake passage	2-73	QDP004660499 Diesel Fil.....	30-3
		QDP004660890 Return Tube.....	30-3
		QDP004672586 Thimble of Drag Link.....	26-13, 26-15
		QDP004690687 Anti-splash Rear Baffle	29-7, 29-9
		QDP004690688 Mud Flap	29-7, 29-9
		QDP004755643 Type Fender.....	29-7, 29-9
		QDP004755648 Left Front Rear Fender with Splash Protection Assembly.....	29-3

QDP004755665 Right Front Rear Fender with Splash Protection Assembly.....	29-3	QDP005514707 Traction and Towing device	1-3
QDP004755710 Rubber Inner Baffle.....	29-3	QDP005523706 Spiral spring suspension assembly.....	2-3
QDP004766494 Rear cross beam assembly	9-7	QDP005525732 Hose connector(Φ10)	30-9
QDP004766500 Rear beam	9-9	QDP005534098 Level sensor module.....	30-3
QDP004766504 Left connecting plate of rear beam.....	9-7	QDP005539529 Oil Tank Support.....	26-17
QDP004766509 Left connecting plate of rear beam.....	9-7	QDP005545619 Steering drag link assem.....	26-5
QDP004787774 Cushion Block of Battery Frame	15-9	QDP005545628 Steering drag link	26-11
QDP004787775 Front Limit Block.....	17-3	QDP005547658 Steering Assisted Long Steel Tube	26-17
QDP004803953 Adjusting Plate	29-3	QDP005547659 Steering Assisted Short Steel Tube	26-17
QDP004812008 Connection Plate	18-5	QDP005549059 Front Brace Plate	24-11
QDP004819378 Oil water separator baffle	30-3	QDP005549062 Left Supporting Plate	24-11
QDP004912721 Bracket for Tubes	15-3	QDP005549063 Right Supporting Plate	24-11
QDP004934392 Right inner reinforced plate.....	9-3	QDP005578639 Column Jacket Bridging Beam Assy	9-5
QDP004934394 Left inner reinforced plate.....	9-3	QDP005580968 Support Rubber Block.....	24-7
QDP004934401 Backrest beam	9-7	QDP005580969 Radiator Suspension Cushion ..	24-5
QDP004994961 Power Device.....	15-3	QDP005580970 Water Tank Guardrail Welding Assembly.....	24-3
QDP005000853 Rear Support of Front Suspension	9-5	QDP005580971 Lower Supporting Plate	24-7
QDP005000854 Front support of front suspension	9-5	QDP005580973 Upper Supporting Plate	24-7
QDP005009578 Lifting Ear Pin.....	17-3	QDP005580974 Water Tank Guardrail Welding Assembly.....	24-9
QDP005015312 Fuel Tank Bracket Transition Bracket.....	30-3	QDP005585984 Front Bumper Device	1-3
QDP005016719 Steering drag link assem.....	26-5	QDP005586048 Bracket Block in Dashboard Central Support	20-3
QDP005016720 Steering drag link	26-15	QDP005586072 cylinder bracket.....	19-3
QDP005018227 Arched beam.....	9-13	QDP005588910 Connecting board of arched beam assembly.....	9-5
QDP005018228 Arched beam assembly.....	9-5	QDP005588911 Front cross rail.....	9-3
QDP005018231 Reinforcement Plate B of the arched beam	9-13	QDP005591587 Right dashboard support.....	20-3
QDP005018237 Reinforcement Plate B of the arched beam	9-13	QDP005591592 Tip mechanism of cab	1-3
QDP005024076 Rear Limit Bracket Assembly....	13-3	QDP005593841 Front suspension right bearer ...	23-3
QDP005054232 Flexible Shaft Fixed Support	27-3	QDP005593843 Soft pad connecting plate	23-5
QDP005067789 Second Axle Footboard Assembly	1-3	QDP005593844 Frame Connecting Board	23-5
QDP005126195 Transmission Control Rod	27-3	QDP005593845 Front suspension left bearer	23-3
QDP005196100 Three Way Joint	19-3	QDP005605356 Rear Rocker.....	26-7
QDP005210230 support	14-23	QDP005629836 Engine suspension device.....	1-3
QDP005232582 Pipe Support.....	14-29	QDP005630762 Steering drag link assem.....	26-5
QDP005282484 support	14-23	QDP005630763 Steering drag link	26-13
QDP005352367 Sliding Sleeve	26-7	QDP005632839 Arched beam assembly.....	9-5
QDP005376488 Ring	26-7	QDP005633073 Upper support of shock absorber.....	17-21
QDP005394557 Supporting Lever of Bumper.....	25-3	QDP005684100 Dust Cover Assembly	27-3
QDP005395946 Rocker Pin Shaft	26-7	QDP005696689 oil cylinder support.....	26-5
QDP005430882 Rear Rocker Support	26-7	QDP005738394 Steel Pipe Bracket.....	21-5
QDP005435152 Front Bumper Left Bracket	25-3	QDP005765319 pipe clamp	16-5
QDP005477266 Guide Plate Adjustment Sheet..	13-3	QDP005792846 Two-shaft wheel dashboard.....	1-3
QDP005504119 Air Reservoir Hanger.....	14-21	QDP005793918 Rear Spring Pressure Plate	13-3
QDP005504123 Air Reservoir Band	14-19	QDP005796439 Rear U Bolt	13-3
QDP005504125 Rubber Pad.....	14-19	QDP005822583 Assembly of Middle Rock Arm and Support	26-5
QDP005504127 Collar Band Assembly of Air Reservoir.....	14-17	QDP005822632 cushion block	26-5
QDP005507875 Bumper Right Lower Mounting Bracket.....	25-3	QDP005828970 Lower Stair	18-5
QDP005514676 Bumper Connecting Board	32-5	QDP005828981 Long Reinforcement Plate	18-5
QDP005514682 Draw Bar Hook Seat Assembly.....	32-3	QDP005828998 Short Reinforcement Plate	18-5
		QDP005865669 Right dashboard support.....	16-5
		QDP005865673 heat insulation plate.....	16-5
		QDP005865675 pipe support of exhaust pipe.....	16-7

QDP005865679 Reinforced bar	16-7	QDP007067789 Pipeline installation module	14-3
QDP005865680 Connecting board	16-7	QDP007067833 Energy supply module	14-3
QDP005865684 connecting board	16-7	QDP007067949 RESERVOIR MOUNTING	
QDP005865688 Reinforced bar	16-7	MODULE	14-13
QDP005865691 heat insulation plate	16-5	QDP007067990 ENERGY STORAGE	
QDP005876507 plate	16-7	MODULE	14-3
QDP005876943 Connecting pipe 2	16-7	QDP007068000 Rear axle module	14-3
QDP005918995 Second Bridge Pedal Support	18-3	QDP007068014 Auxiliary module	14-3
QDP005918996 Big Pedal	18-5	QDP007068349 Brake bundle of Pump Truck	14-3
QDP005918997 Steel Tube of Lower Stair	18-5	QDP007068370 Braking system	1-3
QDP005929553 Radiating Tube Assembly	26-17	QDP007088498 Transmission shaft system	1-3
QDP005930120 Mounting of Front Second Shaft		QDP007092433 Electrical system of chassis	1-3
Shock Absorber	17-3	QDP007098407 power module	1-3
QDP005935637 Oil Tank Module	26-17	QDP007108664 dryer Assembly	14-11
QDP005943238 Mounting of Front First Shaft Shock		QDP007108717 Air compressor steel tube	14-11
Absorber	17-3	QDP007125697 Front suspension system	1-3
QDP005943489 Upper support of shock		QDP007126019 Lower connecting plate-backrest	
absorber	17-23	beam assembly	9-3
QDP006064868 Fixed board of relay valve	14-25	QDP007126021 Upper connecting plate-backrest	
QDP006143700 Second Bridge Pedal Pole	18-5	beam assembly	9-3
QDP006143762 Reinforced Stiffener	18-5	QDP007126023 Upper connecting plate-backrest	
QDP006236225 Guide Plate	13-3	beam assembly	9-3
QDP006311937 Inter-Cooler Outlet Steel Tube ..	21-5	QDP007126027 Lower connecting plate-backrest	
QDP006312805 Air filter air-outlet rubber pipe ..	21-3	beam assembly	9-3
QDP006314357 clutch system	1-3	QDP007128299 Right Outer reinforced plate	9-3
QDP006337536 Warm air system equipment	1-3	QDP007128300 Left Outer reinforced plate	9-3
QDP006342924 Transmission system	1-3	QDP007141421 Longitudinal beam of frame, left ..	9-3
QDP006403148 Driver's Cab Assy	1-3	QDP007141422 Longitudinal beam of frame,	
QDP006641644 Basic diagram of brake	14-3	right	9-3
QDP006685113 Four Circuitl Valve Installation		QDP007141423 Carriage assembly	1-3
Module	14-13	QDP007141424 Inner beam (left)	9-3
QDP006691499 Parking relay valve mounting		QDP007141425 Inner beam (right)	9-3
module	14-23	QDP007152214 Carriage assembly	1-3
QDP006864419 hose assembly	28-3	QDP007158828 Degassing Tube Bracket 1	26-17
QDP006921781 steering gear mounting		QDP007159674 Front splashboard assembly	1-3
module	26-5	QDP007162443 Middle axle transmission shaft	
QDP006922487 steering system	26-3	assembly	31-3
QDP006924284 Wheel and rim device	1-3	QDP007165480 harness	15-3
QDP006925864 Steering system oil way	26-3	QDP007190443 Connecting board of arched beam	
QDP006928112 steering system	1-3	assembly	9-5
QDP006936695 exhaust pipe III	16-5	QDP007199761 abs harness	8-3
QDP007004269 Catalyst module	16-3	QDP007199762 abs device	1-3
QDP007004523 Exhaust tube II assembly	16-3	QDP007201662 Front first axle and spring	
QDP007004603 module of exhaust tube		module	17-3
pipeline	16-3	QDP007202066 Front first axle and spring	
QDP007011614 Exhaust device	1-3	module	17-3
QDP007025330 Inter-Cooler Inlet Steel Tube	21-5	QDP007271238 Inter-Cooler Intake Hose 1	21-3
QDP007025331 Intercooler hose	21-5	QDP007459184 Instrument monitor device	1-3
QDP007025332 Air intake device	1-3	QDP007486935 Tire and rim	10-3
QDP007029634 Water tank lower Water pipe	24-3	QDP007672264 Air compressor steel tube	14-11
QDP007029636 Charging Tube	24-3	QDP007672854 Steel Pipe -Air Compressor Output	
QDP007030891 Shroud, Fan	24-5		14-11
QDP007032192 Oil supply system	1-3	QDP007758855 pipe	16-5
QDP007032394 Cooling Module	24-3	TSC005401381 Expansion Water Tank Module ..	24-3
QDP007044786 Cooling device	1-3	TSC005542134 Bracket	24-13
QDP007067771 Front axle module	14-3		

www.sanygroup.com



Sany Automobile Hoisting Machinery Co., Ltd.

Shaoyang Avenue, Shuangqing Development Zone, Changsha, Hunan, China

Zip Code: 422000

Tel: 4008 87 8318

Website: www.sanyglobal.com

