
Sony UBP-X700



Check DVR Settings

How to Check Your Current Version

1. Turn on your player and make sure no disc is playing (if a disc automatically loads, press **STOP**).
2. From the Home screen menu, use your remote to select **Setup > System Settings**.
3. Scroll down and choose **System Information**.
4. Look at the software version listed. If it is lower than **M43.R.0292**, continue with the USB update steps below. [5]

To resolve the issue of your **Sony UBP-X700** losing its wireless network configurations, follow these device-specific troubleshooting steps: [1]

Step 1: Check "Quick Start Mode"

The most common culprit for forgotten Wi-Fi credentials on this model is a memory flush when entering deep standby mode.

1. Press the **HOME** button on your remote.
2. Navigate to **Setup > System Settings**.
3. Locate **Quick Start Mode** and change it to **On**.
This keeps a tiny amount of residual current flowing through the mainboard chipsets, preventing volatile memory drops when you turn the unit off. [2, 3]

Step 2: Clear Outdated Saved Settings

If your network name (SSID) or router password has ever changed, the player may be loop-authenticating with old data. [4]

1. Go to **Setup > Network Settings > Internet Settings**.
2. Choose your network and select **Forget Network** or **Delete Profile** if the option appears.
3. Re-select your Wi-Fi name and carefully input the password again. [3, 4, 5]

Step 3: Set a Static DNS Address

Sony network cards frequently drop handshakes with automated local IP routers. Assigning a universal DNS stabilizes the connection. [6]

1. Go to **Setup > Network Settings > Internet Settings**.
2. Select **Wireless Setup > Custom / Manual**.
3. Leave the IP Address on *Auto / DHCP*, but when you get to the **DNS Settings**, switch to **Manual**.
4. Set the **Primary DNS** to 8.8.8.8 and **Secondary DNS** to 8.8.4.4 (Google's Public DNS). [3, 6]

Step 4: Perform a Full System Reset

If the player's network partition is corrupted, a full factory refresh can fix it. [2, 7]

1. Go to **Setup > Resetting**.
2. Choose **Reset to Factory Default Settings**.
3. Select **All Settings** and confirm. Reconfigure your internet from scratch once it reboots. [2]

Alternative Workaround

As seen on the back panel of your device in the image, the unit features a physical **LAN (100)** port right next to the power plug. If your player continues to experience internal hardware memory issues with its Wi-Fi chip,

Running a standard **Ethernet cable** directly from your router will completely bypass the wireless system and provide a permanent, drop-free connection. [1, 6, 8]

Would you like help checking if your **firmware version** is outdated, or instructions on how to update it via a USB drive? [7, 9]

[1] <https://www.justanswer.com>

[2] <https://www.sony.com>

[3] <https://www.sony.com>

[4] <https://www.youtube.com>

[5] <https://www.youtube.com>

[6] <https://www.youtube.com>

[7] <https://www.justanswer.com>

[8] <https://blog.bestbuy.ca>

[9] <https://www.youtube.com>

USB Firmware Update

Updating the **Sony UBP-X700** manually using a USB drive is a great way to stabilize network performance if your player is losing its wireless configurations. [1, 2]

The latest widely distributed firmware version for manual download on this player is **M43.R.0292**. If your player shows a lower version number, it is outdated and should be updated. [3, 4, 5]

Part 1: How to Check Your Current Version

5. Turn on your player and make sure no disc is playing (if a disc automatically loads, press **STOP**).
6. From the Home screen menu, use your remote to select **Setup > System Settings**.
7. Scroll down and choose **System Information**.
8. Look at the software version listed. If it is lower than **M43.R.0292**, continue with the USB update steps below. [5]

Part 2: Preparing the USB Drive

You will need a computer and a standard USB flash drive formatted to **FAT32** or **NTFS**. [6]

1. **Download the update file:** Go to the official [Sony Drivers & Downloads Page for UBP-X700](#) on your computer. Locate and download the UPDATE_M43R0292.ZIP folder. [6]
2. **Extract the file:** Right-click the downloaded ZIP folder and select **Extract All** (or open it on a Mac). This will produce a standard unzipped folder explicitly named **UPDATE**. [6]
3. **Verify contents:** Open the extracted UPDATE folder and make sure it contains exactly four system files (MSB43-FW.BIN, MSB43-FW.ID, MSB43-FW_MB.BIN, and MSB43-FW_MB.ID). [6]
4. **Copy to USB:** Drag the entire **UPDATE** folder and drop it into the **root directory** of your USB flash drive.
 - *Note: The folder must be in the root directory (meaning directly on the drive, not tucked inside another folder), and the name must remain capitalized as "UPDATE", or the player will not recognize it. [6]*

When properly extracted, your USB root hierarchy will look like this:

-  USB Drive (D:) (*Root Level*)
 -  **UPDATE** (*Extracted folder—must be capitalized*)
 -  MSB43-FW.BIN
 -  MSB43-FW.ID
 -  MSB43-FW_MB.BIN
 -  MSB43-FW_MB.ID
 -  *Your other personal folders/files (Music, Photos, etc.)*  Sony +1

Part 3: Installing the Update on Your Player

1. Safely eject the flash drive from your computer and plug it into the front USB port of your **Sony UBP-X700**.
2. Grab your remote, navigate to the Home screen, and select **Setup**.
3. Select **Software Update**.
4. Choose **Update via USB Memory**.
5. The player will scan the drive and display a confirmation screen. Select **OK** and press **ENTER** to start the update process. [1, 4, 7]

 **Crucial Warning:** The update process takes several minutes. During this time, the player's progress bar will go from 0% to 100%, and the system will automatically power off and reboot itself multiple times. **Do not unplug the power cord or press any buttons** until the player has completely finished and returns to the standard Home screen menu. [4, 6]

Once finished, you can return to **System Information** to verify that your firmware version successfully displays **M43.R.0292**. [4, 5]

Let me know if you run into any **error messages** during the download or if the player has a **multiregion modification chip** installed! [8]

[1] <https://www.sony.com>

[2] <https://www.sony.com>

[3] <https://www.sony.com>

- [4] <https://www.sony.com>
- [5] <https://www.sony.com>
- [6] <https://www.sony.com>
- [7] <https://www.sony.com.sg>
- [8] <https://forum.blu-ray.com>