



ENGINE DOES NOT START OR IS HARD TO START	21-1
ENGINE LACKS POWER	21-2
POOR PERFORMANCE AT LOW AND IDLE SPEED	21-3
POOR PERFORMANCE AT HIGH SPEED	21-3
HYDRAULIC TAPPET	21-4
POOR HANDLING	21-5

ENGINE DOES NOT START OR IS HARD TO START

		POSSIBLE CAUSE
1. Check fuel flow to carburetor REACHING CARBURETOR ↓	NOT REACHING CARBURETOR →	1. Fuel tank empty 2. Clogged fuel tube or fuel filter 3. Sticking float valve 4. Clogged fuel tank cap breather hole 5. Faulty fuel valve
2. Perform spark test GOOD SPARK ↓	WEAK OR NO SPARK →	1. Faulty spark plugs 2. Fouled spark plugs 3. Faulty spark unit 4. Broken or shorted ignition coil 5. Faulty ignition switch 6. Faulty pulse generator
3. Test cylinder compression COMPRESSION NORMAL ↓	LOW COMPRESSION →	1. Low battery charge 2. Valve stuck open 3. Worn cylinder and piston rings 4. Damaged cylinder head gasket 5. Seized valve 6. Faulty hydraulic tappet 7. Excessive camshaft runout
4. Start by following normal procedure ENGINE DOES NOT FIRE ↓	ENGINE FIRES BUT STOPS →	1. Improper choke operation 2. Carburetor incorrectly adjusted 3. Manifold leaking 4. Improper ignition timing (Spark unit or pulse generator) 5. Fuel contaminated
5. Remove and inspect spark plug	WET PLUG →	1. Carburetor flooded 2. Choke closed 3. Throttle valve open 4. Air cleaner dirty



ENGINE LACKS POWER

		POSSIBLE CAUSE
1. Raise wheels off ground and spin by hand WHEEL SPINS FREELY ↓	WHEELS DO NOT SPIN FREELY →	1. Brake dragging 2. Worn or damaged wheel bearing 3. Wheel bearing needs lubrication 4. Drive chain too tight 5. Rear axle nut excessively tight
2. Check tire pressure PRESSURE NORMAL ↓	PRESSURE LOW →	1. Punctured tire 2. Faulty tire valve
3. Accelerate rapidly from low to second ENGINE SPEED LOWERED WHEN CLUTCH IS RELEASED ↓	ENGINE SPEED CHANGED → WHEN CLUTCH IS RELEASED	1. Clutch slipping 2. Worn clutch disc/plate 3. Warped clutch disc/plate
4. Accelerate lightly ENGINE SPEED INCREASES ↓	ENGINE SPEED DOES NOT INCREASED →	1. Carburetor choke closed 2. Clogged air cleaner 3. Restricted fuel flow 4. Clogged fuel tank vent hole 5. Clogged muffler
5. Check ignition timing CORRECT ↓	INCORRECT →	1. Faulty spark unit 2. Faulty pulse generator
6. Test cylinder compression NORMAL ↓	TOO LOW →	1. Valve stuck open 2. Worn cylinder and piston rings 3. Leaking head gasket 4. Improper valve timing 5. Excessive camshaft runout
6. Check carburetor for clogging NOT CLOGGED ↓	CLOGGED →	1. Carburetor not serviced frequently enough
7. Remove spark plug NOT FOULED OR DISCOLORED ↓	FOULED OR DISCOLORED →	1. Plugs not serviced frequently enough 2. Spark plug with incorrect heat range
3. Check oil level and condition CORRECT ↓	INCORRECT →	1. Oil level too high 2. Oil level too low 3. Contaminated oil
4. Remove cylinder head cover and inspect lubrication VALVE TRAIN LUBRICATED PROPERLY ↓	VALVE TRAIN NOT LUBRICATED PROPERLY →	1. Clogged oil passage 2. Clogged oil control orifice
5. Check for engine overheating NOT OVERHEATING ↓	OVERHEATING →	1. Excessive carbon build-up in combustion chamber 2. Use of poor quality fuel 3. Clutch slipping
6. Accelerate or run at high speed ENGINE DOES NOT KNOCK ↓	ENGINE KNOCKS →	1. Worn piston and cylinder 2. Wrong type of fuel 3. Excessive carbon build-up in combustion chamber 4. Ignition timing too advanced (Faulty spark unit or pulse generator)



POOR PERFORMANCE AT LOW AND IDLE SPEED

		POSSIBLE CAUSE
1. Check ignition timing and camshaft CORRECT ↓	INCORRECT →	1. Improper ignition timing (Faulty spark unit or pulse generator) 2. Faulty camshaft journal
2. Check carburetor pilot screw adjustment CORRECT ↓	INCORRECT →	See Fuel System Section
3. Check for leaking intake pipe NO LEAKS ↓	LEAKING →	1. Deteriorated insulator O-ring 2. Loose carburetor
4. Perform spark test GOOD SPARK ↓	WEAK OR INTERMITTENT → SPARK	1. Faulty, carbon or wet fouled spark plug 2. Faulty spark unit 3. Faulty ignition coil 4. Faulty pulse generator

POOR PERFORMANCE AT HIGH SPEED

		POSSIBLE CAUSE
1. Check ignition timing CORRECT ↓	INCORRECT →	1. Faulty spark unit 2. Faulty pulse generator
2. Disconnect fuel tube at carburetor FUEL FLOWS FREELY ↓	FUEL FLOW RESTRICTED →	1. Lack of fuel in tank 2. Clogged fuel line 3. Clogged fuel tank breather hole 4. Clogged fuel valve
3. Remove carburetor and check for clogged jet NOT CLOGGED ↓	CLOGGED →	1. Clean
4. Check valve timing CORRECT ↓	INCORRECT →	1. Cam sprocket not installed properly
5. Check valve spring tension NOT WEAKENED ↓	WEAK →	1. Faulty spring



HYDRAULIC TAPPET

TAPPET NOISE

Snap ten times or ride for five minutes with the engine speed 3,000 rpm

		POSSIBLE CAUSE
1. Check oil level and condition CORRECT ↓	INCORRECT →	1. Oil level too low 2. Contaminated oil 3. Contaminated oil filter
2. Check oil pressure NOT CLOGGED ↓	TOO LOW →	1. Clogged oil passage 2. Clogged oil control orifice
3. Remove cylinder head cover and oil hole caps and check lubrication CORRECT ↓	NOT LUBRICATE PROPERLY →	1. Clogged oil pipe 2. Defected O-ring 3. Defected oil hole cap
4. Remove hydraulic tappet and check CORRECT	INCORRECT →	1. Plunger stick 2. Defected tappet 3. Defected one way valve

ENGINE LACKS POWER

		POSSIBLE CAUSE
1. Turn the engine for a few minute with starter ENGINE DOES NOT START ↓	ENGINE START →	1. Bubbly engine oil with over rev up.
2. Check oil pressure CORRECT ↓	TOO LOW →	1. Oil level too low 2. Clogged oil passage 3. Contaminated oil 4. Contaminated oil filter
3. Remove tappet and check	INCORRECT →	1. Defect tappet



HONDA
CBX750F

21. Troubleshooting

POOR HANDLING

		POSSIBLE CAUSE
1. If steering is heavy	➔	1. Steering stem adjustment too tight 2. Damaged steering head bearings
2. If either wheel is wobbling	➔	1. Excessive wheel bearing play 2. Bent rim 3. Improperly installed wheel hub 4. Swingarm pivot bearing excessively worn 5. Bent frame
3. If the motorcycle pulls to one side	➔	1. Bent frame 2. Front and rear wheels not aligned 3. Bent front fork 4. Improperly installed front fork brace