
Branch Instructions

Instruction	B, BL	Branch, Branch Link
Format	B{L}{cond} <expression> {L} is for branch with link => PC is stored in R14(LR) {cond} is the condition flag for conditional execution <expression> is the destination (offset)</expression></expression>	
Behavior	if {cond} is met, jumps to the destination calculated by <expression>, and PC value is stored into LR if {L} option is used.</expression>	
Flag	Not affected	
Example	B there BL sub+label CMP R1,#0 BEQ fred	; unconditional jump ; destination is calculated by sub+label ; comparison between R1 and #0 ; if R1 is #0, jump to fred

- BL: Branch with link(PC값을 LR에 저장하고 branch)
- cond: 조건부 실행
- expression : 코드의 위치를 변수같은 형태로 저장해놓은 것



- Destination address calculation
 - Bits [23:0] are used as offset using PC as the basis
 - Offset calculation
 - MSB is the sign bit (+ or -)
 - The remaining 23 bits are used as offset with 2 bits left shift operation
 - 16 MB의 range -> 부호비트 빼면 8 MB range
 - Word addressing의 관점으로 접근하면 32MB range(하위 2비트는 무조건 0인것을 이용)

실습


```
r0, #1 ; 0x00
       mov
              r1, r0, r0 ; 0x04
       add
       b1
              func
                        ; 0x08
              r1, r0, r0 ; 0x0C
       add
              r1, r0, r0 ; 0x10
       sub
loop
              loop
                      ; 0x14
              r1, r0, r0 ; 0x18
func
       add
              pc, 1r
                         ; 0x1C
       mov
```

- 파이프라인 구조때문에 execution line 기준으로 fetch는 2라인 뒤, decode는 1라인 뒤에서 이루어지고 있다
- bl 실행시 돌아와서 다음으로 실행할 pc값을 Ir에 저장
 - ㅇ 브랜치 명령 실행시 파이프라인이 한번 깨짐

Subroutines

- Branch and Link (BL) instruction is used
 - Stores the next address into LR
 - LR <= PC 4: 파이프라이닝 때문에 현재 PC는 2칸앞에 있기때문에 -4 해주는 것
- Returning from subroutine
 - o MOV pc, lr

Data Processing Instructions



• ADD r0, r1, r2

COND I OP S Rn Rd #shift Sh Rm 1110 00 0 0010 0 0001 0000 00000 00 0 0010

S: set condition code

Rn:srcRd:dest

- o 11~0 비트: i가 0이면 레지스터, i가 1이면 immediate
 - shift : 쉬프트해서 넣기
- AL
 - o e0810002
 - 1110 0000 1000 0001 0000 0000 0000 0010

Arithmetic Operations

Lists

opcode	inst	behavios	explanation
0100	ADD	Rd := Rn + Op2	Add
0101	ADC	Rd := Rn + Op2 + Carry	Add with Carry
0010	SUB	Rd := Rn - Op2	Subtract
0110	SBC	Rd := Rn - Op2 - 1 + Carry	Subtract with Carry
0011	RSB	Rd := Op2 - Rn	Reverse subtract
0111	RSC	Rd := Op2 - Rn - 1 + Carry	Reverse Subtract with Carry

- Examples
 - o ADD r0, r1, r2
 - r0 = r1 + r2
 - o SUBGT r3, r3, #1
 - r3 = r3 1 (이전 명령어의 결과가 Greater Than일시)
 - o RSBLES r4, r5, #5
 - r4 = 5 r5 (이전 명령어의 결과가 Less Equal일시), set condition code (S)

실습: Carry 활용 64비트 연산

```
# 더하기
; FF FFFFFFF
     + 1
    100 00000000
1dr  r2, =0x00000001; LSB of OP2
1dr
     r5, =0x0; MSB of destination register
1dr
     r4, =0x0; LSB of destination register
adds r4, r0, r2 ; s를 이용해 carry 저장
adc
     r5, r1, r3 ; carry까지 포함한 연산
# 빼기
      100 00000000
     FF FFFFFFF
r1, =0x00000100 ; MSB of OP1
1dr r0, =0x0 ; LSB of OP1
    r3, =0x00000000 ; MSB of OP2
1dr
```

```
ldr    r2, =0x00000001 ; LSB of OP2
ldr    r5, =0x0 ; MSB of destination register
ldr    r4, =0x0 ; LSB of destination register

subs    r4, r0, r2
sbc    r5, r1, r3
```

Logical Operations

Lists

opcode	inst	behavior	explanation
0000	AND	Rd := Rn AND Op2	AND
1111	ORR	Rd := Rn OR Op2	OR
0001	EOR	Rd := Rn XOR Op2	Exclusive OR
1110	BIC	Rd := Rn AND (NOT Op2)	Bit Clear

- ㅇ 틀린부분있음 주의
- Examples
 - o AND r0, r1, r2
 - o BICEQ r2, r3, #7
 - BIC: AND의 반대개념이라고 보면됨
 - EQ
 - o EORS r1, r3, r0
 - **■** S

Comparison Operations

- No 'S' postfix to affect condition flags
- Lists

opcode	inst	behavior	expanation
1010	CMN	CPSR flags := Rn + Op2	Compare Negative
1011	CMP	CPSR flags := Rn-Op2	Compare
1000	TEQ	CPSR flags := Rn EOR Op2	Test bitwise equality
1001	TST	CPSR flags := Rn AND Op2	Test bits

- Examples
 - o CMP r0, r1
 - TSTEQ r2, #5

Data Move Operations

Lists

opcode	inst	behavior	explanation
1101	MOV	Rd := Op2	Move register or constant
1111	MVN	Rd := 0xFFFFFFF EOR Op2	Move Negative register

- Examples
 - o MOV r0, r1
 - r1 -> r0
 - o MOVS r2, #10
 - 10 -> r2
 - o MVNEQ r1, #0
 - if zero flag set then 0 -> r1
- Idr은 오래걸리는 연산, mov도 비슷한 기능 수행가능
 - o 하지만, mov로 immediate값을 넣을려고 할 경우, 특정 조건을 만족하는 값들만 넣을 수 있음

Arithmetic Operation with Shift


- 값을 shift 해서 들어오게 할 수 있음
- Benefit
 - Arithmetic operation on the operands where shift operation to 2nd operand is applied in a single instruction
 - Barrel shifter is used
- Arithmetic operation with shift format
 - o Immediate value based

- (LSL: Logical Shift Left)
- Register value is used for shift bits

- ASR(**Arithmetic** Shift Right): The signed value of the contents of a register divided by a power of two. It copies the sign bit into vacated bit positions on the left
 - o 대상을 숫자로 보고, 부호비트를 복사해서 shift, 오른쪽으로shift할때만 중요
- LSL(=ASL): The value of a register is **multiplied** by a power of two
 - ㅇ 논리적 연산: 새로 들어온 값은 무조건 0
- LSR: The unsigned value of a register is **divided** by a variable power of two
 - Both instructions(LSL, LSR) insert zeros into the vacated bit positions
- ROR(Rotate): The value of the contents of a register rotated by a value
 - The bits that are **rotated off the right end** are inserted into the vacated bit **positions** on the left
 - o ROL은 명령어들 표현을 위해 3비트를 쓰기 아까워서 안씀(어차피 ROR로 표현 가능)

Operand 2 and Immediate Value

- How we can use big immediate values in the limited space inside 32 bits instruction format?
 - A tricky method to represent immediate values using just 12 bits



- 8비트만 immediate value로 쓴다
- 4비트는 #rot로 사용, #rot * 2 만큼 ROR한 value로 인식
 - 2의 배수 단위만 표현 가능
- Valid Immediate Values : 두칸단위(여덟비트)의 align 확인
 - o 0x000000FF
 - o 0x00000FF0
 - o 0xFF000000
 - o 0xF000000F
- Invalid Immediate Values
 - o 0x000001FE1
 - o 0xF000F000
 - o 0x55550000

PSR Transfer Instruction

- PSR(Program Status Register) needs special treatment
 - The only possible way to access is through moving register contents between general purpose registers and PSRs
 - MRS: Move PSR to Register
 - o MSR: Move Register to PSR
- CPSR(Current Program Status Register)
 - CPSR can be accessed at all the operation modes
 - Only **condition fields** can be modified at USER mode
- SPSR(Saved Program Status Register)
 - o Each operation mode has a dedicated SPSR
 - user mode does not have SPSR

MRS

Inst	MRS	Move PSR to Registers
Format	MRS(cond) Rd, <psr> {cond} is the condition for execution <psr> is either CPSR or SPSR</psr></psr>	
Behavior	Move PSR to R	d
Example	MRS r0, CPS	R ; r0 := CPSR

MSR

Inst	MSR	Move Register to PSR	
Format	MSR{cond} <psr[_fields]>, Rm {cond} is the condition for the execution <psr> is either CPSR or SPSR [_fields] is specific fields in PSR (condition flag(f), control bits(c),)</psr></psr[_fields]>		
Behavior	Move Rm to <psr[_fields]></psr[_fields]>		
Example	MSR CPSR, r0 ; CPSR := r0 MSR CPSR_f, r0 ; CPSR condition flags bits := r0 MSR CPSR_fc, r1 ; CPSR flags, control bits := r1 MSR CPSR_c, #0x80 ; CPSR control bits := 0x80		

- Controbl bits 중 i bit와 f bit가 중요(IRQ, FIQ 관련 비트)
- f(Condition flag bit), c(Control bits)