## **Programming - Initialization**

i This walkthrough is for the example program that DOES NOT include autonomous. For the autonomous program click here!

Before the bulk of our program begins, we need to first establish our variables and tell our motors how we want them to run. This section of code will run once when the program is activated and before we hit "Play" on the Driver Hub.

```
to runOpMode
REVStarterBotTeleOp2025
  Establishing the direction and mode for the motors
                 . Mode ▼
                                 RunMode
                                             RUN USING ENCODER
   set flywheel •
                           to
   set flywheel *
                 Direction
                                    Direction
                                               REVERSE
   set coreHex *
                 Direction
                                    Direction
                                               REVERSE
                               to
   set leftDrive . Direction
                               to
                                    Direction
                                               REVERSE
   set servo . Power to
                               0
  Setting our velocity targets. These values are in ticks per second!
   set bankVelocity to 1300
   set farVelocity to
   set maxVelocity to
   call waitForStart
            call opModelsActive
```

Initialization Code

## **Motor and Servo Settings**

Since we are going to be using velocity control for our flywheel, we need to set it up to run with encoders enabled. It has also been set to be reversed due to the direction it rests on our robot. Our Core Hex being used for the feeder is reversed for a similar reason.

Meanwhile the motors on our drivetrain are a mirror of each other, therefore one needs to be set to run in reverse. In this case, we have the leftDrive motor set to run in reverse.

Lastly, our servo is set to no power. Though it's not being used quite yet this helps to make sure it's properly enabled for when it's later called. You may hear it twitch slightly when initializing the program!

```
REVStarterBotTeleOp2025
  Establishing the direction and mode for the motors
                   Mode ▼
                                              RUN USING ENCODER
   set flywheel *
                            to
                                  RunMode
   set flywheel
                   Direction
                                     Direction
                                                REVERSE
                               to
  set coreHex
                   Direction
                               to
                                     Direction
                                                REVERSE
                  Direction
                                     Direction
                                                REVERSE
  set [leftDrive]
                               to
   set servo v
                Power v to
```

## **Initializing Variables**

① To learn more about "What is a Variable?" check out our Hello Robot tutorial! ↗

```
Setting our velocity targets. These values are in ticks per second!

set bankVelocity to 1300

set farVelocity to 1500

set maxVelocity to 2200
```

The three variables used in our program this year are used to set targets for what velocity our flywheel needs to reach. If at any time the target velocity needs to be adjusted it only has to be updated here to reflect through the whole code!

Variable	Purpose
bankVelocity	The flywheel velocity target for launching balls while against, or close to the goal
farVelocity	The flywheel velocity target for launching balls from a few feet back from the goal
maxVelocity	The "max" velocity for the flywheel. This can be increased, but is not recommended

Variations in your robot build may require these values to be changed. For example, adjusting the deflector may allow the robot to do far shots from further away.

We encourage experimenting with different velocities to determine what works best for your team and robot!