

Description	Content	Type	Cause
Actuator output:	12 V low	alarm	The measured 12 V actuator supply voltage on the iXspray PCB is lower than 9.0 V.
Actuator output:	5 V low	alarm	The measured 5 V actuator supply voltage on the iXspray PCB is lower than 4.5 V.
ECU output:	12 V low	alarm	The measured 12 V ECU supply voltage on the iXspray PCB is lower than 9.0 V.
ECU output:	5 V low	alarm	The measured 5 V ECU supply voltage on the iXspray PCB is lower than 4.5 V.
Front steering sensor	Steering limit exceeded	alarm	The value of the front wheel sensor is lower than 20 or higher than 900 counts. Not working on the steering calibration page.
Rear steering sensor	Steering limit exceeded	alarm	The value of the rear wheel sensor is outside the configured range of + and - 70 counts. Example: if the range is 100-500-100, then the configured range is 330 to 670.
Central steering	Central position not reached	alarm	If the centre position of the wheels is not reached within a certain period of time after activating auto-mid-steer mode.
Pump speed	Pump RPM too high (>600 RPM)	alarm	The spray pump speed exceeds 600 RPM. To avoid temporary spikes, this alert becomes visible after 3 seconds.

Valve position:	Not in position	alarm	An automatic valve (suction or pressure valve) has not reached the required position. Only when the "valve feedback" parameter is enabled?
Boom height	Boom out of sensor range	alarm	The boom height sensor value is less than 40 or more than 982.
Autosteer mode error (self-propelled machine)	Steering mode unchanged	alarm	Indicates a communication issue with the selfpropelled machine's control system. (from 1.12)
Nozzle communication	No communication	alarm	Triggered after hypro-communication error.
Reconnecting TC	Uploading changes to the task controller	alarm	Connection to Task Controller is required again due to the configuration change of the machine section.
Tank (iXclean Pro)	The tank is not empty	warning	The tank level should be below 10 L for proper cleaning.
Service pump	Replace pump diaphragms	warning	This warning is displayed after 400 hours or two years.
Automatic steering off	Automatic steering away. The wheels will centre.	notification	Folding the boom while autosteer is active. Triggers also display alarms when steering limits are exceeded, but this is a bug (SED3721-3377).
PTO shaft off	Switching the PTO shaft off	notification	In the final step of iXclean and ENFO for circulation booms.

Boom locked	Unlock the boom first	notification	An action requiring a locked boom is initiated. Actions not allowed with a locked boom: - activating slope correction.
Boom unlocked	Lock the boom first	notification	An action requiring an unlocked boom is initiated. Actions not allowed with an unlocked boom: - activating folding 1 or 2 (inner boom parts).
Unfolding the boom	Unfold the boom first	notification	Unfolding the boom is required before releasing the pendulum locking.
Boom height	Minimum height	notification	The boom is at its minimum height and the user tries to lower it.
No steering	Speed too high for steering	notification	When the steering is activated, but the speed is too high to steer. With arms folded and manual steering, the speed is too high to steer at over 6 km/h.
Steering limit	Maximum angle:	notification	The user tries to steer when the wheels are already at the maximum angle.
Set valves	Put valves in the indicated position	notification	The user must set the suction/pressure valve to a specific position.
Folded boom	Unfold the boom first	notification	The user tried to switch on ERGODRIVE while the spray boom was folded.
Change nozzle	Preset changed, nozzle replaced!	notification	User switches to a pre-set that requires the use of a different nozzle.

NO 4-wheel steering	Switch on four-wheel steering first	notification	This switch is activated when the machine is selfpropelled and the 4WS switch is not on.
Maximum boom height	Boom exceeds maximum height	notification	When boom rises above set height (Only with mounted boom height sensor)
User spray nozzles	All user-defined spray nozzles will be deleted. Continue?	dialogue	All custom nozzles are reset to factory settings when the user attempts to reset them.
Total lifespan	Was the area sprayed again this season?	dialogue	When user tries to reset the season counter.