SIZE:143x210mm

SHARP

EO-G120-K3

100L Electric Oven

Please read these instructions carefully before operating the appliance.

OPERATION MANUAL

Safety Notices

Please follow this instruction manual strictly to operate this unit correctly.
To avoid personal injury and property loss, please comply with the following safety notices. Accidents may occur if the user doesn't comply with the safety notices and operates the unit incorrectly.

- Do not touch hot surfaces. Use handles or knobs.
- Close supervision is necessary when any appliances are used by or near children.
- To protect against electric shock, do not immerse cord, plug, or any parts of the oven in water or other liquid.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not operate appliances with damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliances to the nearest Authorized Service Center for examination, repair, or adjustment.
- The use of accessory attachments not recommended may cause hazard or injury.
- Do not place on or near a hot gas or electric burner, or in a heated oven or in a microwave oven.
- When operating the oven keep at least four inches of space on all sides of the oven to allow for adequate air circulation.
- Unplug from outlet when not in use and before cleaning. Allow cooling before putting on or taking off parts, and before cleaning.
- To disconnect, turn the control to OFF, then remove the plug. Always hold the plug, but never pull the cord.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not cover any part of the oven with metal foil.
- Do not clean with metal scouring pads pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- Never leave the appliances unattended while broiling or toasting.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may cause if the oven is covered or touching inflammable material, including curtains draperies, walls and like, when on operation. Do not store any item on the oven during operation.

Distribution in GCC:

- Extreme caution should be exercised when using containers constructed of anything other than metal or glass.
- Do not place any of the following materials in the oven: cardboard, plastic, paper, or anything similar.
- Do not store any materials, other than recommended accessories, in this oven when not oven.
- Always wear protective, insulated oven gloves when inserting or removing items from the hot oven.
- Do not use outdoors.
- Do not use appliance for other than intended use;
- The appliances are not intended to be operated by means of an external timer or separate remote-control system;
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliances is intended to be used in household and similar applications such as:
  -Staff kitchen areas in shops, offices and others working environments
  -Farm houses
  -by clients in hotels, motels and other residential type environments
  -bed and breakfast type environments

If you have any concerns regarding the performance and use of your appliance, please visit www.sharpmea.com

Ensure the above safety precautions are understood. Read carefully and save all the instructions provided with an appliance.

Parts' Name

1. Switch control for rotisserie& convection functions
2. Temperature control
3. Switch for heating
4. Timer
5. Rotisserie set
6. Wire rack
7. Bake tray
8. Tray handle
9. Rotisserie handle





Note: The inner lamp always works during the oven timer is on.

SPECIFICATIONS:

Voltage: 220-240V 50/60Hz

Power: 2800W

SHARP

EO-G120-K3

فرن كهربائي سعة 100 لتر

دليل التشغيل

ملاحظات السلامة

Operation Method

Before using your oven/toaster

Before using your toaster oven for the first time, be sure to:

1. Read all of the instruction included in the manual.
2. Make sure that the oven is unplugged and the Time control is in the "OFF" position.
3. Wash the accessories in hot soapy water or in the dishwasher.
4. Thoroughly dry all accessories and re-assemble in oven, plug oven into outlet and you are ready to use your new toaster oven.
5. After -reassembling your oven, we recommend that you run it at the highest temperature on the toast function for approximately 15 minutes for eliminate any packing residue that may remain after shipping. This will also remove all traces of odor initially present.

Please note: initial start-up operation may result in minimal smell and smoke. This is normal and harmless. It is due to burning of the protective substance applied to the heating elements in the factory.

Using your electric oven

1. **Function control**: this oven is equipped with different positions for a variety of cooking needs:

☐	: Off
⊛	: The convection function is on;
⊟	: The rotisserie function is on;
⊞	: The rotisserie and convection functions are working together.

2. **Temperature control**: choose the desired temperature from 100℃ to 230℃ for cooking.
3. **Switch for heating**: this oven is equipped with different positions heating for a variety of cooking needs:

☐	: Off
⊤	: Upper heating element is working
⊥	: Lower heating element is working
⊟	: Upper and lower heating elements are working together

4. **Time control**: when you turn the control to the right (clockwise). This function has a bell which will ring at the end of the programmed time.

أسماء الأجزاء





طريقة التشغيل

قبل استخدام الفرن/المحمصة

استخدام الفرن الكهربائي

Cleaning and Maintenance

1. It is important that you clean the appliance after each use to prevent an accumulation of grease and avoid unpleasant odors.
2. Allow the appliance to cool and unplug from outlet before cleaning.
3. Do not immerse appliance in water or wash it under waterspout.
4. Removable wire rack, bake pan, crumb tray can be washed, as normal kitchenware.
5. Clean outside of appliance with a damp sponge.
6. Do not use abrasive cleaners or sharp utensils to clean the oven, as scratching may weaken it and cause shattering.
7. Let all parts and surfaces dry thoroughly prior to plugging oven in and using.

Disposal

Old appliances must be put out of order.

About the latest ways for disposal contact at your retailer or at your local authority.

Repairs

Danger: Electrical appliances must only be repaired by authorized specialists, because damages can occur by non-authorized repairs. In the case of a repair, contact your retailer or contact the producer.

تمیز کردن و نگهداری

التنظيف والصيانة

SHARP

EO-G120-K3

فر برقی 100 لیتری

راهنمای کاربری

نحوه کارکرد دستگاه

پیش از استفاده از فر/توستر

استفاده از فر برقی

نام قطعات





هشدارهای ایمنی